



**TECHNICIAN'S REPAIR
MANUAL**
Tracker EV

Released MAY 2019

699330-B
Revised JULY 2019

For any questions about material in this manual, contact an authorized representative.

Read and understand all labels on the vehicle. Always replace any damaged or missing labels.

Steep hills allow the vehicles to move at faster speeds than speeds on a flat surface. To prevent the loss of vehicle control and possible injury, speeds must be controlled to the maximum level ground speed indicated in the GENERAL SPECIFICATIONS section. Apply the brake to control the speed.

If you operate the vehicle above the maximum specified speed, you can damage the drivetrain components. The damage caused by speeds more than the maximum specified can cause a loss of vehicle control, is abuse, and will not be covered under the warranty.

Refer to the TRANSPORTING VEHICLE section to learn how to tow or move the vehicle from one location to another location.

If the vehicle is used in a commercial environment, signs must be in position to inform of possible conditions that can be dangerous. Examples shown below.



NOTICES, CAUTIONS, WARNINGS AND DANGERS

Read the **NOTICES, CAUTIONS, WARNINGS** and **DANGERS**. The person who services a vehicle needs the mechanical skill and experience to see possible hazardous conditions. Incorrect service or repairs can cause damage to the vehicle or make the vehicle dangerous to operate.

NOTICE: A **NOTICE** indicates and describes information not related to personal injury.

CAUTION A **CAUTION** indicates a dangerous condition that can cause injury that is not life threatening.

WARNING A **WARNING** indicates a dangerous condition that can cause death or serious injury.

DANGER A **DANGER** indicates a dangerous condition that will cause death or serious injury.

NOTICE: The exhaust emissions of this vehicle engine complies with regulations set forth by the Environmental Protection Agency (EPA) of the United States of America (USA) at time of manufacture. Significant fines could result from modifications or tam-

pering with the engine, fuel, ignition or air intake systems.

WARNING Engine exhaust from this product contains chemicals known, in certain quantities, to cause cancer, birth defects, or other reproductive harm.

The battery posts, terminals and all related accessories contain lead and lead compounds. Wash your hands after you contact any of these components.

REPAIR AND SERVICE MANUAL 72V ELECTRIC POWERED VEHICLE

TRACKER EV

STARTING MODEL YEAR 2020

Never modify the vehicle in any way that will alter the weight distribution of the vehicle, decrease its stability or increase the speed beyond the factory specifications. Such modifications can cause serious personal injury or death. The manufacturer prohibits and disclaims responsibility for any such modifications or any other alteration which would adversely affect the safety of the vehicle.

The manufacturer reserves the right to incorporate engineering and design changes to products in this manual, without obligation to include these changes on units sold previously.

The information contained in this manual may be revised periodically by the manufacturer, and therefore is subject to change without notice.

THE MANUFACTURER DISCLAIMS LIABILITY FOR ERRORS IN THIS MANUAL, and SPECIFICALLY DISCLAIMS LIABILITY FOR INCIDENTAL AND CONSEQUENTIAL DAMAGES resulting from the use of the information and materials in this Manual.

These are the original instructions as defined by 2006/42/EC.

Manufacturer Information:

Textron Specialized Vehicles, Inc.
1451 Marvin Griffin Road
Augusta, Georgia, USA 30906-3852

Dealer: 800-286-4804
Consumer: 877-294-6727

www.trackeroffroad.com

California Proposition 65

WARNING

Operating, servicing and maintaining a passenger vehicle or off-road vehicle can expose you to chemicals including phthalates and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, wear gloves and wash your hands frequently when servicing your vehicle.

For more information go to www.P65Warnings.ca.gov/passenger-vehicle.

This vehicle has been designed and manufactured in the United States of America (USA). The Standards and Specifications listed in the following text originate in the USA unless otherwise indicated.

The use of non-Original Equipment Manufacturer (OEM) approved parts can void the warranty.

BATTERY PROLONGED STORAGE

Batteries self-discharge over time. The rate of self-discharge varies depending on the ambient temperature, the age and condition of the batteries.

Fully charged batteries will not freeze in winter temperatures unless the temperature falls below -75°F (-60°C).

For winter storage, the batteries must be clean, fully charged and disconnected from any source of electrical drain.

The battery charger can be left connected to the vehicle to maintain a full charge on the batteries, provided the charger is plugged into an active electrical source. If power to the electrical source is disconnected or interrupted, the battery charger will continue to check the charge on the battery pack. This will draw power from the battery pack and eventually drain the batteries if power is not restored in a timely manner.

As with all electric vehicles, the batteries must be checked and recharged as required or at a minimum of 30 day intervals.

Check and maintain the proper fluid level in all battery cells during the storage period. Proper fluid level is required for maximum battery performance.

BATTERY DISPOSAL

Lead-acid batteries are recyclable. Return whole scrap batteries to distributor, manufacturer or lead smelter for recycling. For neutralized spills, place residue in acid-resistant containers with absorbent material, sand or earth and dispose of in accordance with local, state and federal regulations for acid and lead compounds. Contact local and/or state environmental officials regarding disposal information.

SAFETY INFORMATION

This manual has been designed to assist the owner-operator in maintaining the vehicle in accordance with procedures developed by the manufacturer. Adherence to these procedures and fault testing tips will ensure the best possible service from the product. To reduce the chance of personal injury and/or property damage, the following instructions must be carefully observed:

GENERAL

Many vehicles are used for a variety of tasks beyond their original intended use; therefore it is impossible to anticipate and warn against every possible combination of circumstances that may occur. Warnings cannot replace good common sense and prudent driving practices. Common sense and prudent driving practices do more to prevent accidents and injury than warnings and instructions can provide.

The manufacturer strongly suggests anyone operating the vehicle read the entire owner's guide provided with the purchase of the vehicle, paying particular attention to the CAUTIONS, WARNINGS and DANGERS within.

For any questions or concerns, contact the closest representative, or write to the address on the back cover of this publication, Attention: Customer Care Department.

The manufacturer reserves the right to make design changes without obligation to make these changes on units previously sold and the information contained in this manual is subject to change without notice.

The manufacturer is not liable for errors in this manual or for incidental or consequential damages that result from the use of the material in this manual.

This vehicle conforms to the current applicable standard for safety and performance requirements.

This vehicle is designed and manufactured for off-road use. It does not conform to Federal Motor Vehicle Safety Standards and is not equipped for operation on public streets. Some communities may permit these types of vehicles to be operated on their streets on a limited basis and in accordance with local ordinances.

Ensure all electrical accessories are grounded directly to the battery (-) post. **Never use the chassis or body as a ground connection.**

Refer to GENERAL SPECIFICATIONS for vehicle seating capacity. Do not exceed number of occupants indicated.

⚠ WARNING *Never modify the vehicle in any way that will alter the weight distribution of the vehicle, decrease its stability, increase the speed or extend the stopping distance beyond the factory specification. Such modifications can result in serious personal injury or death.*

Modifications that increase the speed and/or weight of the vehicle will extend the braking distance and may reduce the stability of the vehicle. Do not make any such modifications or changes. The manufacturer prohibits and disclaims responsibility for any such modifications or any other alteration which would adversely affect the safety of the vehicle.

Speed should be moderated by the environmental conditions, terrain and common sense.

GENERAL OPERATION

ALWAYS:

- Use the vehicle in a responsible manner and maintain the vehicle in safe operating condition.
- Read and observe all warnings and operation instruction labels affixed to the vehicle.
- Follow all safety rules established in the area where the vehicle is being operated.
- Reduce speed to compensate for poor terrain or conditions.
- Apply service brake to control speed on steep grades.
- Reduce speed in damp or wet areas.
- Reduce speed and use caution when approaching sharp or blind turns.
- Reduce speed and use caution when driving over loose terrain.
- Reduce speed and use caution when driving in areas where pedestrians are present.

SAFETY INFORMATION

MAINTENANCE

ALWAYS:

- Replace damaged or missing warning, caution or information labels.
- Maintain the vehicle in accordance with the manufacturer's periodic service schedule.
- Ensure that repairs are performed by trained and qualified persons.
- Follow the manufacturer's maintenance procedures.
- Insulate any tools used within the battery area in order to prevent sparks or battery explosion.
- Check the polarity of each battery terminal and be sure to rewire the batteries correctly.
- Use specified replacement parts. Never use replacement parts of lesser quality.
- Use recommended tools.
- Determine that tools and procedures not specifically recommended by the manufacturer will not compromise the safety of personnel, nor jeopardize the safe operation of the vehicle.
- Support the vehicle using wheel chocks and safety stands. Never get under a vehicle that is supported by a jack. Lift the vehicle in accordance with the manufacturer's instructions.
- Never attempt to maintain a vehicle in an area where exposed flame is present or persons are smoking.
- Be aware that a vehicle that is not performing as designed is a potential hazard and must not be operated.
- Test drive vehicle after repairs or maintenance in a safe area free of vehicular and pedestrian traffic.
- Keep complete records of the maintenance history of the vehicle.

VENTILATION

ALWAYS:

- Charge vehicle in a well ventilated area.
- Charge in an area free of flammable liquids and items.
- Charge a vehicle in an area that is free from flame or spark. Pay particular attention to natural gas or propane gas water heaters and furnaces.
- Use a dedicated circuit for battery charger. Do not permit other appliances to be plugged into the receptacle when the charger is in operation.
- Operate charger in accordance with manufacturers recommendations or applicable electrical code.

TABLE OF CONTENTS

SAFETY INFORMATION

GENERAL	III
GENERAL OPERATION	III
MAINTENANCE	IV
VENTILATION.....	IV

GENERAL INFORMATION AND ROUTINE MAINTENANCE

SERIAL NUMBER AND PIN PLATE LOCATION	1
SERVICING THE VEHICLE	1
ROUTINE MAINTENANCE	2
POWERTRAIN MAINTENANCE.....	2
BRAKES.....	2
TIRES.....	2
VEHICLE CLEANING AND CARE	2
VEHICLE CARE PRODUCTS.....	3
OPS, CANOPY TOP AND WINDSHIELD	3
TRANSPORTING VEHICLE	3
EMERGENCY ELECTRIC PARK BRAKE RELEASE.....	3
TOWING A TRAILER.....	4
PROLONGED STORAGE.....	4
HARDWARE	4
TORQUE SPECIFICATIONS.....	5
CAPACITIES AND REPLACEMENT PARTS	5

SAFETY

NOTICES, CAUTIONS, WARNINGS AND DANGERS	7
IMPORTANT SAFETY WARNING.....	7
MODIFICATIONS TO VEHICLE	7
GENERAL MAINTENANCE.....	7
BEFORE SERVICING VEHICLE	7
LIFTING THE VEHICLE.....	8
How to Lift the Vehicle	8
Lift Front of Vehicle	9
Lift Rear of Vehicle	9
Lower Vehicle	9

TABLE OF CONTENTS

ACCELERATOR

ACCELERATOR PEDAL	11
Pedal Replacement	11

BATTERIES AND BATTERY CHARGER

SAFETY	13
BATTERY	13
Batteries Removal	14
Battery Installation	15
BATTERY MAINTENANCE	15
At Each Charging Cycle	15
Monthly	16
Temperature Affects Battery Capacity	16
.....	16
Electrolyte Level and Water	16
Cleaning Batteries	17
Prolonged Storage	17
Battery Charging	18
AC Voltage	18
FAULT TESTING	18
Hydrometer	19
Using Hydrometer	19
BATTERY CHARGER	20
Charger Description	20
Portable Charger Installation	20

BODY

GENERAL	23
BODY COMPONENT REPLACEMENT	23
Rocker Panel Replacement	24
Gauge Panel Replacement	24
Cowl Replacement	25
Removal of Headlight Grille Assembly	25
Instrument Panel Replacement	26
Rear Fender Replacement	28
Seat Wrap and Closeout Replacement	29
Rear Closeout Panel Replacement	30

TABLE OF CONTENTS

PAINTING	31
Minor Scratches	31
Larger Scratches	31
Complete Panel Repair	31
BRAKES	
MAINTENANCE	33
Daily Brake Performance Test	33
Brake System Inspection	33
MASTER CYLINDER	34
Master Cylinder Replacement	34
Brake Fluid	35
REPLACEMENT OF WEAR ITEMS	35
Brake Pads Replacement	35
Rotor Replacement	36
BLEEDING AND FLUSHING	36
Bleeding	36
Bleeding Sequence	37
Flushing	37
BRAKE PEDAL REMOVAL AND INSTALLATION	38
ELECTRICAL	
VOLTAGE TESTING FOR BATTERIES	45
MAIN HARNESS	45
Power Supply	45
Accessory Wiring	46
Faulty Wire Replacement	46
Headlight Bulb Replacement (Standard)	46
Tail light Replacement	46
ELECTRONIC SPEED CONTROL	47
Speed Sensor	47
Rotary Position Sensor	47
Controller	47
Controller Replacement	48
Solenoid Replacement	49
DC to DC Converter	50

TABLE OF CONTENTS

FAULT TESTING	51
General	51
Testing Battery Voltage	51
Continuity Check	51
Testing A Switch for Continuity	51
Testing A Solenoid for Continuity	52
ACCESORIES	52
Key Switch	52
State of Charge (SOC) Meter	52
Rocker Switches	53
12V Outlet	53

FRONT CV SHAFT, SUSPENSION, AND STEERING

FRONT SUSPENSION	55
Front Strut Assembly Replacement	55
Control Arm Assembly Replacement	56
Lower Ball Joint Replacement	56
Wheel Bearing Replacement	57
Strut Replacement	58
FRONT AXLE	59
CV Shaft Replacement	59
CV Joint Boot Replacement	60
Front Differential Replacement	60
STEERING.....	61
Steering Wheel Replacement	61
Steering Column Replacement	62
Steering Rack Replacement	63
Tie Rod Removal	64
Tie Rod Installation	64
MAINTENANCE.....	64
Wheel Alignment	64

MOTOR

GENERAL.....	67
Motor Brake Removal	67
Motor Brake Installation	67
Front Motor Removal	68

TABLE OF CONTENTS

Front Motor Installation	69
Rear Motor Removal	70
Rear Motor Installation	71
MOTOR TESTS	71
SEATING AND OPS	
SEATING	73
Front Seat Removal and Installation	73
Front Seat Back and Support	73
Rear Seat Removal and Installation	73
Seat Cushion Disassembly	75
Footrest Removal and Installation	75
Seat Belt Removal and Installation	75
Front Seat Belt Buckle Replacement	76
Rear Seat Belt Buckle Replacement	76
UPPER OPERATOR PROTECTION SYSTEM	78
Upper OPS Frame Removal and Installation	78
LOWER OPERATOR PROTECTION SYSTEM	79
Brush Guard Removal and Installation	79
OPS Lower Weldment Removal and Installation	80
REAR AXLE AND SUSPENSION	
REAR AXLE	83
Maintenance	83
Checking the Lubricant Level	83
Rear Axle Removal	83
Rear Axle Installation	84
Rear Axle Disassembly	85
REAR SUSPENSION.....	85
Shock Absorber Removal	85
Shock Absorber Installation	85
Rear Leaf Spring Removal	86
Rear Spring Installation	86
FAULT TESTING	
SUSPENSION AND STEERING.....	89
CURTIS CONTROLLER	90

TABLE OF CONTENTS

General	90
Navigation	90
Changing Data Value	90
Favorites	90
Main Menu Definitions	91
Fault Code Chart	95
Curtis Handheld Diagnostic Tool Function	103
ELECTRICAL FAULT TESTING	115
Front - Slave and Rear - Master	115
Controller Location and Mounting Configuration	116
COMPONENT TESTING	116
Voltmeter	116
Fuses - Testing	117
Key Switch - Testing	117
State of Charge (SOC) Meter - Testing	118
Electronic Speed Controller Solenoid - Testing	118
Temperature Sensor - Testing	119
Electronic Speed Sensor - Testing	119
AC Motor Bench Test	120

WEATHER PROTECTION

GENERAL	123
Transporting Vehicle	123
CANOPY TOP	123
Canopy Top Removal	123
WHEELS AND TIRES	125
WHEEL AND TIRE SERVICE	126
Tire Repair	126
Wheel Installation	126
VEHICLE SPECIFICATIONS	129
Tracker EV	129

PERIODIC SERVICE SCHEDULE

PSS	131
-----------	-----

APPENDIX A

BATTERY CHARGER USER'S GUIDE	133
------------------------------------	-----

GENERAL INFORMATION AND ROUTINE MAINTENANCE

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

GENERAL INFORMATION AND ROUTINE MAINTENANCE

SERIAL NUMBER AND PIN PLATE LOCATION

The PIN plate is attached to the frame below the seat wrap panel (Ref. Fig. 3).

Two serial number labels, PART A and PART B, and a PIN label are attached to the frame below the flip seat (Ref. Fig. 2).

Design changes occur continuously. When you order service parts, the PIN number, manufacture date code, or serial number must be available.




Fig. 1 SN Label




Fig. 2 Serial Number and PIN Labels




Fig. 3 PIN Plate

SERVICING THE VEHICLE

WARNING To prevent severe injury or death, resulting from improper servicing techniques, observe the following warnings:

Do not attempt any type of servicing operations before reading and understanding all notes, cautions, and warnings in this manual.

Any service that requires adjustments to be made to the powertrain while the motor is in operation must be made with all four wheels raised.

Wear eye protection when working on the vehicle. In particular, use care when working around batteries or using solvents or compressed air.

To reduce the possibility of causing an electrical arc, which could cause a battery explosion, disable all electrical loads from the batteries before removing any heavy gauge battery wires.

To prevent the possibility of motor disintegration in the electric powertrain, never operate vehicle at full throttle for more than 4 - 5 seconds while vehicle is in a "no load" condition (all 4 wheels off of the ground).

It is in the best interest of both vehicle owner and servicing dealer to carefully follow the procedures recommended in this manual. Adequate preventative maintenance, applied at regular intervals, is the best guarantee for keeping the vehicle both dependable and economical.

In any product, components will eventually fail to perform properly as the result of normal use, age, wear, or abuse.

It is impossible to anticipate all possible component failures or the manner in which each component can fail.

A vehicle requiring repair indicates that the vehicle is no longer functioning as designed and should be considered potentially hazardous. Use caution when working on a vehicle. When diagnosing, removing or replacing any components that are not operating properly, consider the safety of yourself and those around you should the component move unexpectedly.

Some components are heavy, spring loaded, highly corrosive, explosive, or can produce amperage or reach high temperatures. Carbon monoxide, battery acid and hydrogen gas could cause serious bodily injury to the technician/mechanic and bystanders if not treated with the utmost caution. Be careful not to place hands, face, feet, or body in a location that could expose them to injury should an unforeseen dangerous situation occur.

Always use the appropriate tools listed in the tool list and wear approved safety equipment.

Before a new vehicle is put into operation, the items shown in the INITIAL SERVICE CHART should be performed (Ref. Fig. 4).

GENERAL INFORMATION AND ROUTINE MAINTENANCE

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

INITIAL SERVICE CHART	
Item	Service Operation
Battery Charger	Remove from vehicle and read operating instructions.
Batteries	Charge. Batteries must be fully charged before initial use.
Seats	Remove protective plastic covering.
Brakes	Check operation; adjust if necessary.
	Check hydraulic fluid level; add if necessary.
Tires	Check air pressure; adjust if necessary. Refer to WHEELS AND TIRES section for inflation recommendations.
Vehicle Inspection	Visually inspect for leaks or damage that may have occurred during shipment from the factory.
	Inspect for loose hardware; tighten if necessary.

Fig. 4 Initial Service Chart

ROUTINE MAINTENANCE

This vehicle will give years of satisfactory service, provided it receives regular maintenance (See PERIODIC SERVICE SCHEDULE on page 131).

Verify appropriate lubrication locations (See Checking the Lubricant Level on page 83).

NOTICE: *To prolong vehicle life, some maintenance items must be serviced more frequently on vehicles used under severe driving conditions such as extreme temperatures, extreme dust/debris conditions, or frequent use with maximum load.*

POWERTRAIN MAINTENANCE

The powertrain is most easily accessed from the underside of the vehicle (See LIFTING THE VEHICLE on page 8). Remove the cowl for full access to the front powertrain (See Cowl Replacement on page 25). Remove the rear seat for full access to the rear powertrain (See Rear Seat Removal and Installation on page 73).

WARNING *Use insulated wrenches to prevent the possibility of a dropped wrench causing a short-circuit in a battery, which can cause an explosion and severe personal injury or death.*

To prevent accidental starting, disconnect the main negative battery cable before servicing.

BRAKES

This vehicle is equipped with four wheel hydraulic disc brakes. Check the fluid level at intervals specified (See PERIODIC SERVICE SCHEDULE on page 131). If fluid leaks are noticed or the brake pedal seems soft, check the fluid level immediately. If the brake pedal is soft, the brake system should be bled to remove air from the brake lines (See Bleeding on page 36).

The parking brake is an electric motor brake and is engaged any time that the vehicle comes to a complete stop. The parking brake is released when the vehicle is in F (forward) or R (reverse) and the accelerator pedal is pressed.

After the vehicle has been put into service, it is recommended that the brakes be checked periodically (See Daily Brake Performance Test on page 33).

WARNING *To prevent severe injury or death caused from driving a vehicle with an improperly operating brake system, the braking system must be properly maintained. All driving brake tests must be done in a safe location with regard for the safety of all personnel.*

TIRES

Tire condition should be inspected and inflation pressures checked periodically while tires are cool (See PERIODIC SERVICE SCHEDULE on page 131). Be sure to install the valve dust cap after checking or inflating tire.

VEHICLE CLEANING AND CARE

WARNING *Read and understand all instructions supplied by the manufacturer of the pressure washer before use.*

CAUTION *When pressure washing the exterior of the vehicle, do not use pressure in excess of 700 psi. Maintain a 12" minimum distance from spray nozzle to painted surface. To reduce the possibility of cosmetic damage, do not use any abrasive or reactive solvents to clean plastic parts.*

Proper techniques and cleaning materials must be used to prevent damage to the exterior of the vehicle. Using excessive water pressure can cause severe injury to operator or bystander. Excessive pressure can also cause damage to seals, plastics, seat material, body finish, or the electrical system. Do not use pressure in excess of 700 psi to wash exterior of vehicle.

Clean the windshield with water and clean cloth. Minor scratches can be removed using a commercial plastic polish or Plexus® plastic cleaner. Both are available from the service parts department.

Normal cleaning of vinyl seats and plastic or rubber trim requires the use of a mild soap solution applied with a sponge or soft brush followed by and wiping with a damp cloth.

Removal of oil, tar, asphalt, shoe polish, etc. will require the use of a commercially available vinyl/rubber cleaner.

GENERAL INFORMATION AND ROUTINE MAINTENANCE

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

The painted surfaces of the vehicle provide attractive appearance as well as durable protection. Frequent washing with lukewarm or cold water and mild detergent is required to preserve the painted surfaces.

Occasional cleaning and waxing with non-abrasive products designed for 'clear coat' automotive finishes will enhance the appearance and durability of the painted surfaces.

Corrosive materials used as fertilizers or dust control can collect on the underside of the vehicle. These materials will cause corrosion of components, unless flushed occasionally with plain water. Clean any areas where mud or other debris can collect. Loosen sediment packed in closed areas to ease its removal. Always use caution not to chip or otherwise damage paint.

VEHICLE CARE PRODUCTS

There are several products, available through a local distributor, an authorized Branch, or the Service Parts Department, to help maintain the vehicle. Among them are:

- Touch-up paint specially formulated to match vehicle colors for use on both metal and TPE (plastic) bodies. (P/N 28140G**, 28432G** and 75831G01)
- Multi-purpose battery protectant (P/N 27619G01) formulated to form a long-term, flexible, non-tacky, dry coating that will not crack, peel or flake over a wide temperature range.
- Use windshield and plastic protectant (P/N 606314) to remove minor scratches from windshield.

OPS, CANOPY TOP AND WINDSHIELD

WARNING *The Operator Protection System (OPS) and optional canopy top do not provide protection from roll over or falling objects.*

The optional windshield does not provide protection from tree limbs or flying objects.

Remove the optional windshield and store securely before transporting the vehicle on a trailer. The optional windshield is not designed to withstand highway speeds.

The vehicle is equipped with an OPS (Operator Protection System), and may be equipped with an optional canopy top, and/or an optional windshield.

The OPS and optional canopy top provide some protection from smaller falling objects, but will not protect against large falling objects such as trees or heavy limbs.

The optional windshield deflects oncoming wind from occupants, but will not protect against flying objects and tree limbs.

The optional canopy top and optional windshield provide some protection from the elements; however, they will not keep occupants dry in a downpour.

The optional canopy top and optional windshield are designed for weather protection only (See WEATHER PROTECTION on page 123).

TRANSPORTING VEHICLE

WARNING *To prevent personal injury to occupants of other highway vehicles, make sure the vehicle and contents are adequately secured to trailer.*

Do not ride on a vehicle being transported.

Remove the windshield before transporting the vehicle.

Maximum speed with canopy top installed is 50 mph (80 kph).

Do not tow the vehicle. It is not designed to be towed.

It is recommended that the vehicle be moved by placing the entire vehicle on a trailer, flat bed truck or other suitable transport.

If the vehicle is to be transported on a trailer at highway speeds, the windshield and canopy top must be removed (if equipped) and the seat bottoms secured. Always check that the vehicle and its contents are adequately secured before transporting the vehicle. The rated capacity of the trailer must be more than the weight of the vehicle and load (See VEHICLE SPECIFICATIONS on page 129). Engage the park brake and secure the vehicle to the trailer using ratchet tie downs.

EMERGENCY ELECTRIC PARK BRAKE RELEASE

If the park brake release switch does not deactivate the electric park brake, or if the vehicle experiences a power failure, you can release the park brake using the procedure below. This method is intended for emergency procedures only and should only be used if necessary.

NOTICE: *Leaving the key switch in the ON position while the park brake is released for long periods of time will result in a complete discharge of the battery pack.*

Tool List **Qty.**

Wheel Chocks.....4

1. Chock the wheels so that the vehicle cannot roll.
2. Turn the key switch to the OFF position and remove the key.
3. Remove the seat bottom.
4. Locate the connectors labeled 1,2,3, and 4. They are zip tied to the main wiring harness between the passenger side battery and the row of three batteries in the middle.
5. Disconnect both sets of connectors and connect 1 to 3 and 2 to 4.
6. Insert the key and turn the key switch to the N position. This will release the park brake.

GENERAL INFORMATION AND ROUTINE MAINTENANCE

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

- Carefully remove the wheel chocks in the direction that the vehicle needs to be moved.
- Turn the key switch to the OFF position after the car has been moved.
- Disconnect both sets of connectors and connect 1 to 2 and 3 to 4. This will return the vehicle to normal operation.




Fig. 5 Motor Brake Jumper

TOWING A TRAILER

The vehicle is equipped with a 2-inch receiver. The trailer and its load must not exceed 1000 lbs (454 kg) and no more than 100 lbs (46 kg) tongue weight can be attached to the hitch. The overall capacity of the vehicle, operator, passenger, and accessories must be reduced to compensate for the trailer and load.

The range of motion of the trailer is limited by the ball and hitch. The trailer should not be used on rough trails or over objects such as logs, large rocks, holes, etc.

Never install baskets or extensions using the hitch receivers. Such items will change the performance characteristics of vehicle and cause unsafe handling, possible roll over, or vehicle damage.

PROLONGED STORAGE

During periods of storage, the batteries must be maintained to prevent discharge.

During cold conditions, the batteries must be fully charged to prevent the possibility of freezing. A fully charged battery will not freeze in temperatures above -75° F (-60° C). Although the chemical reaction is slowed in cold temperatures, the battery must be stored fully charged, and disconnected from any circuit that could discharge the battery.

Clean the batteries and neutralize all deposits on the battery cases to prevent self discharge.

The battery charger can remain connected to the vehicle to maintain a full charge on the batteries provided the charger is connected to an active electrical source. If power to the electrical source is disconnected or interrupted, the battery charger will continue to check the charge on the battery pack. This will pull power from the battery pack and eventually drain the batteries if power is not restored in a timely manner.

HARDWARE

Periodically, inspect the vehicle for loose fasteners. Use care when tightening fasteners, refer to the following table for torque values (Ref. Fig. 6).

Three classes of standard hardware, and two classes of metric hardware are used in the vehicle.

Standard:

- Grade 2 hardware is unmarked.
- Grade 5 hardware can be identified by the three marks on the hex head.
- Grade 8 hardware is identified by six marks on the head.

The class specification is marked on metric hardware.

GENERAL INFORMATION AND ROUTINE MAINTENANCE

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

TORQUE SPECIFICATIONS

ALL TORQUE FIGURES ARE IN FT. LBS. (Nm)										
Unless otherwise noted in text, tighten all hardware in accordance with this chart.										
This chart specifies 'lubricated' torque figures. Fasteners that are plated or lubricated when installed are considered 'wet' and require approximately 80% of the torque required for 'dry' fasteners.										
BOLT SIZE	1/4"	5/16"	3/8"	7/16"	1/2"	9/16"	5/8"	3/4"	7/8"	1"
Grade 2 	4 (5)	8 (11)	15 (20)	24 (33)	35 (47)	55 (75)	75 (102)	130 (176)	125 (169)	190 (258)
Grade 5 	6 (8)	13 (18)	23 (31)	35 (47)	55 (75)	80 (108)	110 (149)	200 (271)	320 (434)	480 (651)
Grade 8 	6 (8)	18 (24)	35 (47)	55 (75)	80 (108)	110 (149)	170 (230)	280 (380)	460 (624)	680 (922)
BOLT SIZE	M4	M5	M6	M8	M10	M12	M14			
Class 5.8 (Grade 2) 	1 (2)	2 (3)	4 (6)	10 (14)	20 (27)	35 (47)	55 (76.4)			
Class 8.8 (Grade 5) 	2 (3)	4 (6)	7 (10)	18 (24)	35 (47)	61 (83)	97 (131)			
Class 10.9 (Grade 8) 	3 (4)	6 (8)	10 (14)	25 (34)	49 (66)	86 (117)	136 (184)			

Fig. 6 Torque Specifications

CAPACITIES AND REPLACEMENT PARTS

CAPACITIES	
Front Axle Oil	48 oz. 90 wt. Gear Oil
Rear Axle Oil	48 oz. 90 wt. Gear Oil
Brake Fluid	DOT 4


REPLACEMENT PARTS	
LED Headlight Bulb	P/N 619101
Headlight Bulb	P/N 619100
ATC Type Fuse 10 Amp	P/N 35212G07
ATC Type Fuse 15 Amp	P/N 35212G01
ATC Type Fuse 20 Amp	P/N 35212G02

Fig. 7 Capacities and Replacement Parts

GENERAL INFORMATION AND ROUTINE MAINTENANCE

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Notes:

A large grid of graph paper for taking notes, consisting of 20 columns and 30 rows of small squares.

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

SAFETY

NOTICES, CAUTIONS, WARNINGS AND DANGERS

Read the **NOTICES, CAUTIONS, WARNINGS** and **DANGERS** in this manual. The person who services a vehicle needs the mechanical skill and experience to see possible hazardous conditions. Incorrect service or repairs can cause damage to the vehicle or make the vehicle dangerous to operate.

NOTICE: A **NOTICE** indicates and describes information not related to personal injury.

CAUTION A **CAUTION** indicates a dangerous condition that can cause injury that is not life threatening.

WARNING A **WARNING** indicates a dangerous condition that can cause death or serious injury.

DANGER A **DANGER** indicates a dangerous condition that will cause death or serious injury.

IMPORTANT SAFETY WARNING

Normal use, age, wear or abuse can cause some components on the vehicle to fail.

The manufacturer can not know all possible component failures or the methods that failures can occur.

A vehicle in need of repair does not operate correctly and can be dangerous.

Use caution when working on a vehicle. When diagnosing, removing or replacing any components that are not operating properly, consider the safety of yourself and those around you should the component move unexpectedly.

Some components are heavy, spring loaded, corrosive, explosive, can cause high amperage, or get hot. Battery acid and hydrogen gas can cause injury. Do not put your hands, face, feet or body in a location that can expose them to injury if an unexpected situation occurs.

Always use the correct tools shown in the tool list and wear approved safety equipment.

MODIFICATIONS TO VEHICLE

Do not modify the vehicle in any manner that will change the weight distribution of the vehicle.

WARNING Changes to the weight distribution or the center of gravity decreases the stability of the vehicle and can cause it to easily roll over.

GENERAL MAINTENANCE

WARNING Always use correct service procedures. Never perform any service procedures before reading and understanding all notices, cautions, warnings, and dangers in this manual.

When any maintenance procedure or inspection is done, use caution to make sure the technician or any person in the area is safe. Use caution to prevent damage to the vehicle.

Always read and understand the full applicable manual section (chapter) before performing any inspection or service.

BEFORE SERVICING VEHICLE

Before attempting to inspect or service a vehicle, be sure to read and understand the following warnings:

WARNING To prevent personal injury or death, observe the following:

Remove all jewelry before working on the vehicle.

Do not allow loose clothing or hair to contact the moving parts.

Do not touch hot objects.

Before engaging or adjusting the powertrain, lift and support the vehicle on the jack stands.

Wear OSHA approved clothing and eye protection when working on anything that could expose the body or eyes to potential injury. In particular, use caution when working around batteries, using compressed air or solvents.

Always remove the key from key switch before you disconnect an active circuit.

When connecting the battery cables, pay particular attention to the polarity of the battery terminals. Do not confuse the positive and negative cables.

If repairs are to be made that will require welding or cutting, the batteries must be removed.

Open flame or sparks can cause an explosion. Keep all flammable materials away from the batteries.

Explosive hydrogen gas is created during the charge cycle of the batteries. Proper ventilation will remove gas from the buildings. The air must exchange every 12 minutes.

Make sure that the key switch is in the OFF position, and the key removed. Make sure all electrical accessories are disabled before starting service on the vehicle.

SAFETY

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.



The batteries must be removed before any service or repairs that can cause sparks.

Never disconnect an active circuit at a battery terminal.

The batteries are heavy. Use correct safety procedures to lift the batteries. Always lift the battery with a commercially available battery lifting device. Make sure that not to tilt the batteries during removal or installation. An electrolyte spill can cause burns and damage.

The electrolyte in a storage battery is an acid solution which can cause burns to the skin and eyes. Always use clean water to wash electrolyte from your body or eyes. Get medical assistance immediately.



When servicing the vehicle, always wear eye protection. Use caution when working around batteries, or using solvents or compressed air.

Any electrolyte spills should be neutralized with a solution of 1/4 cup (60 ml) sodium bicarbonate (baking soda) dissolved in 1-1/2 gallons (6 liters) of water and flushed with water (See Preparing Acid Neutralizing Solution on page 17).

Use insulated wrenches to prevent the possibility of a dropped wrench from 'shorting out' a battery, which could result in an explosion and severe personal injury or death.

Aerosol containers of battery terminal protectant must be used with extreme care. Insulate metal container to prevent can from contacting battery terminals, which could result in an explosion.

CAUTION Make sure to fill the batteries to a level of 1/2 inch (13 mm) above the plates. Electrolyte more than 1/2 inch (13 mm) above the plates can cause a spill from the battery during the charge cycle. A spill of electrolyte can cause damage to the vehicle and storage facility.

LIFTING THE VEHICLE

Tool List	Qty.
Floor Jack	1
Jack Stands	4
Wheel Chocks.....	4

WARNING To reduce the possibility of severe injury or death from a vehicle falling from a jack, always observe the following warnings:

Always place chocks in front and behind the wheels not being raised.

Be sure the vehicle is on a firm and level surface.

Never get under a vehicle while it is supported by a jack.

Use jack stands and test the stability of the vehicle on the stands.

Use extreme caution. The vehicle is very unstable during the lifting process.

CAUTION When lifting the vehicle, position jacks and jack stands only in the areas indicated (Ref. Fig. 1).

How to Lift the Vehicle

1. Put the wheel chocks in front of each front wheel and behind each front wheel (Ref. Fig. 2).
2. Put the jack below the rear axle-tube, next to the differential housing or below the skid plate (Ref. Fig. 1).
3. Lift the vehicle and put the jack stands below the frame where the leaf-spring bracket is attached to the frame (Ref. Fig. 1).
4. Lower the jack and test the stability of the vehicle on the two jack stands by gently rocking the vehicle.
5. Put the jack below the center of the front of the vehicle behind the bumper.
6. Lift the vehicle and put the jack stands below the frame where the instrument-panel support is attached to the frame.

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

7. Lower the jack and test the stability of the vehicle on all four jack stands by rocking the vehicle gently.




Fig. 1 Lifting the Vehicle




Fig. 2 Wheel Chocks

Lift Front of Vehicle

1. Put the wheel chocks in front of each rear wheel and behind each rear wheel (Ref. Fig. 2).
2. Place the jack under the center front of the vehicle just behind the bumper (Ref. Fig. 1).
3. Lift the vehicle with jack and position the jack stands under the frame where the instrument panel support is attached to the frame (Ref. Fig. 1).
4. Lower the jack and test the stability of the vehicle on jack stands by gently rocking the vehicle.
5. The jack can be left under the center front of the frame while the front end of the vehicle is on the jack stands.

Lift Rear of Vehicle

1. Put the wheel chocks in front of each front wheel and behind each front wheel (Ref. Fig. 2).
2. Center jack under rear axle tube next to the differential housing (Ref. Fig. 1).
3. Lift vehicle with jack and position jack stands under the frame where the leaf spring mounting bracket is welded to the frame (Ref. Fig. 1).
4. Lower the jack and test the stability of the vehicle on the two jack stands by gently rocking the vehicle.
5. The jack can be left under rear axle tube while the rear end of the vehicle is on the jack stands.


Lower Vehicle

Lower the vehicle by reversing the lifting sequence.

SAFETY

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Notes:

A large grid of graph paper for taking notes, consisting of 20 columns and 30 rows of small squares.

ACCELERATOR

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

ACCELERATOR




Fig. 1 Accelerator Components

ACCELERATOR PEDAL

The accelerator is a throttle by wire system with a rotary position sensor (See Rotary Position Sensor on page 45).

There are no serviceable items within the accelerator pedal assembly. The pedal assembly must be replaced as a unit if it does not operate correctly.

Pedal Replacement

Tool List

	Qty.
Socket, 7/16"	1
Socket, 13 mm	
Wrench, 7/16"	1
Wrench, 13 mm	
Ratchet.....	1
Torque Wrench, ft.lbs	1

- To access the accelerator pedal (1), remove two bolts (3), washers (4) and nuts (7) that secure the cover (5) to the mounting bracket (10).
- Disconnect the wire harness from the rotary position sensor on the pedal.


- Remove the lock nuts (8) securing the pedal (1) to the mounting bracket.(10).
- Remove the pedal.
- Replace the pedal (1) and secure with new lock nuts (8).
- Connect the wiring harness to the rotary position sensor.
- Install the pedal cover (5) and secure it with the bolts (3), washers (4) and nuts (7).
- Tighten the nuts (7, 8) to the torque values specified below.

Item	Torque Specification
7	6 - 8 ft. lbs. (8 - 11 Nm)
8	6 - 8 ft. lbs. (8 - 11 Nm)

ACCELERATOR

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Notes:

A large grid of graph paper for taking notes, consisting of 20 columns and 30 rows of small squares.

BATTERIES AND BATTERY CHARGER

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

BATTERIES AND BATTERY CHARGER

SAFETY

NOTICE: Always observe the following warnings when working on or near batteries.

⚠ WARNING To prevent battery explosion that could result in severe personal injury or death, keep all smoking materials, open flame or sparks away from the batteries.

Hydrogen gas is formed when charging batteries. Do not charge batteries without adequate ventilation. A 4% concentration of hydrogen gas is explosive.

Be sure that the key switch is off and all electrical accessories are disabled before starting work on vehicle.

Never disconnect an active circuit at a battery terminal.

SAFETY FIRST



BEND KNEES
WHEN
LIFTING

Batteries are heavy. Use proper lifting techniques when moving them. Always lift the battery with a commercially available battery lifting device. Use care not to tip batteries when removing or installing them; spilled electrolyte can cause burns and damage.

The electrolyte in a battery is an acid solution which can cause severe burns to the skin and eyes. Treat all electrolyte contact to the body and eyes with extended flushing with clear water. Contact a physician immediately.



Always wear a safety shield or approved safety goggles when adding water or charging batteries.

Any electrolyte spills should be neutralized with a solution of 1/4 cup (60 ml) sodium bicarbonate

(baking soda) dissolved in 1-1/2 gallons (6 liters) of water and then flushed with water (Ref. Fig. 7).

Overfilling batteries can result in electrolyte being expelled from the battery during the charge cycle. Expelled electrolyte can cause damage to the vehicle and storage facility.

Aerosol containers of battery terminal protectant must be used with extreme caution. Insulate metal container to prevent can from contacting battery terminals which could result in an explosion.

Use insulated wrenches to prevent the possibility of a dropped wrench from 'shorting out' a battery, which could result in an explosion and severe personal injury or death.

BATTERY

A battery is able to produce electricity as the result of a chemical reaction. This chemical reaction releases stored chemical energy in the form of electrical energy. The chemical reaction occurs faster in warm conditions and slower in cold conditions. Temperature is important when conducting tests on a battery, and test results must be corrected to compensate for temperature differences.

As a battery ages, it still may perform adequately, but its capacity is diminished. Capacity describes the time that a battery can continue to provide its design amperes from a full charge.

A battery has a maximum life, therefore good maintenance is designed to maximize the available life and reduce the factors that can reduce the life of the battery.

BATTERIES AND BATTERY CHARGER

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




Fig. 1 Battery System

Batteries Removal

Tool List

	Qty.
Insulated Wrench, 1/2"	1
Insulated Wrench, 9/16"	1
Insulated Socket, 1/2",	1
Insulated Socket, 9/16"	1
Ratchet	1
Battery Carrier	1
Torque Wrench, ft. lbs.....	1

Torque Wrench, in. lbs.	1
Putty Knife.....	1
Wire Brush	1
Terminal Spreader.....	1

NOTICE: Hardware that is removed must always be installed in its original position unless otherwise specified. If torque values are not specified, refer to the Torque Specifications table (See TORQUE SPECIFICATIONS on page 5).

BATTERIES AND BATTERY CHARGER

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

WARNING Use insulated wrenches to prevent the possibility of a dropped wrench from 'shorting out' a battery, which could result in an explosion and severe personal injury or death.

Make sure that the key switch is in the OFF position and remove the key from vehicle. Make sure all electrical accessories are deactivated.

1. Remove the negative (B-) cable.
2. Remove the positive (B+) cable.
3. Remove the nuts (6) and hold down bolts (4) from the battery hold downs (2) and battery bracket (1).
4. Remove the batteries (3) using a battery carrier (Ref. Fig. 1).
5. Remove all corrosion from terminals and hardware with a putty knife and wire brush.
6. Wash the area with a solution of sodium bicarbonate (baking soda) and water and thoroughly dry.
7. Apply corrosion resistant paint battery racks and surrounding area.

Battery Installation

1. Place the batteries (3) in the battery racks.
2. Install the battery hold downs (2) and battery bracket (1) with hold down bolts (4).
3. Tighten the lock nuts (6) to torque specified below, tight enough to prevent movement of the battery but not tight enough to cause distortion of the battery cases.
4. Inspect all wires and terminals.
5. Clean any corrosion from the battery terminals or the wire terminals with a solution of sodium bicarbonate (baking soda) and brush.
6. Connect the battery wires as shown (Ref. Fig. 2). Be sure that all battery terminals are installed with crimp upward.
7. Tighten the battery terminal hardware to torque specified below.

Item	Torque Specification
Lock Nut (6)	16 - 19 ft. lbs. (22 - 26 Nm)
Battery Terminal Hardware	90 - 110 in. lbs. (10 - 12 Nm)

CAUTION Do not overtighten the battery terminal clamps. This will cause a "mushroom" effect on the battery post, preventing the terminal nut from being properly tightened. Protect the battery terminals and battery wire terminals with a commercially available protective coating.

WARNING Aerosol containers of battery protector spray must be used with extreme care. Insulate metal container to prevent can from contacting battery terminals which could result in an explosion.

After installing batteries, coat terminals with commercially available terminal protector spray.




Fig. 2 Battery Connections

BATTERY MAINTENANCE

Tool List

	Qty.
Insulated Wrench, 9/16"	1
Battery Carrier	1
Hydrometer	1
Battery Maintenance Kit P/N 25587G01	1
Battery Protective Spray	1
Torque Wrench, in.lbs	1
Insulated Socket, 9/16"	1
Terminal Spreader	1
Ratchet	1

At Each Charging Cycle

Before charging the batteries, inspect the battery charger connector and vehicle receptacle housing for dirt or debris. Clean with compressed air if necessary.

Charge the batteries after each day of use.

BATTERIES AND BATTERY CHARGER

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Monthly

- Inspect all wiring for fraying, loose terminals, corrosion, and worn or missing insulation.
- Check that the electrolyte level is correct and add suitable water as required.
- Clean the batteries and wire terminals.
- Tighten battery terminal nuts to 90 - 110 in. lbs. (10.2 - 12.4 Nm).
- Spray battery terminals with commercially available battery protective spray.
- Install all terminal covers.

Temperature Affects Battery Capacity

Battery storage capacity is affected by the temperature. The colder the temperature, the less energy the battery is able to store. As temperature increases, so does the storage capacity of the battery (Ref. Fig. 3).

The ideal battery temperature for deep cycle batteries is 77°F (25°C). At 32°F (0°C), the storage capacity of the battery will be reduced by 20%, meaning the vehicle will not travel as far in cold weather as it will in warm weather.





Fig. 3 Temperature Effects

Electrolyte Level and Water

The correct level of the electrolyte is 1/2" (13 mm) above the plates in each cell (Ref. Fig. 4).

This level will leave approximately 1/4" - 3/8" (6 - 10 mm) of space between the electrolyte and the vent tube. The electrolyte level is important. Any portion of the plates that become exposed to air will be irreparably damaged. Too much water will force electrolyte out of the battery due to gassing and the increase in electrolyte volume that results from the charging cycle.



Electrolyte level should be at least 1/2" (13mm) above the plates and 1/4" to 3/8" (6 to 10 mm) below vent.

Fig. 4 Correct Electrolyte Level

WARNING Do not overfill batteries. The charging cycle will increase electrolyte volume and force it out of the battery and damage surrounding components.

A battery being charged will 'gas' with the majority of the gassing taking place at the end of the charging cycle. This gas is hydrogen, which is lighter than air. Water and sulfuric acid droplets will be carried out of the battery vents by the hydrogen gas; however, this loss is minimal. If the battery electrolyte level is too high, the electrolyte will block the vent tube and the gas will force the electrolyte out of the vent tube and battery cap. The water will evaporate but the sulfuric acid will remain where it can damage vehicle components and the storage facility floor. Sulfuric acid loss will weaken the concentration of acid within the electrolyte and reduce the life of the battery.

Over the life of the battery, a considerable amount of water is consumed. It is important that the water used be pure and free of contaminants that could reduce the life of the battery by reducing the chemical reaction. The water must be distilled or purified by an efficient filtration system. Water that is not distilled should be analyzed and if required, filtration installed to permit the water to meet the requirements of the water purity table (Ref. Fig. 5).

BATTERIES AND BATTERY CHARGER

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Impurity	Parts Per Million
Color.....	Clear
Suspended.....	Trace
Total Solids.....	100
Calcium & Magnesium Oxides.....	40
Iron.....	5
Ammonia.....	8
Organic & Volatile Matter.....	50
Nitrites.....	5
Nitrates.....	10
Chloride.....	5

Fig. 5 Water Purity Table

Even if the water is colorless, odorless, tasteless and suitable for drinking, it should be analyzed to see that it does not exceed the impurity levels specified in the water purity table (Fig. 5).

Automatic watering devices such as the one included in the Battery Maintenance Kit (P/N 25587G01) can be used with an approved water source (Ref. Fig. 6). These watering devices are fast and accurate to use, and maintain the correct electrolyte level within the battery cells.

Watering gun similar to the type included in the battery maintenance kit




Fig. 6 Automatic Watering Gun

NOTICE: The watering device should only be used if the electrolyte level is less than 1/2" (13 mm) above top of plates.

Cleaning Batteries

When cleaning the exterior of the batteries and terminals, do not use a water hose without first spraying with a solution of sodium bicarbonate (baking soda) and water to neutralize any acid deposits.

Use of a water hose without first neutralizing any acid, will transfer acid from the top of the batteries to another area of the vehicle or storage facility, where it will attack the structure or floor. After spraying down the batteries, a conductive residue will remain on the batteries which will contribute to the discharge of the batteries.

CAUTION To prevent battery damage, be sure that all battery caps are tightly installed.

The correct cleaning technique is to spray the top and sides of the batteries with a solution of sodium bicarbonate (baking soda) and water. This solution is best applied with a garden type sprayer with a non metallic spray wand. The solution should consist of 1/4 cup (60 ml) of sodium bicarbonate (baking soda) mixed with 1-1/2 gallons (6 liters) of clear water (Ref. Fig. 7). In addition to the batteries, spray all metal components adjacent to the batteries with the sodium bicarbonate (baking soda) solution.




Fig. 7 Preparing Acid Neutralizing Solution

Leave solution on batteries for minimum of three minutes. Use a soft bristle brush or cloth to clean the tops of the batteries to remove any residue that could cause the self discharge of the battery. Rinse the entire area with low pressure clear water. All items required for complete battery cleaning and watering are included in the Battery Maintenance Kit (P/N 25587G01).

Cleaning should be done once a month or more often under extreme conditions.

Prolonged Storage

Prior to prolonged storage, the battery charger, controller, and all other electronic devices must be disconnected. Otherwise, they will contribute to the premature discharge of batteries.

The batteries need to be maintained to prevent discharge during periods of storage.

In high temperatures the chemical reaction is faster, while low temperatures cause the chemical reaction to slow down. A vehicle that is stored at 90° F (32° C) will lose 0.002 of specific gravity each day. If a fully charged battery has a specific gravity of 1.275 and the battery is allowed to sit unused, it will become partially discharged. When it reaches 1.240 (usually less than 20 days), it should be recharged. If a battery is left in a discharged state, sulfating takes place on and within the plates. Sulfating will cause permanent damage to the battery. To prevent damage, the battery should be recharged. A hydrometer (P/N 50900G1) can be used to determine the specific gravity, and therefore the state of charge of a battery.

In cold conditions, the battery must be fully charged to prevent the possibility of freezing (Fig. 8). A fully charged battery will not freeze in temperatures above - 75° F (-60° C). Although the chemical reaction is slowed in cold temperatures, the battery must be stored fully charged and disconnected from any circuit that could discharge the battery.

BATTERIES AND BATTERY CHARGER

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Disconnect the charger connector from the vehicle receptacle.

Clean the batteries, neutralize and remove all deposits from the battery case to prevent self discharge. The batteries should be tested or recharged at thirty day minimum intervals.




Fig. 8 Freezing Point of Electrolyte

Battery Charging

The battery charger is designed to fully charge the battery set. Some automatic battery chargers contain an electronic module that can not activate if the batteries are severely deep cycled. Automatic chargers will determine the correct duration of charge to the battery set and will shut off when the battery set is fully charged. Always refer to the instructions of the specific charger used.

Before charging, the following should be observed:

CAUTION Do not overfill batteries. The charging cycle will increase electrolyte volume and force it out of the battery and damage surrounding components.

- The electrolyte level in all cells must be at the recommended level and the plates covered (See Electrolyte Level and Water on page 16).
- Charging must be done in an area that is well ventilated and capable of removing the hydrogen gas that is generated by the charging process. A minimum of five air exchanges per hour is recommended.
- The charging connector components must be in good condition and free from dirt or debris.

- The charger connector must be fully inserted into the vehicle receptacle.
- The charger connector and cord set must be protected from damage and located in an area to prevent injury resulting from personnel running over or tripping over the cord set.
- The charger is automatically turned off during the connect/disconnect cycle, and therefore no electrical arc is generated at the DC plug/receptacle contacts.

NOTICE: In some portable chargers, an audible rattle is present in the body of the charger DC plug. This rattle is caused by an internal magnet within the charger plug. The magnet is part of the interlock system that prevents the vehicle from being driven when the charger plug is inserted in the charging receptacle.

AC Voltage

Battery charger output is directly related to the input voltage. If the vehicle routinely receives an incomplete charge in a normally adequate time period, low AC voltage could be the problem. Consult the electrical provider.

FAULT TESTING

Fault testing is done for two distinct reasons:

- A battery that performs poorly and is outside of the manufacturer's specification should be identified in order to replace it under the terms of the manufacturer's warranty. Different manufacturers have different requirements. Consult the battery manufacturer or the manufacturer's representative for specific requirements.
- Determine why a particular vehicle does not perform adequately. Performance problems can cause a vehicle to operate slowly or be incapable of operating for the time required.

A new battery must **mature** before it will develop its maximum capacity. Maturing can take up to 100 charge/discharge cycles. After the maturing phase, as the battery ages, its capacity diminishes. The only way to determine the capacity of a battery is to perform a load test using a discharge machine following manufacturer's recommendations.

A cost effective way to identify a poorly performing battery is to use a hydrometer to identify a battery in a set with a lower than normal specific gravity. Once the problematic cell or cells are identified, the suspect battery can be removed and replaced. At this point there is nothing that can be done to save the battery. The individual battery should be replaced with a good battery of the same brand, type, and approximate age.

BATTERIES AND BATTERY CHARGER

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Hydrometer

A hydrometer (P/N 50900G1) is used to test the state of charge of a battery cell (Ref. Fig. 9). This is performed by measuring the density of the electrolyte, which is accomplished by measuring the specific gravity of the electrolyte. The greater the concentration of sulfuric acid, the more dense the electrolyte becomes. The higher the density, the higher the state of charge.

WARNING To prevent a battery explosion that could result in severe personal injury or death. Never insert a metal thermometer into a battery. Use a hydrometer with a built in thermometer that is designed for testing batteries.




Fig. 9 Hydrometer

Specific gravity is the measurement of a liquid that is compared to a baseline. The baseline is water which is assigned a base number of 1.000. The concentration of sulfuric acid to water in a new vehicle battery is 1.280 which means that the electrolyte weighs 1.280 times the weight of the same volume of water. A fully charged battery will test at 1.275 - 1.280. A discharged battery will read in the 1.140 range.

NOTICE: Do not perform a hydrometer test on a battery that has just been filled. The battery must go through at least one charge and discharge cycle in order to allow the water to adequately mix with the electrolyte.

The temperature of the electrolyte is important. The hydrometer reading must be corrected to 80° F (27° C). High quality hydrometers are equipped with an internal thermometer that will measure the temperature of the electrolyte and will include a conversion scale to correct the float reading. It is important to recognize that the electrolyte temperature is significantly different from the ambient temperature if the vehicle has been operated.

WARNING The electrolyte in a battery is an acid solution which can cause severe burns to the skin and eyes. Treat all electrolyte contact to the body and eyes with extended flushing with clear water. Contact a physician immediately.



Always wear a safety shield or approved safety goggles when using a hydrometer to test the electrolyte solution.

Any electrolyte spills should be neutralized with a solution of 1/4 cup (60 ml) sodium bicarbonate (baking soda) dissolved in 1-1/2 gallons (6 liters) of water and then flushed with water (Ref. Fig. 7).

Using Hydrometer

1. Draw electrolyte into the hydrometer several times to permit the thermometer to adjust to the electrolyte temperature and note the reading. Examine the color of the electrolyte. A brown or gray color indicates a problem with the battery and indicates the battery is nearing the end of its life.
2. Draw the minimum quantity of electrolyte into the hydrometer to permit the float to float freely without contacting the top or bottom of the cylinder.
3. Hold the hydrometer in a vertical position at eye level and note the reading where the electrolyte meets the scale on the float.
4. Add or subtract four points (.004) to the reading for every 10° F (6° C) the electrolyte temperature is above or below 80° F (27° C). Adjust the reading to conform with the electrolyte temperature, e.g., if the reading indicates a specific gravity of 1.250 and the electrolyte temperature is 90° F (32° C), add four points (.004) to the 1.250 which gives a corrected reading of 1.254. Similarly if the temperature was 70° F (21° C), subtract four points (.004) from the 1.250 to give a corrected reading of 1.246 (Ref. Fig. 10).
5. Test each cell and note the readings (corrected to 80° F or 27° C). A variation of fifty points between any two cell readings (example 1.250 - 1.200) indicates a problem with the low reading cell(s). As a battery ages the specific gravity of the electrolyte will decrease at full charge. This is not a reason to replace the battery, providing all cells are within fifty points of each other.

Since the hydrometer test is in response to a vehicle showing a performance problem, the vehicle should be recharged and the test repeated. If the results indicate a weak cell, the battery or batteries should be removed and replaced with a good battery of the same brand, type and approximate age.

BATTERIES AND BATTERY CHARGER

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




Fig. 10 Hydrometer Temperature Correction

BATTERY CHARGER

Charger Description

The battery charger supplied with the vehicle is a Delta-Q Technologies QuiQ 72V charger. It is a fully automatic battery charger and is designed specifically for charging electric vehicle batteries. Use the charger on 72V battery systems only.

Instructions are printed on the charger for daily reference. A manual provided by the charger manufacturer is shipped with the charger.

For information regarding the battery charger, including charging instructions, LED display explanations, fault testing, and ordering replacement parts, refer to the charger manual or contact the manufacturer directly (See BATTERY CHARGER USER'S GUIDE on page 133).

Portable Charger Installation

WARNING Use charger only on 72 volt battery systems. Other usage can cause personal injury and damage.

Lead acid batteries can generate explosive hydrogen gas during normal operation. Keep sparks, flames, and smoking materials away from batteries. Provide adequate ventilation during charging.

Never charge a frozen battery.

Study all of the battery manufacturer's specific precautions such as recommended rates of charge and removing or not removing cell caps while charging.

DANGER Risk of electric shock. Connect charger power cord to an outlet that has been properly installed and grounded in accordance with all local codes and ordinances. A grounded outlet is required to reduce risk of electric shock – do not use ground adapters or modify the plug. Do not touch uninsulated portion of output connector or uninsulated battery terminal. Disconnect the DC supply before making or breaking the connections to the battery while charging.

Do not open or disassemble the charger.

Do not operate the charger if the AC supply cord is damaged or if the charger has received a sharp blow, been dropped, or otherwise damaged in any way. Refer all repair work to qualified personnel.

The charger is not for use by children.

Portable chargers are shipped with the vehicle. Prior to vehicle or charger operation, chargers must be removed and mounted on a platform above the ground to permit maximum air flow around and underneath the charger. For optimum performance and shortest charge times, put the charger in an area with adequate ventilation. The charger should also be installed in an area that will be relatively free of dirt, mud, or dust. Accumulations within the charger vents will reduce their heat dissipating qualities. The status display of the charger must be visible to the user.

BATTERIES AND BATTERY CHARGER

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Provide Protection From Elements



Locations outside the US and Canada:
Reference appropriate local electrical code and charger manufacturer recommendations for AC power requirements.

Fig. 11 Charger Installation

The charger can remain connected to the AC outlet. To charge the vehicle, refer to the instruction labels on the charger. Insert the polarized DC plug completely into the vehicle receptacle. The charger will automatically start a few seconds after the plug is connected. The charger will automatically stop when the batteries are fully charged, and the DC plug can be removed from the vehicle.


NOTICE: *Routing the DC cord through the steering wheel when charging the batteries, serves as a good reminder to store the cord out of the way when charging is complete. The DC plug can be damaged by driving over or catching the cord on the vehicle when driving away.*

⚠ WARNING *An ungrounded electrical device can become a physical hazard that could result in an electrical shock or electrocution.*

BATTERIES AND BATTERY CHARGER

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Notes:

A large grid of graph paper for taking notes, consisting of 20 columns and 30 rows of small squares.

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

BODY

GENERAL

NOTICE: Hardware that is removed must always be installed in its original position unless otherwise specified. If torque values are not specified, refer to the Torque Specifications (See TORQUE SPECIFICATIONS on page 5).

⚠ DANGER To prevent possible injury or death from battery explosion, batteries should always be removed before any service is performed that may generate sparks.

⚠ WARNING It is important to use a sharp drill bit when removing the rivets on the side of the vehicle. Extreme care must be used when drilling out the rivets located in the front of the body and the bottom side of the body. Excessive pressure could result in the drill bit being forced through the body panel and penetrating a component behind it. It is recommended that extra protection be provided by using a protective piece of sheet metal placed between the battery and the rivet. Use of a drill depth stop will provide additional protection.

Body components can be replaced with a minimum of special tools. Most body components are held in position with standard removable hardware (nuts, bolts, washers and screws). Some components are installed with pop rivets that require the rivet head be removed to push the shank of the rivet out. The rivet head can be removed by drilling into the head with a sharp drill bit that is slightly larger than the shank of the rivet (Ref. Fig. 1). Do not allow the drill bit to push through and damage components behind the rivet. Use a sharp drill bit that needs minimum pressure to correctly cut, and put a piece of protective sheet metal between the panel and components behind the panel.

BODY COMPONENT REPLACEMENT

NOTICE: Most mechanical and electrical components are accessible without removing body panels from the vehicle.

To replace the body components, remove the mounting hardware, replace the component and secure with hardware in the original position.

The following illustrations indicate the rivet removal methods for the different components. (Ref. Fig. 1) (Ref. Fig. 2) (Ref. Fig. 3)




Fig. 1 Drill Out Metal Rivet




Fig. 2 Drive Rivet Removal




Fig. 3 Remove Ratchet Fasteners

BODY

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Rocker Panel Replacement

Tool List	Qty.
Torx Bit, T30	1
Bit Driver.....	1
Torque Wrench, in. lbs.....	1

1. Remove the upper OPS from the vehicle (See Upper OPS Frame Removal and Installation on page 78).
2. Remove the lower OPS from the vehicle (See OPS Lower Weldment Removal and Installation on page 80).
3. Remove the screws (2) securing the rocker panels (1) to the chassis frame (3) (Ref. Fig. 4).
4. Remove rocker panels (1).




Fig. 4 Rocker Panel Replacement

Assemble in the reverse order of removal. Tighten the screws (2) to the torque values below.

Item	Torque Specification
2	25 - 40 in. lbs. (2.8 - 4.5 Nm)

Gauge Panel Replacement

Tool List	Qty.
Pry Bar, Small	1
Bit Driver	1
Torx Bit, T30.....	1

NOTICE: The gauge panel can be removed without removing the instrument panel.

WARNING To prevent personal injury, disconnect negative (-) battery cables before servicing vehicle.

Removal:

1. Remove two screws (6) that secure the gauge panel (5) to instrument panel (10).
2. Gently pry out the top of the gauge panel (5).
3. Remove the connections from the main harness to the electrical accessories in the gauge panel.
4. Pull the bottom of the gauge panel away from and out of the instrument panel (10) (Ref. Fig. 5).

Assembly:

1. Connect the main harness to all electrical accessories in the gauge panel.
2. Push the body clips (4) through the instrument panel. If the body clips (4) remained in the instrument panel (10) during the gauge panel (5) removal, push the tabs (7) into the body clips (4).
3. Install the two screws (6).




Fig. 5 Gauge Panel Replacement

Torque the screws (6) to the torque values below.

Item	Torque Specification
6	25 - 40 in. lbs. (2.8 - 4.5 Nm)

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Cowl Replacement

Tool List	Qty.
Drill	1
Drill Bit	1
Punch, Small	1
Rivet Gun	1
Pry Bar	1

⚠ WARNING To prevent personal injury, disconnect negative (-) battery cable before servicing vehicle.

1. Disconnect the wiring harness from the headlights (See Headlight Bulb Replacement (Standard) on page 46).
2. Remove the gauge panel (5) (See Gauge Panel Replacement on page 24).
3. Drill out the upper rivets (12) connecting the cowl (15) to the instrument panel (10).
4. Drill out the remaining rivets (11).
5. Remove cowl assembly (15) from vehicle (Ref. Fig. 6).

Assemble in the reverse order of removal using new rivets.




Fig. 6 Cowl Removal

Removal of Headlight Grille Assembly

Tool List	Qty. 1
Socket, 10mm	1
Wrench, 10mm	1
Ratchet	1
Pry Bar	1
Torque Wrench, in. lbs.....	1

1. Disconnect the wire harness (16) from the headlight bulb (17).

2. Remove the eleven nuts (18) from the rear of the headlight grille assembly (20), that secure the headlight grille assembly to the cowl (15).
3. Remove the headlight grille assembly (20) from the outside of the cowl (15). It may be necessary to pry the headlight grille assembly gently away from the cowl (Ref. Fig. 7).

Assemble in the reverse order of removal.

Tighten the nuts (18) to the torque values listed below.

Item	Torque Specification
18	17 - 25 in. lbs. (1.9 - 2.8 Nm)

BODY

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




Fig. 7 Headlight Grille Assembly

Instrument Panel Replacement

Tool List

	Qty.
Torx Bit, T30	1
Wrench, 10mm	1
Socket, 10mm.....	1
Ratchet	1
Bit Driver.....	1
Drill	1
Drill Bit	1
Pry Bar.....	1
Punch, Small	1
Rivet Gun.....	1

⚠ WARNING To prevent personal injury, disconnect negative (-) battery cables before servicing vehicle.

DO NOT reuse rivets.

1. Remove the upper OPS (See Upper OPS Frame Removal and Installation on page 78).
2. Remove Lower OPS weldment (See OPS Lower Weldment Removal and Installation on page 80).
3. Remove the rocker panels (See Rocker Panel Replacement on page 24).
4. Remove the cowl (See Cowl Replacement on page 25).

5. Remove the gauge panel (See Gauge Panel Replacement on page 24).
6. Remove the self threading nuts (25) that attach the instrument panel to the support (24).
7. Remove the two bolts (21) that attach the instrument panel (10) to the support (24) (Ref. Fig. 8).
8. Fold down the floor mat to access the rivets (11, 12)
9. Drill out the rivets (26, 27) securing the instrument panel to the floorboard (Ref. Fig. 9).
10. Pull the instrument panel from the vehicle.

Assemble in the reverse order of removal using new rivets.

Tighten all hardware to the torque values below.

Item	Torque Specification
21	25 - 40 in. lbs. (2.8 - 4.5 Nm)
25	12 - 18 in. lbs. (1.3 - 2 Nm)

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




Fig. 8 Instrument Panel (Rear)

BODY

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




Fig. 9 Instrument Panel (Front)

Rear Fender Replacement

Tool List

	Qty.
Drill	1
Drill Bit	1
Socket, 7/16"	1
Ratchet	1
Wrench, 7/16"	1
Rivet Gun.....	1
Torque Wrench, ft. lbs.	1
Pry Bar.....	1

To replace either driver or passenger side panel

1. Disconnect the tail light leads from the main wiring harness.
2. Drill out the two rivets (36) securing the side panel (35) to the rear fender (30).
3. Remove the two nuts (39) and bolts (38) securing the rear of the rear fender (30).
4. Pry out the four ratchet rivets (37) securing the rear fender to the frame (Ref. Fig. 10).

Assemble in the reverse order of removal using new rivets.

Tighten the nuts (39) to torque value specified below.

Item	Torque Specification
39	9 - 11 ft. lbs. (12 - 15 Nm)

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




Fig. 10 Fender Replacement

Seat Wrap and Closeout Replacement

Tool List	Qty.
Drill	1
Drill Bit	1
Rivet Gun	1
Screwdriver, Phillips	1

1. Drill out the rivets (49) securing the seat wrap (40, 45) to the floor (41) and frame (Ref. Fig. 11). Retain the hinge plates (47) for reuse during installation.
2. Remove the 6 screws (42) connecting the front of the seat wrap (40) to the sides (45).
3. Pull the front portion (40) of the seat wrap out of the vehicle.
4. Remove the screws (46) connecting the seat wrap to the frame from the inside of the side portions of the seat wrap.
5. Pull the side portions (45) of the seat wrap out of the vehicle.
6. If a closeout (48) needs to be replaced, remove the two screws (44) attaching the closeout to the seat wrap sides (Ref. Fig. 12).

Assemble in the reverse order of removal using new rivets.




Fig. 11 Seat Wrap Replacement

BODY

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




Fig. 12 Seat Wrap Closeout




Fig. 13 Closeout Panel

Rear Closeout Panel Replacement

Tool List

	Qty.
Ratchet	1
Wrench, 7/16"	1
Wrench, 9/16"	1
Torque Wrench, ft. lbs.	1
Socket, 7/16"	1
Socket, 9/16"	1
Torque Wench, ft. lbs.	1

1. Remove the bolts (53), lock washers (52), washers (54) and nuts (51) securing rear closeout panel (50) to chassis frame (Ref. Fig. 13).
2. Remove the rear closeout panel (50).

Assemble in the reverse order of removal. Tighten the bolts (53) to torque value specified below.

Item	Torque Specification
53	21 - 25 ft. lbs. (28 - 34 Nm)

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

PAINTING

Follow the paint manufacturer's recommendations for specific painting procedures and information.

⚠ WARNING *All painting must be done in an area with adequate ventilation to safely disperse harmful vapors.*

Wear eye protection and respirator, following manufacturer's instructions to protect from over spray and airborne mist.

⚠ CAUTION *Provide protection from over spray to vehicle and surrounding area.*

Minor Scratches

To repair minor scratches, the manufacturer of the Durashield™ body panels recommends the following steps be taken:

1. Thoroughly clean the surface to be repaired with alcohol, and allow to dry.
2. Use a brush to apply a minimum of two coats of touch up paint to damaged area. Allow 30 - 45 minutes between coats; increase to 45 - 60 minutes in higher humidity. The painted area should be slightly above the surface of the part.
3. Use 400 grit "wet" sand paper to blend the painted area level with the surface of the part being repaired.
4. Use a polishing compound (3M Finesse or automotive grade) to renew the gloss and to further blend and transition the newly painted surface.
5. Clean with alcohol, and allow to dry.
6. (Optional but recommended) Apply a clear coat to renew and protect the depth of the finish.
7. Wax or polish with a Carnauba base product available at any automotive parts distributor. Do not wax flat finishes.

Larger Scratches

To repair large scratches, the manufacturer of the Durashield™ body panels recommends the following steps be taken:

1. Thoroughly clean the surface to be repaired with alcohol, and allow to dry.
2. Apply tape to area surrounding damaged area to prevent over spray of paint.
3. Shake the aerosol touch up paint a minimum of one minute to mix thoroughly and achieve the best color match.
4. Apply paint in light even overlapping strokes. Multiple coats can be applied to provide adequate coverage and finish.
5. Allow paint to dry overnight.
6. Use 400 grit "wet" sand paper to blend the painted area level with the surface of the part being repaired.

7. Use a polishing compound (3M Finesse or automotive grade) to renew the gloss and to further blend and transition the newly painted surface.
8. Clean with alcohol, and allow to dry.
9. (Optional but recommended) Apply a clear coat to renew and protect the depth of finish.
10. Wax or polish with a Carnauba base product available at any automotive parts distributor. Do not wax flat finishes.

Complete Panel Repair

In situations where large panels or areas must be painted, touch up paint is not recommended. In such cases, professional painting or panel replacement is necessary. Body panel replacement is sometimes more cost effective than painting. If the decision to paint is chosen, it can be accomplished by any body panel repair shop with experience in painting thermoplastic elastomer (TPE) panels. TPE is a common material in modern automobile body panels. All body panel repair shops should be familiar with the materials and processes required.


The finish will include an application of a primer coat, a base color coat, and a clear coat.

Most paint manufacturers can perform a computer paint match to assure accurate color matching.

BODY

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Notes:

A large grid of graph paper for taking notes, consisting of 20 columns and 30 rows of small squares.

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




Fig. 1 Hydraulic Brake Line

MAINTENANCE

Daily Brake Performance Test

NOTICE: To ensure correct braking performance, all periodic maintenance, inspections, and procedures must be performed as indicated in the Periodic Service Schedule (See PERIODIC SERVICE SCHEDULE on page 131). A Daily Brake Performance Test must be performed and the entire brake system serviced in accordance with the Periodic Service Schedule (See Daily Brake Performance Test on page 33).

The brake system must be bled whenever any part of the brake system has been replaced.

Press the brake pedal. The pedal should have some initial free play and then become resistant. This indicates proper performance.

If the brake pedal has a soft feel or loses resistance, per-

form a brake system inspection, (See Brake System Inspection on page 33)

Brake System Inspection

Brake failure usually occurs as either a gradual decrease in braking effect from the disc pads wearing away, a loss of braking at one wheel, or a sudden and complete failure with no brakes working except the electric parking brake. If the brakes at one wheel become ineffective while the brakes at the other wheel functions properly, remove the entire brake assembly and inspect the brake for signs of a leaking or inoperative wheel cylinder assembly.

NOTICE: Do not allow brake fluid to contact the brake pads. If the brake pads become wet with hydraulic fluid, wipe the brake pads and rotor until they are dry.

BRAKES

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Complete brake failure usually indicates a loss of hydraulic fluid pressure.

If the brake pedal has a soft feel:

1. Bleed the brakes to remove air from the brake system. (See BLEEDING AND FLUSHING on page 36)

A brake pedal that loses resistance indicates a leak in the hydraulic system:

1. Check brake fluid level.
2. If the fluid is low, inspect the system for leaks.
 - i. Check for leaks by applying pressure to the pedal gradually and steadily.
 - ii. If pedal sinks very slowly to the floor, the system has a leak along the brake lines or at the hydraulic cylinder. If no external leaks are apparent, the problem is likely inside the master cylinder
3. If leaks are found, repair the leaks in the brake system.
4. If the master cylinder is found to be leaking, replace it.
5. Bleed the brakes to remove air from the brake system.

CAUTION Do not allow brake fluid to contact painted surfaces. Wipe off immediately if contact is made.

MASTER CYLINDER

The master cylinder is mounted to the frame, behind the driver side front wheel (Ref. Fig. 1). The master cylinder will eventually require replacement due to deterioration of the cylinder seals (cups). Fluid will leak past the cups and show as an external leak. A common symptom is a soft brake pedal, meaning that it goes all the way to the floor. The rubber parts wear or deteriorate with use, age, or fluid contamination. Corrosion or deposits formed in the cylinder bore that are due to moisture or dirt in the hydraulic system may cause wear of the cylinder bore or related parts. Do not try to remove corrosion or deposits with a cylinder hone. If corrosion or deposits are detected on the master cylinder, replace it with a new one and flush the system (See Flushing on page 37).

Master Cylinder Replacement

Tool List	Qty.
Insulated Wrench, 9/16"	1
Container	1
Needle Nose Pliers	1
Wrench, 9/16"	2
Wrench, 1/2"	1
Wrench, 14mm	1
Socket, 9/16"	1
Socket, 1/2"	1
Socket, 14mm.....	1
Torque Wrench, ft. lbs.....	1

WARNING DO NOT reuse crush washers.

CAUTION When replacing the master cylinder, it is likely that brake fluid will leak from the master cylinder. Do not allow brake fluid to contact the painted body components of the vehicle. Clean off immediately if contact is made.

1. Switch the key switch into the OFF position, and remove the key.
2. Clean the area around the master cylinder (1) to prevent dirt and grease from contaminating the hydraulic system (Ref. Fig. 2).
3. Remove the banjo bolts (9) and washers (10).
4. Disconnect the front brake line (7) and the rear brake line (11) from the master cylinder (1) (Ref. Fig. 2). Provide a container for the released brake fluid.
5. Remove the cotter pin (3) and clevis pin (4).
6. Remove two hex head bolts (2) and nuts (5).
7. Remove the master cylinder from the vehicle.

Assemble in the reverse order of removal using new crush washers. Tighten all hardware to the torque values below.

Item	Torque Specification
9	20 - 24 ft. lbs. (27 - 32 Nm)
5	13 - 17 ft. lbs. (18 - 23 Nm)




Fig. 2 Master Cylinder

WARNING To prevent contaminated brake fluid causing a brake failure, never use any excess fluid or return to the original container. Dispose of brake fluid properly.

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Fill the master cylinder with DOT 4 brake fluid and bleed the brake system. (See BLEEDING AND FLUSHING on page 36)

After bleeding the brake system, check for leaks along all lines and at the master cylinder.

Brake Fluid

NOTICE: Hydraulic brake systems must be completely flushed if the fluid becomes contaminated. To flush, bleed the entire system until all brake fluid has been replaced with new DOT 4 standard automotive brake fluid.

Keep the fluid in the master cylinder (1) at the correct fluid level. The master cylinder is mounted to the frame behind the driver side front wheel (Ref. Fig. 1). To prevent contamination when checking fluid, clean the fill cap before removing it. Check reservoir fluid level as indicated in the Periodic Service Schedule (See PERIODIC SERVICE SCHEDULE on page 131). When required, add clean brake fluid to maintain fluid level 1/4" (6 mm) from top of reservoir. Use new DOT 4 standard automotive brake fluid.

Total brake fluid capacity for the complete hydraulic brake system is 13 fl. oz.

REPLACEMENT OF WEAR ITEMS

Brake Pads Replacement

Tool List

	Qty.
Allen Socket, 3/8"	1
Ratchet	1
Channel Lock Pliers	1
Torque Wrench, ft. lbs.	1
Torque Wrench, in. lbs.....	1
Socket, 1/2"	1
Socket, 13mm	1
Wrench, 1/2"	1
Wrench, 13mm	1

NOTICE: The front and rear brake pads must be replaced as a full set.

Replace the brake pads as a full set on both wheels. To remove the brake pads, lift and support the vehicle (See LIFTING THE VEHICLE on page 8).

1. Remove the wheel (See WHEEL AND TIRE SERVICE on page 126).
2. Remove the banjo bolts and crush washers securing the brake lines to the caliper.
3. Loosen the 2 socket head slider pins (15), but do not remove them.
4. Remove the two hex head screws (14) securing the caliper (13) to the mounting bracket (18) (Ref. Fig. 3).




Fig. 3 Brake Caliper




Fig. 4 Rear Brake Caliper (passenger side shown)

5. Swing the caliper (13) free from the rotor.
6. Remove both anti-rattle springs (17).
7. Use channel lock pliers to compress the side with the O-ring.
8. Remove the brake pads (16) one at a time.
9. Compress the caliper piston. When the piston is compressed, it will stay in position until the brake pedal is pressed.
10. Compress the side with the O-ring and hold while installing the new pads (16). When both pads are installed, release pressure on the side with the O-ring.
11. Separate the brake pads (16) and put the caliper (13) over the rotor.
12. Install the two socket head slider pins (15) finger tight.

BRAKES

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

13. Install the two hex head bolts (14) to attach the caliper (13) to the mounting bracket (18).
14. Reconnect the brake line using new crush washers.
15. Tighten all hardware to torque values below.

Item	Torque Specification
14	205 - 215 in. lbs. (23 - 25 Nm)
15	25 - 35 ft. lbs. (34 - 47 Nm)
Brake Line Banjo Bolt	17 - 20 ft. lbs (23 - 27 Nm)

16. Replace the wheel and tighten the lug nuts (See Wheel Installation on page 126).
17. Bleed the brake system. (See BLEEDING AND FLUSHING on page 36)

Rotor Replacement

NOTICE: Do not turn the rotor (disc brake hub) to remove grooves or high spots.

If the rotor (disc hub) has deep grooves or gouges, it must be replaced. If the pad contact area has worn the rotor to a thickness of 0.120" or less, the rotor must be replaced.

1. Remove the brake calipers (See Brake Pads Replacement on page 35).
2. Remove the wheel spacer (30).
3. Remove the cotter pin (31) and castellated nut (32).
4. Pull the hub assembly (2) away from the axle (35).
5. Remove the four bolts (37) securing the rotor (45) to the hub assembly (2) (Ref. Fig. 5).

Assemble in the reverse order of removal. Tighten all hardware in a cross pattern to the torque values below.

Item	Torque Specification
32	205 - 215 in. lbs. (23 - 25 Nm)
37	28 - 32 ft. lbs. (38 - 43 Nm)




Fig. 5 Rotor

BLEEDING AND FLUSHING

Tool List

	Qty.
Shop Towels.....	A/R
Hose.....	A/R
Clean Container, Glass.....	1
Brake Fluid, DOT 4.....	A/R
Wrench, 1/4" Box End.....	1
Crowfoot Wrench, 1/4".....	1
Torque Wrench, in. lbs.	1
Socket, 1/4".....	1

Bleeding

The brake hydraulic system must be free of air to function properly.

The brake pedal and master cylinder acts as a hydraulic pump to remove air and brake fluid from the system.

Bleed the hydraulic system at all wheels if:

- The primary brake line was disconnected from the flexible brake hose.
- Air was introduced into the system due to low fluid level in master cylinder reservoir.

If a line or hose was disconnected at any fitting located between the master cylinder and calipers, all wheel calipers served by the disconnected line or hose must be bled.

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Bleeding Sequence

Bleed at each caliper in succession beginning with the passenger side rear wheel, which is farthest from the master cylinder. After the rear passenger caliper, move to the driver side rear wheel, then to the passenger side front wheel, and finish with the driver side front wheel.

WARNING Never use any excess fluid or return it to the original container. Discard brake fluid properly.

NOTICE: An assistant is necessary to perform this procedure.

Use a clean cloth to clean the master cylinder reservoir and caliper bleeder valves (Ref. Fig. 6). Clean each fitting before opening to prevent contamination of the system.




Fig. 6 Bleeder Valve

Fill the master cylinder reservoir to within 1/4" (6 mm) of the top with new DOT 4 brake fluid before starting, and after bleeding is complete.

Check the master cylinder fluid level frequently during bleeding and keep the reservoirs at least half full.

The following steps apply to one bleeder screw. Repeat at both bleeder points.

1. Attach a bleeder hose to the bleeder screw. Put the other end of the hose in a glass container partially filled with brake fluid (Ref. Fig. 6).

NOTICE: Be sure that the free end of the hose is submerged in brake fluid. This shows air bubbles as they come out of the system, and prevents air from being sucked into the system through the bleeder screw.

2. Apply moderate (40 - 50 lbs. [18 - 23 kg]), steady pressure on the brake pedal and open the bleeder screw.

CAUTION Do not force the brake pedal to the floor. The operating rod jam nut can be forced into the master cylinder where it can damage internal components.

3. If the brake pedal goes to the floorboard without removing all of the air bubbles, close the bleeder screw and release the brake pedal slowly. Repeat steps 1 and 2.

NOTICE: The bleeder valve at the wheel cylinder must be closed at the end of each stroke, and before the brake pedal is released to ensure that air cannot enter the system. It is also important that the brake pedal be returned to the full released position.

4. When fluid coming from the submerged end of the hose is clear and free of bubbles, close the bleeder screw and release the brake pedal.
5. Tighten the bleeder screw to the maximum torque value specified below..

Item	Torque Specification
Bleeder Screw	38 in. lbs. (4 Nm)

Flushing

The process of removing old brake fluid to remove water, mineral oil, or other contaminants from the system is called flushing the hydraulic system.

Flushing is similar to bleeding except that a greater amount of brake fluid is discharged from each bleeder point to make sure that all of the dirty or contaminated fluid is removed.

The total fluid capacity for the entire hydraulic brake system is 13 fl. oz. It is recommended to have at least 26 fl. oz. of DOT 4 brake fluid on hand when flushing.

BRAKES

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

BRAKE PEDAL REMOVAL AND INSTALLATION

Tool List	Qty.
Needle Nose Pliers.....	1
Screwdriver, Flat Head.....	1
Allen Socket, 1/4".....	1
Ratchet.....	1
Wrench, 1/2".....	1
Socket, 1/2".....	1
Torque Wrench, ft. lbs.....	1

1. Disconnect the master cylinder shaft from the brake pedal (8). (See Master Cylinder Replacement on page 34)
2. Remove bolt (18), bushings (17), washers (3) and lock nut (5) (Fig. 7).

Assemble in the reverse order of removal.

Tighten the nut (5) to the torque specified below.

Item	Torque Specification
5	18 - 20 in. lbs. (24 - 27 Nm)




Fig. 7 Brake Pedal Removal

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.


Notes:

A large grid of graph paper for taking notes, consisting of 20 columns and 30 rows of small squares.

BRAKES

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Notes:

A large grid of graph paper for taking notes, consisting of 20 columns and 30 rows of small squares.

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

ELECTRICAL




Fig. 1 Main Harness Routing

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




Fig. 3 Electrical Schematic

ELECTRICAL

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




Fig. 4 Electrical Schematic (continued)

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

VOLTAGE TESTING FOR BATTERIES

WARNING Hydrogen gas formed during battery charging is explosive. Avoid any electrical spark or open flame near battery.

NOTICE: If the temperature of the battery or the ambient temperature is below 60° F (15.55° C), the capacity of the battery will be reduced, and it will require more time to charge.

Voltage on a cold battery increases faster, therefore reducing the charging rate.

Fully charge new batteries or batteries that have been in storage before testing or installing in vehicle.

CAUTION Do not over charge battery.

Use a Digital Volt Ohm Meter (DVOM) to check the battery.

Attach the negative (-) lead of the DVOM to the ground terminal of the battery. Attach the positive (+) lead to the positive battery terminal. The voltage reading obtained should be 12 volts or above. If the reading is below 12 volts, the battery needs to be charged or replaced.

MAIN HARNESS

Power Supply

Tool List

DVOM.....	Qty.
	1

1. Check for loose or bare wires.
2. Check for loose wires at each terminal connection and for worn insulation or bare wires touching the frame.

CAUTION Bare wires can cause a short-circuit.

NOTICE: If any DVOM readings indicate a faulty wire, check the condition of the terminals and wire junction. A faulty wire must be replaced. (See Faulty Wire Replacement on page 46)

3. Check the condition of the 72V batteries set.
 - a. Check for adequate battery volts (nominal 12 VDC) by setting the DVOM to 30 VDC range and place the red probe (+) on the battery post with the white (WHT) wire attached.
 - b. Place the black probe (-) on the battery post with the black (BLK) wire attached.
 - c. A reading of 11 VDC or greater indicates adequate battery condition.
 - d. No reading indicates:
 - a poor connection between the probes and the battery terminals or
 - a faulty DVOM

- e. A voltage reading below 11 volts indicates poor battery condition and the vehicle should be recharged before proceeding with the test.




Fig. 5 72V Battery Set Connections

NOTICE: Due to the resistance of the wires involved within the harness, voltage readings can be slightly lower than battery voltage. A reading of 1 volt below battery voltage is acceptable.

4. Check the power wire.
 - a. Attach the black probe (-) to the battery post with the black wire attached.
 - b. Attach the red probe (+) to the power (white) wire terminal at the fuse block.
 - c. A reading of battery voltage indicates that the power wire is in good condition.

NOTICE: The power wire supplies power to the entire fuse block.

5. Check the fuse (Ref. Fig. 6).
 - a. Place the red probe (+) to each wire terminal on the fuse block.
 - b. A reading of battery voltage indicates that the fuse is in good condition.
 - c. No reading indicates a faulty fuse; replace with a good fuse of the same amperage rating.

ELECTRICAL

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

CAUTION The use of an incorrect fuse rating can damage electrical components.




Fig. 6 Fuse Block




Fig. 7 Headlight Bulb Replacement

Accessory Wiring

After determining that there is power to the fuse panel, and the fuse is good, check the circuit using the procedures previously used to check the power supply (See Power Supply on page 45).

Use the wiring diagram to check for correct wiring and wire routing (Ref. Fig. 2). If there is power at the fuse end of the wire, there is power at the other end of the wire at the switch or electrical accessory, and there is continuity at the ground connection; then the circuit is complete. Electricity must flow from the fuse panel through the full length of the circuit to the ground connection. Correct any interruption of electricity flow, by repairing or replacing the wire or the switch or accessory.

Faulty Wire Replacement

Replace a faulty wire with one of the same gauge and color. Connect between the correct components, and secure to the harness bundle with a wire tie. Cut the faulty wire back close to the harness and wrap the ends with vinyl electrical tape.

Headlight Bulb Replacement (Standard)

1. Find the bulb socket (3) on the rear of light and disconnect the harness (4) from the bulb.
2. Rotate the bulb socket a quarter turn counterclockwise to unlock and remove bulb and socket (Ref. Fig. 7).
3. Insert new bulb, install the socket and bulb assembly, and rotate the socket (3) a quarter turn clockwise to secure.
4. Reconnect the wiring harness (4) to the bulb socket.

Tail light Replacement

Tool List	Qty.
Drill.....	1
Drill Bit.....	1
Rivet Gun.....	1

1. Drill out the rivets (8).
2. Disconnect the wiring harness from the tail light assembly (9).
3. Install the new tail light assembly.
4. Install new rivets (Ref. Fig. 8).

Headlight bulbs, tail light assemblies, and fuses are available from a local distributor, an authorized branch or the service department.

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




Fig. 8 Tail Light Replacement

ELECTRONIC SPEED CONTROL

Speed Sensor

The speed sensor uses a sealed sensor to read the impulses of a ring magnet that is attached to the armature shaft of the motor speed sensor (Ref. Fig. 9). Magnetic pulses change to electrical signals, which the controller uses to determine the motor speed.

Test the speed sensor and replace if necessary (See FAULT TESTING on page 51).





Fig. 9 Speed Sensor

Rotary Position Sensor


The rotary position sensor determines the speed of the vehicle. The rotary position sensor is connected through the main harness to the electronic speed control system. With no pressure applied on the accelerator pedal, the rotary position sensor remains in the neutral position. When the pedal is pressed, the amount of deflection in the rotary sensor is transferred to the electronic speed control system. The speed control system controls the speed of the motor that transmits power to the electric powertrain module in the vehicle.

Controller

The controller is a solid state unit that activates a solenoid, and controls the function of the vehicle by responding to inputs from the rotary position sensor, motor speed sensor and many other units. The controller is located under the flip seat at the rear of the vehicle (Ref. Fig. 10).



For Vehicles Manufactured Before February 24, 2019



For Vehicles Manufactured After February 25, 2019

Fig. 10 Controllers

The main wire harness, rotary position sensor, and speed sensor are connected to the controller with a 24-pin plug. The rotary position sensor is connected to the controller with a 2-pin plug on the main wire harness. The speed sensor is connected to the controller with a 3-pin plug on the main wire harness.

The controller is connected to the batteries and creates a regulated power supply for the rotary position sensor. When the pedal is pressed, the amount of deflection in

ELECTRICAL

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

the rotary sensor changes the voltage which is fed back to the controller. The controller senses the change in voltage and supplies the appropriate power to the motor.

The rotary position sensor unit and the controller are both solid state units that contain no serviceable parts. The testing procedures test the basic functionality of the power and control wiring systems. Once the functionality of the wiring has been confirmed, the remaining tests are used to identify which of the components (controller or rotary position sensor) must be replaced.

Item	Torque Specification
21	80 - 90 in. lbs. (9 - 10.1 Nm)
25	90 - 100 in. lbs. (10.1-11.2 Nm)

Controller Replacement

Tool List	Qty.
Socket, 7/16.....	1
Socket, 13mm.....	1
Ratchet.....	1
Extension, 6".....	1
Wrench, 7/16".....	1
Wrench, 13mm.....	1
Insulated Wrench, 9/16".....	1
Torque Wrench, ft. lbs.	1

⚠ WARNING To prevent electrical shock, the negative (B-) wire must be removed before discharging the controller.

Use a large screwdriver to cause a short-circuit in the positive (B+) and negative (B-) terminals of the controller. Be sure to hold screwdriver by the insulated handle.

NOTICE: Record the location of the wiring on the controller before disconnecting it.

NOTICE: Always test the motors for a shorted condition before installing a new converter. An electrical motor short may be the cause of the controller failure and will damage the new controller (See AC Motor Bench Test on page 120).

1. Use an insulated wrench to remove the negative (B-) wire from the battery.
2. Remove the bolts (9,21) and flat washers (13,22) (Ref. Fig. 11).
3. Remove the connectors from the controller (10,24) (Ref. Fig. 11).
4. Disconnect the cables connecting the controller to the motor.
5. Remove bolts (12,23), washers (11) and lock nuts (14,25) (Ref. Fig. 11).
6. Remove the controller (10,24) from the controller bracket (Ref. Fig. 11).
7. Mount new controller (10,24) and connect wiring (Ref. Fig. 11).
8. Tighten the hardware to the torque values specified below.
9. Connect the negative (B-) battery cable.

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

For Vehicles Manufactured After February 25, 2019
CONTROLLER with REAR MOTOR CONNECTIONS




Fig. 11 Controller Removal

Solenoid Replacement

Tool List

	Qty.
Socket, 7/16"	1
Socket, 3/8"	1
Ratchet	1
Insulated Wrench, 9/16"	1
Torque Wrench, ft. lbs.	1

WARNING To prevent electrical shock, the negative (B-) wire must be removed before discharging the controller. Use a large screwdriver to cause a short-circuit in the positive (B+) and negative (B-) terminals of the controller. Be sure to hold screwdriver by the insulated handle.

NOTICE: Record the location of the wiring on the controller before disconnecting wiring from the solenoid. Use an insulated wrench to remove the negative (B-) wire from the battery.

1. Disconnect the wires from solenoid (20).

- Remove the two screws (16), washers (18) and nuts (17) to remove the solenoid (20) from the rear fender (Ref. Fig. 12).
- Mount new solenoid (20) and connect the wiring.
- Tighten the nut (17) to torque value specified below.

Item	Torque Specification
17	6 - 8 ft. lbs. (8 - 11 Nm)

- Connect the negative (B-) battery cable.

ELECTRICAL

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




Fig. 12 Solenoid Replacement




Fig. 13 DC to DC Converter

DC to DC Converter

Tool List	Qty.
Wrench, 1/4"	1
Socket, 1/4"	1
Ratchet	1

1. Disconnect the negative (-) battery cable using an insulated wrench.
2. Disconnect the electrical connectors (33).
3. Remove the two nuts (31) that secure the DC to DC converter (30) to the frame (34).
4. Remove the DC to DC converter (30) from the vehicle retaining the spacers (32) for reuse during the installation (Ref. Fig. 13).

Assemble in the reverse order of removal. Tighten the nuts to the torque values below

Item	Torque Specification
31	50 - 55 in. lbs. (5 - 6 Nm)

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

FAULT TESTING

General

Knowledge of use of wiring diagrams and a Digital Volt Ohm Meter (DVOM) is necessary to effectively determine fault within the circuits that include the electrical accessories, lighting, and gauges.

The wiring diagram shows the path followed by a voltage or signal from its origination point to its destination. Each wire is indicated by color.

Knowledge of simple logic fault testing will reduce the number of steps required to isolate the problem.

Example 1: If the vehicle does not start and none of the lights operate or burn dimly, test the battery before trying to determine fault within the lighting circuit.

Example 2: If a problem occurs in the lighting circuit that causes only one of the headlights to fail, it is not necessary to check the battery wiring or the fuse since voltage is present. Check the headlight that is not operating. If power is found at the connector and the ground wiring is satisfactory, it is a burned out bulb or a poor contact between the connectors and the headlight.

If power is not present but the other headlight functions, a wiring problem is indicated between the two headlights.

In some cases where battery voltage is expected, the easiest way to test the circuit is to set the DVOM to DC volts and put the negative (-) probe on the negative battery terminal. Move the positive (+) probe to each wire terminal starting at the battery and moving out to the device that is not working. Check both sides of all switches and fuses.

When no battery voltage is found, the problem is between the point where no voltage is detected, and the last place that voltage was detected. In circuits where no voltage is expected, the same procedure can be used except that the DVOM is set to continuity. Place the negative (-) probe on a wire terminal at the beginning of the circuit and move toward the device that is not working with the positive (+) probe. When continuity is no longer indicated, a failed conductor or device is indicated.

Testing Battery Voltage

Determine the condition of the battery set before proceeding with any electrical testing.

An open voltage test is not helpful since a battery that has deteriorated to the point of requiring replacement can still show eight volts or higher in an open voltage test.

If there is any doubt as to the adequacy of the battery set, charge the batteries and perform a load test using a discharge machine following manufacturer's instructions. If batteries are satisfactory, recharge battery set.

With the adequacy of the batteries confirmed, use a DVOM connected directly to the battery terminal posts to determine the open voltage of the set.

In the following tests, this voltage level will be used as a reference.

Some loss due to resistance of wires and connectors can

be shown by readings that could be up to one volt less than battery reference voltage (BRV).

No reading indicates an "open" condition and the battery wires should be checked for a broken or disconnected wire or component.

Continuity Check

WARNING To prevent possible injury or death caused by a battery explosion, disconnect the electrical power. Use an insulated wrench to remove the negative (B-) wire from the battery.

Before removing the negative (B-) wire at the battery, switch the key switch to the OFF position, then remove the key from the switch. Always use insulated wrenches when working on batteries.

To check for continuity, set the DVOM to the K setting and select 'Continuity'. The meter will give an audible signal when it detects continuity. If the meter does not have a continuity setting, set it to K, the meter will indicate "0" when it detects continuity.

Testing A Switch for Continuity

Put one probe on one contact of the switch. Put the second probe on the second terminal of the switch (Ref. Fig. 14).

Actuating a normally open (NO) switch causes the DVOM to show "0", or gives an audible indication when the switch is operated. A normally closed (NC) switch causes the meter to show "0", or gives an audible indication when the probes are attached, without activating switch. The audible indicator will stop and the meter display will show a value greater than "0" when the switch is activated.

The change in display or audible indicator shows that the switch is functioning.




Fig. 14 Continuity Check of Switch

ELECTRICAL

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Testing A Solenoid for Continuity

Put one probe on one of the large terminals and the other probe on the second large terminal (Ref. Fig. 15).

If the meter shows “0” or gives an audible indication, the solenoid terminals are “welded” closed and the solenoid must be replaced.

If the continuity test shows that contacts are not “welded” and the wiring to the solenoid coil is good, the coil has failed and the solenoid must be replaced.




Fig. 15 Continuity Check of Solenoid

ACCESSORIES

Key Switch

Tool List	Qty.
Screwdriver, Flathead.....	1
Bit Driver.....	1
Torx Bit, T30.....	1
Pliers, Needle Nose.....	1

1. Set the key switch to the OFF position and remove the key.
2. Disconnect the negative (-) battery cable using an insulated wrench.
3. Remove the gauge panel (See Gauge Panel Replacement on page 24).
4. Disconnect the main wiring harness from the key switch.
5. Squeeze the tabs on the back side of the key switch (41) and push it through the front of the gauge panel (40) (Ref. Fig. 16).

Assemble in the reverse order of removal. Confirm proper orientation using the alignment pegs.




Fig. 16 Key Switch

State of Charge (SOC) Meter

Tool List	Qty.
Screwdriver, Flathead.....	1
Bit Driver.....	1
Torx Bit, T30.....	1
Pliers, Needle Nose.....	1

1. Disconnect the negative (-) battery cable.
2. Remove the gauge panel (See Gauge Panel Replacement on page 24).
3. Disconnect the main wiring harness from the SOC meter.
4. Squeeze the tabs on the back of the SOC meter (42) and push it through the front of the gauge panel (40) (Ref. Fig. 17).

Assemble in the reverse order of removal. The SOC meter will only go into the gauge panel in the correct orientation.




Fig. 17 SOC Meter

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Rocker Switches

Tool List	Qty.
Screwdriver, Flathead.....	1
Bit Driver.....	1
Torx Bit, T30	1
Pliers, Needle Nose.....	1

1. Disconnect the negative battery cable using an insulated wrench.
2. Remove the gauge panel (See Gauge Panel Replacement on page 24)
3. Disconnect the main wiring harness from the rocker switch.
4. Squeeze the tabs on the top and bottom of the backside of the rocker switch (43) and push it through the front of the gauge panel (40) (Ref. Fig. 18).

Assemble in the reverse order of removal. Confirm proper orientation of the switch prior to seating it completely in the gauge panel.




Fig. 18 Rocker Switch

12V Outlet

NOTICE: It is not necessary to remove the gauge panel to replace the 12V outlet.

Tool List	Qty.
Drill.....	1
Drill Bit	1
Rivet Gun	

1. Drill out the two rivets securing the 12V outlet (45) to the gauge panel (40).
2. Gently pull the 12V outlet (45) through the front of the gauge panel (40) until the push on connectors are accessible.
3. Disconnect the push on connectors.
4. Connect the push on connectors to the new 12V outlet.
5. Install the 12V outlet into the gauge panel using new rivets (Ref. Fig. 19).





Fig. 19 12V Outlet

ELECTRICAL

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Notes:

A large grid of graph paper for taking notes, consisting of 20 columns and 30 rows of small squares.

FRONT CV SHAFT, SUSPENSION, AND STEERING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

FRONT CV SHAFT, SUSPENSION, AND STEERING

FRONT SUSPENSION

NOTICE: Hardware that is removed must always be installed in its original position unless otherwise specified. If torque values are not specified, refer to the Torque Specifications table (See TORQUE SPECIFICATIONS on page 5).

⚠ WARNING To reduce the possibility of personal injury, follow the lifting procedure in the SAFETY section of this manual (See LIFTING THE VEHICLE on page 8). Place wheel chocks in front and behind the rear wheels. Check the stability of the vehicle on the jack stands before starting any repair procedure. Never work on a vehicle that is supported by a jack alone.

Routine maintenance of the front suspension and steering consists of:

- periodic inspections for loose, worn or damaged components
- alignment checks

See Lubrication Chart and Periodic Service Schedule for recommended intervals (See PERIODIC SERVICE SCHEDULE on page 131). Use only recommended lubricants.

Routine examination of the tires will provide indications if an alignment is required.

The hub is a sealed assembly and does not require lubrication.

The control arms contain lube free bushings.

The tie rod ends are sealed and do not require lubrication.

The steering unit is sealed and does not require lubrication.

Front Strut Assembly Replacement

Tool List	Qty.
Wheel Chocks	4
Floor Jack.....	1
Jack Stands.....	4
Plastic Faced Hammer	1
Wrench, 17mm	1
Wrench, 19mm	1
Impact Wrench	1
Impact Socket, 24mm.....	1
Torque Wrench, ft. lbs	1
Socket, 17mm	1
Socket, 19mm	1
Ratchet.....	1

Inspect the strut cartridge for leaks at the seal. Replace if leakage is found.

1. Lift and support the vehicle (See LIFTING THE VEHICLE on page 8).

2. Remove the front wheel (See WHEEL AND TIRE SERVICE on page 126).
3. Remove the brake calipers from the rotor (See Brake Pads Replacement on page 35).
4. Remove the cotter pin (8) and castellated nut (12) at the end of the steering rack assembly (11) (Ref. Fig. 1).
5. Remove the cotter pin (24), castellated nut (25), and flat washer (26) from the axle (27).
6. Remove the cotter pin (10) and nut (9) from the bottom of the front strut assembly (1) at the control arm assembly (21).
7. Tap downward on the control arm assembly with a plastic hammer to separate it from the ball joint.
8. Remove the front axle (27) from the front strut assembly.
9. Remove the nut (2), washers (3, 4), and strut bushing (5) that secures the top of the strut assembly (1) to the vehicle frame.
10. Remove the strut assembly from the vehicle.

Assemble in the reverse order of removal.

Tighten hardware to torque values specified below.

Item	Torque Specification
12	45 - 55 ft. lbs. (61 - 74 Nm)
9	12 - 14 ft. lbs. (16 - 19 Nm)
2, 6	14 - 16 ft. lbs. (19 - 22 Nm)

FRONT CV SHAFT, SUSPENSION, AND STEERING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




Fig. 1 Front Suspension

Assemble in the reverse order of removal.
Tighten hardware to torque values specified below.

Item	Torque Specification
23	32 - 37 ft. lbs. (43 - 50 Nm)
9	12 - 14 ft. lbs. (16 - 19 Nm)




Fig. 2 Control Arm

Control Arm Assembly Replacement

Tool List	Qty.
Wheel Chocks	4
Floor Jack	1
Jack Stands	2
Plastic Faced Hammer	1
Needle Nose Pliers	1
Wrench, 9/16"	1
Wrench, 17mm	1
Socket, 9/16"	1
Socket, 17mm	1
Ratchet	1
Ball Joint Separator	1
Torque Wrench, ft. lbs.	1

- Lift and support the front of the vehicle (See Lift Front of Vehicle on page 9).
- Remove the front wheel (See WHEEL AND TIRE SERVICE on page 126).
- Remove the cotter pin (10) and castellated nut (9) from the lower ball joint at the control arm assembly (21) (Ref. Fig. 1).
- If necessary, use a ball joint separator to separate the control arm (21) from the strut assembly (1).
- Remove the bolt (22), flanged bushings (19), and lock nuts (23)
- To remove the control arm (21) from the vehicle (Ref. Fig. 2).

Lower Ball Joint Replacement

Tool List	Qty.
Wheel Chocks	4
Floor Jack	1
Jack Stands	2
Allen Socket, 5/32"	1
Socket, 17mm	1
Wrench, 17mm	1
Ball Joint Separator	1
Ratchet	1
Thread Locking Adhesive, Red	003 mL

- Lift and support the front of the vehicle (See Lift Front of Vehicle on page 9).
- Remove the front wheel (See WHEEL AND TIRE SERVICE on page 126).
- Remove the cotter pin (10) and castellated nut (9) from the lower ball joint at the control arm assembly (21) (Ref. Fig. 1).
- If necessary, use a ball joint separator to separate the control arm from the lower ball joint.
- Remove the two screws (101) securing the lower ball joint (100) to the strut assembly (1) (Ref. Fig. 3).

FRONT CV SHAFT, SUSPENSION, AND STEERING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Assemble in the reverse order of removal using red thread locking adhesive on screws (101).

Tighten hardware to torque values below.

Item	Torque Specification
101	95 - 105 in. lbs. (11 - 12 Nm)
9	12 - 14 ft. lbs. (16 - 19 Nm)




Fig. 3 Lower Ball Joint

Wheel Bearing Replacement

Wheel Chocks.....	4
Floor Jack	1
Jack Stands	4
Plastic Faced Hammer	1
Wrench, 17mm	1
Wrench, 19mm	1
Impact Wrench.....	1
Impact Socket, 24mm	1
Torque Wrench, ft. lbs.....	1
Socket, 17mm.....	1
Socket, 19mm.....	1
Ratchet	1
Snap Ring Pliers	1
Arbor Press.....	1
Hammer, Ball Peen.....	1
Brass Punch	1

1. Lift and support the front of the vehicle (See Lift Front of Vehicle on page 9)
2. Remove the front wheel (See WHEEL AND TIRE SERVICE on page 126).
3. Remove the strut assembly (See Front Strut Assembly Replacement on page 55).
4. Slide the hub out of the front of the strut assembly.
5. Remove the snap ring (104) securing the wheel bearing (103) into the strut assembly (1).
6. Press the wheel bearing (103) out of the front of strut assembly (1) from the rear.
7. If an arbor press is not available, a ball peen hammer and brass punch can be used to tap the wheel bearing out of the strut assembly.

Assemble in the reverse order of removal.




Fig. 4 Wheel Bearing

FRONT CV SHAFT, SUSPENSION, AND STEERING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Strut Replacement

Tool List	Qty.
Wheel Chocks	4
Floor Jack	1
Jack Stands	4
Plastic Faced Hammer	1
Wrench, 17mm	1
Wrench, 19mm	1
Wrench, 13mm	1
Wrench, 9mm	1
Impact Wrench	1
Impact Socket, 24mm	1
Torque Wrench, ft. lbs.....	1
Socket, 17mm.....	1
Socket, 19mm.....	1
Socket, 13mm.....	1
Coil Spring Compressor	1
Ratchet	1

Item	Torque Specification
111	14 - 16 ft. lbs. (19 - 22 Nm)
117	20 - 25 ft. lbs. (27 - 34 Nm)

⚠ DANGER Use extreme caution when working with compressed coil springs.

Do not compress the spring any more than is necessary to relieve the tension against the spring cap.

1. Lift the front of the vehicle (See Lift Front of Vehicle on page 9).
2. Remove the front wheel (See WHEEL AND TIRE SERVICE on page 126)
3. Remove the strut assembly (See Front Strut Assembly Replacement on page 55).
4. Compress the coil spring (115) just enough to relieve the tension between the coil spring cap (112) and the coil spring base (114).
5. Remove the spring retaining nut (111) and coil spring cap (112).
6. Slowly release the tension from the coil spring compressor and remove the spring (115).
7. Remove the bump stop (113) from the strut (110) to reuse during reassembly. If the bump stop is cracked or otherwise damaged, replace it with a new one.
8. Remove the two nuts (117), washers (118), and bolts (116) securing the strut to the strut assembly (1).
9. Remove the strut (110) from the strut assembly (1), retaining the coils spring base washers (114) for reuse (Ref. Fig. 5).

Assembly in the reverse order of removal using new lock nuts.

Torque all hardware to the torque values below.




Fig. 5 Strut Replacement

FRONT CV SHAFT, SUSPENSION, AND STEERING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

FRONT AXLE

NOTICE: When the axle is replaced, the front wheels must be aligned. (See Wheel Alignment on page 64)

CV Shaft Replacement

Tool List	Qty.
Wheel Chocks	4
Floor Jack.....	1
Jack Stands.....	2
Impact Wrench	1
Impact Socket, 24mm.....	1
Plastic Faced Hammer.....	1
Socket, 17mm	1
Wrench, 17mm.....	1
Torque Wrench, ft. lbs	1
Pry Bar	1
Ratchet.....	1

CAUTION Inspect the front axle (shaft) for contamination, specifically for torn CV boots around the axle. Replace the front axle if any contamination is found.

1. Lift and support the vehicle (See LIFTING THE VEHICLE on page 8).
2. Remove the front wheel (See WHEEL AND TIRE SERVICE on page 126).
3. Remove the cotter pin (8) and nut (12) at the end of the steering rack assembly (11) (Ref. Fig. 1).
4. Remove the cotter pin (24), castle nut (25), and flat washer (26) from the end of the front axle (27) (Ref. Fig. 1).
5. Remove the cotter pin (10) and nut (9) from the lower ball joint.(Ref. Fig. 1).
6. Tap downward on the control arm assembly (21) with a plastic faced hammer, below the strut assembly (1) to separate the control arm assembly from the strut assembly (1) If necessary, use a ball joint separator.
7. Remove the outer end of the front axle (27) from the front strut assembly (1) (Ref. Fig. 6).
8. Pry from the back side of the CV joint housing between the differential and the CV axle, being careful not to damage the seal on the differential, to remove the axle.(27).

Assemble in the reverse order of removal.

Tighten hardware to torque values specified below.

Item	Torque Specification
12	45 - 55 ft. lbs. (61 - 74 Nm)
25	100 - 110 ft. lbs. (136 - 149 Nm)
9	12 - 14 ft. lbs. (16 - 19 Nm)




Fig. 6 CV Axle Removal

FRONT CV SHAFT, SUSPENSION, AND STEERING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

CV Joint Boot Replacement

Tool List

	Qty.
Needle Nose Pliers.....	1
Wire Cutters.....	1

1. Remove the front axle assembly. (See Front Differential Replacement on page 60)
2. Inspect the inner and outer CV joint boots (28) for damage (Ref. Fig. 7).
3. Cut the CV joint boot clamps (29) and (30) and remove the CV joint boot (28).

Assemble in the reverse order of removal.




Fig. 7 CV Boot Replacement

Front Differential Replacement

Tool List

	Qty.
Wheel Chocks	4
Floor Jack	1
Jack Stands	4
Impact Wrench	1
Impact Socket, 24mm.....	1
Wrench, 3/4".....	1
Plastic Faced Hammer	11
Socket, 9/16"	1
Wrench, 9/16"	1
Torque Wrench, ft. lbs.....	1

WARNING To prevent injury caused by accidental movement of the differential, you must have a second person to help support and remove the differential.

1. Lift and support the front of the vehicle (See Lift Front of Vehicle on page 9).

2. Remove the front wheel(See WHEEL AND TIRE SERVICE on page 126).
 3. Remove the CV shaft. (See CV Shaft Replacement on page 59)
 4. Remove the motor (See Front Motor Removal on page 68).
 5. Remove the breather hose (34) by removing the clamp (35) and set aside for reuse during installation.
 6. Remove the eight bolts (31), lock washers (33) and flat washers (32).
 7. Carefully lift the differential (30) from vehicle (Fig. 8).
- Assemble in the reverse order of removal.

Tighten hardware to torque values specified below.

Item	Torque Specification
31	30 - 35 ft. lbs. (41 - 47 Nm)




Fig. 8 Front Differential Replacement

FRONT CV SHAFT, SUSPENSION, AND STEERING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

STEERING

Steering Wheel Replacement

Tool List	Qty.
Screwdriver, Flat Head	1
Socket, 24mm	1
Ratchet	1
Plastic Faced Hammer	1
Ball Peen Hammer	1
Torque Wrench, ft. lbs	1

NOTICE: Align wheels straight ahead to maintain correct orientation when replacing steering wheel.

1. Insert a flat screwdriver under the edge of the steering wheel cover (37) and pry it from the steering wheel (39) (Ref. Fig. 9).




Fig. 9 Steering Wheel Cover Removal

2. Loosen the lock nut (38) two to three turns (Ref. Fig. 9) until it is slightly above the end of the steering shaft. DO NOT completely remove the nut at this time.
3. From below the steering wheel, put a plastic faced hammer against the lock nut as shown (Ref. Fig. 10).
4. Pull upward on the plastic faced hammer and strike hammer sharply with a ball peen hammer.

CAUTION

Do not hit the steering wheel lock nut or the end of the steering shaft directly with the ball peen hammer.




Fig. 10 Remove Steering Wheel

5. When the steering wheel (39) is loose, remove the lock nut (38) and the steering wheel (39).
6. Before installing the steering wheel (39), lightly cover the splines of the steering shaft with a commercially available anti-seize compound.
7. Align the front wheels in the straight ahead position.
8. Align the steering wheel (39) on the steering shaft, then slide onto shaft.

Tighten the lock nut (38) to the torque value specified below.

Item	Torque Specification
38	20 - 25 ft. lbs. (27 - 34 Nm)

9. Align the pins on the steering wheel cover (37) with the holes in the steering wheel (Ref. Fig. 9).
10. Press the cover until it snaps into place.

FRONT CV SHAFT, SUSPENSION, AND STEERING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Steering Column Replacement

Tool List

	Qty.
Socket, 15mm.....	1
Socket, 24mm.....	1
Ratchet.....	1
Wrench, 15mm.....	1
Torque Wrench, ft. lbs.....	1

1. Remove the steering wheel. (See Steering Wheel Replacement on page 61)
2. Remove the four bolts (41) and lock nuts (42) that secure the steering column (40) to the frame.

3. Remove the yoke bolts (44), lock washers, and nuts (46) to release the steering yoke (43) from the steering column (40) and steering rack (45) (Ref. Fig. 11).

Assemble in the reverse order of removal.

Tighten hardware to torques values specified below.

Item	Torque Specification
42	25 - 35 ft. lbs. (34 - 47 Nm)
38	20- 25 ft. lbs. (27 - 34 Nm)
44	25 - 30 ft. lbs. (34 - 41 Nm)




Fig. 11 Steering Column

FRONT CV SHAFT, SUSPENSION, AND STEERING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Steering Rack Replacement

Tool List

	Qty.
Wrench, 15mm	1
Needle Nose Pliers.....	1
Ball Joint Separator	1
Plastic Faced Hammer	1
Screwdriver, Flathead.....	1
Allen Socket, 8mm	1
Socket, 15mm	1
Socket, 17mm	1
Ratchet.....	1
Torque Wrench, ft. lbs.	1
Floor Jack.....	1
Wheel Chocks	2
Jack Stands.....	2

1. Raise the front of the vehicle (See Lift Front of Vehicle on page 9).
2. Remove the front wheels (See WHEEL AND TIRE SERVICE on page 126).
3. Remove the steering column from the steering rack (45). (See Steering Column Replacement on page 62)
4. Remove the cotter pin (8) and nut (12) from the front strut assembly (1.) (Ref. Fig. 1).
5. Remove the three bolts (49) and nuts (48) attaching the steering rack assembly to the frame (Ref. Fig. 12).

Assemble in the reverse order of removal.

Tighten nuts to the torque value specified below.

Item	Torque Specification
48	34 - 37 ft. lbs. (46 - 50 Nm)




Fig. 12 Steering Rack Removal

FRONT CV SHAFT, SUSPENSION, AND STEERING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Tie Rod Removal

Tool List

	Qty.
Floor Jack	1
Wheel Chocks	2
Jack Stands	2
Wrench, 17mm	1
Socket, 17mm.....	1
Ratchet	1

When replacing the tie rod (50), the steering rack (45) must be removed from the steering assembly to adjust the rack/ball joint length correctly. (Ref. Fig. 13)

1. Lift the front of the vehicle (See Lift Front of Vehicle on page 9)
2. Remove the front wheels (See WHEEL AND TIRE SERVICE on page 126).
3. Loosen the jam nut (52).
4. Remove the tie rod assembly (50) from the steering rack (45).

Tie Rod Installation

Tool List

	Qty.
Wrench, 17mm	1
Torque Wrench, ft. lbs.....	1
Crowfoot Wrench, 17mm.....	1
Thread Lock Primer	1
Thread Locking Adhesive, Red.....	1

1. Clean the threads.
2. Apply thread locking primer and red thread locking adhesive to the rack ball end, before attaching to the steering rack (45).
3. Install an inner tie rod end (53) on each outer tie rod end (51).
4. Set the jam nuts (52) 5/8" (16 mm) distance onto the threaded portion of the steering rack (45).
5. Install the tie rod assemblies (50) onto the threaded portion of the steering rack (45) until they reach the jam nuts (52).
6. The tie rod orientation must be as shown (Ref. Fig. 13).
7. Tighten all hardware to torque values specified below.

Item	Torque Specification
52	36 - 40 ft. lbs. (48 - 54 Nm)
50 (including 51 and 53)	20 - 25 ft. lbs. (27 - 34 Nm)




Fig. 13 Tie Rod Installation

MAINTENANCE

All steering and suspension components are lube free. Routine examination of the tires provide indications that an alignment is required.

NOTICE: Some maintenance items must be serviced more frequently on vehicles used under severe driving conditions.

Wheel Alignment

Measuring Tape	1
Wrench, 17mm.....	2
Torque Wrench, ft. lbs	1

1. Center the steering unit by pushing the vehicle forward 10 feet.
2. Allow the unit to center itself, or rotate the steering wheel to the left until the stop is contacted.
3. Rotate the wheel to the right while counting the number of rotations required to contact the right hand stop.
4. Divide the number of rotations by two. This will indicate the number of steering wheel rotations to achieve center.
5. Measure the center tread distance at the front of the tires. Measure as close to parallel with the front lower frame of the vehicle as possible (Ref. Fig. 14).
6. Put the measuring tape just under the frame rails and measure the center tread distance on the rear of the front tires.
 - The correct measurement is 1/8" to 1/4" toe in.
7. To adjust the wheel alignment, loosen the tie rod jam nut (52), while holding the hex form on the outer tie rod end (51) (Ref. Fig. 13).

If tie rods or ends have been replaced; adjust both rod spacers the same distance prior to installing on the vehicle.

8. Count the threads on each end of the tie rod to make sure that each side was adjusted equally.
9. Tighten the jam nut (52) to the torque value specified below.

FRONT CV SHAFT, SUSPENSION, AND STEERING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Item	Torque Specification
52	36 - 40 ft. lbs. (48 - 54 Nm)

Counting threads or measuring thread distance are two methods to equalize tie rod length.

Drive the vehicle to confirm that the steering wheel is correctly centered. If not, remove the steering wheel and rotate it to the correct position.



Fig. 14 Wheel Alignment Front of Front Tires




Fig. 15 Wheel Alignment Rear of Front Tires

FRONT CV SHAFT, SUSPENSION, AND STEERING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Notes:

A large grid of graph paper for taking notes, consisting of 20 columns and 30 rows of small squares.

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

MOTOR

GENERAL

CAUTION Do not use the accelerator and motor to hold the vehicle on a hill. Leaving the motor in a stalled condition for more than 3-4 seconds can cause permanent damage.

Disassembly of the motor is not recommended.

Neither the motor housing nor armature are available as service items, therefore in the unlikely event of a failure in either component, the entire motor must be replaced.

Motor Brake Removal

Tool List	Qty.
Wrench, 10mm	1
Insulated Wrench, 9/16"	1
Insulated Socket, 9/16"	1
Ratchet	1

1. Use an insulated wrench to disconnect the negative (-) battery cable from the battery (Ref. Fig. 2).
2. Disconnect the harness from the motor brake connector (7).
3. Remove the three bolts (5) and washers (4) that secure the motor brake (3) to the motor (1).
4. Remove the motor brake (3).
5. Make sure to retain the gasket (2) for reassembly or replace it if it is damaged (Ref. Fig. 1).

Motor Brake Installation

1. Verify that the seal is in place and that the mounting bolts pass through the holes without any interference.
2. Apply a small amount of anti-seize to the armature shaft.
3. Install the motor brake onto the motor leaving the bolts loose.
4. Connect the wiring harness.
5. Reconnect the negative (-) battery cable.
6. Turn the key switch on and set the park brake switch to the "RELEASE" position.
7. Tighten the bolts to the torque values below.
8. Return the park brake release switch to "RUN".




Fig. 1 Motor Brake

MOTOR

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Front Motor Removal

WARNING Disconnect the negative (-) battery cable with an insulated wrench before removing wires from the motor. A short-circuit of the motor wires can cause an explosion.

Tool List	Qty.
Wrench, 10mm	1
Insulated Wrench, 9/16"	1
Chalk or Paint Pen.....	1
Socket, 10mm.....	1
Ratchet	1
Scraper	1
Torque Wrench, in. lbs.....	1

1. Use an insulated wrench to disconnect the negative (-) battery cable from the battery (Ref. Fig. 2).
2. Mark both the axle and motor housings to help with realignment during assembly of the motor to rear axle (Ref. Fig. 3).




Fig. 3 Mark Axle and Motor

CAUTION Do not damage the splines when removing and installing the motor to the rear axle housing.

3. Disconnect the motor wires from terminals U, V, and W (12) (Ref. Fig. 4) (Ref. Fig. 5).
4. Remove the connectors at the speed sensor (8), temperature sensor (9), and motor brake (7) (Ref. Fig. 4).
5. Remove the six bolts (11) that secure the motor (1) to the axle housing (10).
6. Carefully slide the motor straight out from the axle splines.
7. Remove the bolts (5), washers (4), motor brake (3) and motor cover gasket (2) from the motor (1).
8. Keep the motor brake (3) and gasket (2) to be used in assembly, or replace them if they are damaged.
9. Clean the motor coupler with compressed air and use a scraper to remove any rust deposits.




Fig. 2 Disconnect Battery Cable

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




Fig. 4 Front Motor Components

Front Motor Installation

Assemble in the reverse order of removal.

1. Apply a small quantity of molybdenum grease or a generous amount of silver grade anti-seize grease to the female part of the spline.
2. Carefully align the motor spline with the input shaft of the axle. Align the orientation marks and install the mounting hardware.
3. Place the differential gasket (6), in the groove provided in the differential (10). Finger tighten the bolts (11) in a 'cross sequence' (Ref. Fig. 4), then tighten to 25 in. lbs. (2.82 Nm) increments of torque using the same 'cross sequence' pattern.
4. Reconnect the temperature sensor (9), speed sensor (8), and motor brake (7) wiring harnesses.
5. Reconnect the U, V, and W terminals (12) (Ref. Fig. 4) (Ref. Fig. 5).

MOTOR WIRING

Motor Terminal	Wire Marker	From
U	U	Controller "U"
V	V	Controller "V"
W	W	Controller "W"

Fig. 5 Motor Wiring

Tighten the hardware to the torque value specified below.

Item	Torque Specification
5, 9	72 - 78 in. lbs. (8 - 9 Nm)
12	5 - 7 in. lbs. (.6 - .8 Nm)

⚠ WARNING *Disconnect the negative (-) battery cable with an insulated wrench before removing wires from the motor. A short-circuit of the motor wires can cause an explosion.*

MOTOR

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Rear Motor Removal

Tool List

	Qty.
Wrench, 10mm	1
Insulated Wrench, 9/16"	1
Chalk or Paint Pen.....	1
Socket, 10mm.....	1
Ratchet.....	1
Torque Wrench, in. lbs.....	1

1. Use an insulated wrench to disconnect the negative (-) battery cable from the battery (Ref. Fig. 6).
2. Mark both the axle and motor housings to help with realignment during assembly of the motor to rear axle (Ref. Fig. 7).
3. Disconnect the motor wires from terminals U, V, and W (12) (Ref. Fig. 8) (Ref. Fig. 9).




Fig. 7 Mark Axle and Motor

CAUTION Do not damage the splines when removing and installing the motor to the rear axle housing.

4. Disconnect the speed sensor (8) and temperature sensor (9). (Ref. Fig. 8).
5. Remove the six bolts (11) that secure the motor (1) to the axle housing, and carefully slide the motor straight out from the axle splines.
6. Remove the bolts (5), washers (4), motor cover (3) and motor cover gasket (2) from the motor (1).
7. Keep the motor cover (3), hardware (5,4), and gasket (2) to be used in assembly, or replace them if they are damaged.
8. Clean the motor coupler with compressed air and use a scraper to remove any rust deposits.




Fig. 6 Disconnect Battery Cable

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




Fig. 8 Rear Motor Components

Rear Motor Installation

Assemble in the reverse order of removal.

1. Apply a small quantity of molybdenum grease or a generous amount of silver grade anti-seize grease to the female part of the spline.
2. Carefully align the motor spline with the input shaft of the axle. Align the orientation marks and install the mounting hardware.
3. Place the differential gasket (6), in the groove provided in the differential (10). Finger tighten the bolts (11) in a 'cross sequence' (Ref. Fig. 8), then tighten to 25 in. lbs. (2.82 Nm) increments of torque using the same 'cross sequence' pattern.
4. Reconnect the temperature sensor (9) and speed sensor (8) wiring harnesses.
5. Reconnect the U, V, and W terminals (12) (Ref. Fig. 8) (Ref. Fig. 9).

Tighten the hardware to the torque value specified below

Item	Torque Specification
5, 9	72 - 78 in. lbs. (8 - 9 Nm)
12	5 - 7 in. lbs. (.6 - .8 Nm)

MOTOR WIRING

Motor Terminal	Wire Marker	From
U	U	Controller "U"
V	V	Controller "V"
W	W	Controller "W"

Fig. 9 Motor Wiring


MOTOR TESTS

The armature and motor housing are not available as individual parts. The Curtis handheld can show specific motor faults (See FAULT TESTING on page 89). The motor can also be tested using a DVOM (See AC Motor Bench Test on page 120). Additionally, when a test of the power wiring system indicates that the system is operating correctly and the vehicle either does not run or runs poorly, the motor is the only remaining component and should be replaced.

MOTOR

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Notes:

A large grid of graph paper for taking notes, consisting of 20 columns and 30 rows of small squares.

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

SEATING AND OPS

SEATING

NOTICE: Complete seat removal and replacement is not necessary in some of the repair procedures. Remove and replace the seat bottom or seat back assembly only if necessary.

Front Seat Removal and Installation

Front Seat Bottom

Lift and tilt the seat bottom toward the front of the vehicle, and remove the seat bottom.

To install the seat bottom, insert the seat tabs in the slots in the seat frame, and lower the seat bottom in position.

Front Seat Back and Support

Tool List

	Qty.
Ratchet.....	1
Socket, 7/16.....	1
Socket, 9/16.....	1
Wrench, 9/16.....	1

- To remove front seat back (9), remove four screws (11) and lock washers (12) securing the seat back to the lower OPS (Ref. Fig. 1).
- Remove the four lock nuts (8), washers (7), and bolts (6), from the seat back support (5) (or lower OPS).

Assemble in the reverse order of removal.

Tighten the bolts (11) to the torque value specified below.

Item	Torque Specification
11	13 - 16 ft. lbs. (18 - 22 Nm)
8	30 - 33 ft. lbs. (40 - 45 Nm)




Fig. 1 Front Seat Back Removal

Rear Seat Removal and Installation

Tool List

	Qty.
Socket, 7/16".....	1
Socket, 9/16".....	1
Ratchet.....	1
Wrench, 7/16".....	1
Wrench, 9/16".....	1
Torque Wrench, ft. lbs.....	1
Torque Wrench, in. lbs.....	1

- Remove the two bolts (15) and lock nuts (16) securing the armrest (14) to the seat frame (Ref. Fig. 2).
- Remove the bolts (36) and lock nuts (16) securing the armrest (14) to the footrest (24).
- Remove the armrests (14) from the rear seat (Ref. Fig. 2).




Fig. 2 Arm Rest Removal

SEATING AND OPS

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

4. Remove the bolts (33) and lock washers (34) fastening the seat back (32) to the seat back bracket (28).
5. Remove the lock nuts (31), flat washers (30), and bolts (29) to remove the seat back brackets.
6. Remove the deck board fillers (40) (Ref. Fig. 3).




Fig. 3 Flip Seat Back Removal

7. Remove the lower seat belt support from the frame (See Rear Seat Belt Buckle Removal on page 77).
8. Remove the four lock nuts (35), flat washers (20), and bolts (19) to remove the seat bottom (18) (Ref. Fig. 4).




Fig. 4 Seat Bottom Removal

9. Remove the bolts (42), flat washers (43), and lock nuts (44) that secure the seat frame (41) to the main frame of the vehicle (Ref. Fig. 5).




Fig. 5 Seat Frame

10. Remove bolts (21), flat washers (22), and lock nuts (23) that secure the crossmember to the vehicle frame.) (Ref. Fig. 4).

Assemble in the reverse order of removal.
Tighten hardware to torque values below.

Item	Torque Specification
16, 31, 23, 44	21 - 25 ft. lbs. (28 - 34Nm)
33	44 - 55 in. lbs. (5 - 6 Nm)
35	9 - 11 ft. lbs (12 - 15 Nm)

SEATING AND OPS

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Seat Cushion Disassembly

Tool List

	Qty.
Screwdriver, Flat Head	1
Staple Gun	1
Staples	A/R

1. Remove the seat back from the vehicle (See Front Seat Removal and Installation on page 73).
2. Remove the back cover (5).
3. Remove the staples (40).
4. Separate the seat back base(6) and seat cushion (7) (Ref. Fig. 6).

To assemble the seat cushion, attach it to the seat back base with new staples and attach the seat back cover.




Fig. 6 Seat Cushion

Footrest Removal and Installation

NOTICE: It is not necessary to completely remove the arm rest to remove the footrest.

Tool List

	Qty.
Socket, 9/16"	1
Socket, 7/16"	1
Socket, 5/8"	1
Ratchet	1
Wrench, 7/16"	1
Wrench, 9/16"	1
Wrench, 5/8"	1
Torque Wrench, ft. lbs.	1

1. Remove the rear closeout panel (4) (See Rear Closeout Panel Replacement on page 30)
2. Remove the bolts (36) and lock nuts that secure the footrest (24) to the armrest (Ref. Fig. 7).
3. Remove the bolts (25), flat washers (26), and lock nuts (27) to remove the footrest (24) from the vehicle (Ref. Fig. 7).

Assemble in the reverse order of removal.

Tighten hardware to torque values specified below.

Item	Torque Specification
27	62 - 68 ft. lbs. (84 - 92 Nm)




Fig. 7 Foot Rest

Seat Belt Removal and Installation

Tool List

	Qty.
Socket, 5/8"	1
Ratchet	1
Wrench, 5/8"	1
Torque Wrench, in. lbs.	1

1. Remove the bolts (46) and nuts (47) that secure the seat belt pillar loops (48) on both sides of the vehicle.
2. Remove the bolts (50) and nuts (51) to remove the seat belt retractors (49).
3. Remove the seat belt anchors (52) by removing the bolts (53) and nuts (54) (Ref. Fig. 8).

Assemble in the reverse order of removal.

Tighten the nuts to the torque values specified below.

Item	Torque Specification
47, 54	21 - 25 ft. lbs. (28 - 34 Nm)
51	45 - 55 in. lbs. (5 - 6 Nm)

SEATING AND OPS

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




Fig. 8 Seat Belt Assembly

Front Seat Belt Buckle Replacement

Tool List	Qty.
Socket, 5/8"	1
Ratchet	1
Wrench, 5/8"	1
Torque Wrench, ft. lbs.....	1

Remove the bolts (67), washers (69), and lock nuts (66) that secure the front seat belt buckle (70) to the OPS frame (Ref. Fig. 9).

Assemble in the reverse order of removal.

Tighten the nuts to the torque value specified below.

Item	Torque Specification
66	45 - 55 ft. lbs. (61 - 75 Nm)




Fig. 9 Front Seat Belt Buckle Removal

Rear Seat Belt Buckle Replacement

Tool List	Qty.
Socket, 5/8"	1
Ratchet.....	1
Wrench, 5/8"	1
Torque Wrench, ft lbs.	1

1. Remove bolts (74) and lock nuts (75) from the rear seat belt bracket (76) to remove the rear seat buckle (73) (Ref. Fig. 10).
2. To remove the rear seat belt bracket (76), remove the bolts (77), washers (78), and nuts (79) that secure the bracket to the frame (Ref. Fig. 10).

Assemble in the reverse order of removal.

Tighten the nuts to the torque values specified below.

Item	Torque Specification
75	45 - 55 ft. lbs (61 - 75 Nm)
79	21 - 25 ft. lbs. (28 - 34 Nm)

SEATING AND OPS

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




Fig. 10 Rear Seat Belt Buckle Removal

SEATING AND OPS

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

UPPER OPERATOR PROTECTION SYSTEM

Upper OPS Frame Removal and Installation

Tool List	Qty.
Ratchet	1
Allen Socket, 8mm"	1
Torque Wrench, ft. lbs.....	1

1. Remove front and rear seat belts. (See Seat Belt Removal and Installation on page 75)

WARNING The following steps involve lifting heavy and awkward objects. Two people are recommended.

Use a personal back support brace and proper lifting technique to prevent personal injury.

2. Loosen, but do not remove, the four bolts (84) fastening the forward (85) and the rear (86) sections of the upper OPS together.

3. Remove eight bolts (81) and lock nuts (82) that attach the upper OPS frame to the lower OPS frame.
4. Lift the upper OPS off of the vehicle.
5. If necessary, the forward (85) and rear (86) sections can be separated by removing the four bolts (94) and nuts (87) connecting them.

Assemble in the reverse order of removal.

Tighten the nuts to the torque values specified below.

Item	Torque Specification
81, 84	37 - 41 ft. lbs. (50 - 56 Nm)




Fig. 11 Upper OPS Removal

SEATING AND OPS

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

LOWER OPERATOR PROTECTION SYSTEM

Brush Guard Removal and Installation

Tool List	Qty.
Socket, 1/2"	1
Socket, 15mm	1
Ratchet	1
Wrench, 1/2"	1
Wrench, 15mm	1
Torque Wrench, ft. lbs.	1

1. Remove the bolts (97), flat washers (98), and lock nuts (99) to release the winch plate (96) from the brush guard (100) (Ref. Fig. 12).

2. Remove the bolts (101) and lock nuts (103) from the brush guard (100).
3. Remove the bolts (104) and lock nuts (105) to remove the brush guard (100) from the vehicle.

Assemble in the reverse order of removal.
Tighten the nuts to the torque values specified below.

Item	Torque Specification
99	15 - 19 ft. lbs. (20 - 26 Nm)
103, 105	30 - 33 ft. lbs. (41 - 45 Nm)




Fig. 12 Brush Guard Removal

SEATING AND OPS

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

OPS Lower Weldment Removal and Installation

NOTICE: Assistance may be required to remove the lower OPS weldment.

Tool List	Qty.
Ratchet	1
Socket, 10mm.....	1
Socket, 15mm.....	1
Wrench, 10mm	1
Wrench, 15mm	1
Wrench, 1/2".....	1
Torque Wrench, ft. lbs.....	1
Torque Wrench, in. lbs.....	1

1. Remove upper OPS frame from the lower OPS. (See Upper OPS Frame Removal and Installation on page 78)
2. Remove the back rest on the front seat. (See Front Seat Removal and Installation on page 73)
3. Remove the brush guard. (See Brush Guard Removal and Installation on page 79)
4. Remove the seat belts. (See Seat Belt Removal and Installation on page 75)
5. Remove the front seat belt buckle. (See Front Seat Belt Buckle Replacement on page 76)
6. Loosen, but do not remove, the bolt (111) that secures the upper portion of the lower OPS weldment (110) (Ref. Fig. 13).

11. Have an assistant to support the front of the lower OPS weldment.
12. Lift the rear of the lower OPS weldment (110) and slide it toward the rear of the vehicle to release the front bracket (115) from the bolt (111) (Ref. Fig. 13) (Ref. Fig. 14).




Fig. 13 Lower OPS Weldment (Upper Fastening)

7. Remove the top bolt (124) from the restraint panel (129).
8. Remove the two lock nuts (125), bolts (121), restraint panel (129), and bracket (128).
9. Remove the lock nuts (126) and bolts (122).
10. Remove the lock nuts (127) and bolts (123) securing the rear of the lower OPS weldment (110) (Ref. Fig. 14).

SEATING AND OPS

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




Fig. 14 Lower OPS Weldment

Assemble in the reverse order of removal.
Tighten hardware to torques values specified below.

Item	Torque Specification
124, 126	6 - 7 ft. lbs. (8 - 10 Nm)
111	15 - 19 ft. lbs. (20 - 25 Nm)
125	19 - 22 ft. lbs. (25 - 30 Nm)
127	30 - 33 ft. lbs. (40 - 45 Nm)

SEATING AND OPS

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Notes:

A large grid of graph paper for taking notes, consisting of 20 columns and 30 rows of small squares.

REAR AXLE AND SUSPENSION

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

REAR AXLE AND SUSPENSION

REAR AXLE

Maintenance

The rear axle has a plug to check and fill the lubricant level. The plug is located on the driver side at the rear of the housing. Unless leakage is found, an annual lubricant check is sufficient.

Checking the Lubricant Level

Tool List	Qty.
Allen Socket, 5/16"	1
Ratchet	1
Extension	1
Funnel	1

Clean the area around the check/fill plug (11). Remove the check/fill plug (11) (Ref. Fig. 1).

If lubricant needs to be added, remove the check/fill plug (11) and use a funnel to add lubricant (SAE 80W-90 gear oil). Add slowly until lubricant reaches capacity.

If the lubricant needs to be replaced, a drain plug (12) for removing the lubricant is located at the bottom of the differential housing.

The capacity of the axle is 13.5 oz. (410 mL).




Fig. 1 Check, Add or Drain Rear Axle Lubricant

Rear Axle Removal

Tools List	Qty.
Lug Wrench, 3/4"	1
Wheel Chocks	4
Jack Stands	4
Floor Jack	1
Socket, 17mm	1
Ratchet	1
Wrench, 17mm1	1
Torque Wrench ft. lbs.	1
Anti-seize Compound	A/R
Thread Locking Sealant (Red	A/R

WARNING To reduce the possibility of personal injury, follow the lifting procedure (See LIFTING THE VEHICLE on page 8). Place wheel chocks in front and behind each wheel not being raised and check the stability of the vehicle on the jack stands before starting any repair procedure. Never work on a vehicle that is supported by a jack alone.

1. Loosen the lug nuts (6) on the rear wheels.
2. Lift the rear of the vehicle (See Lift Rear of Vehicle on page 9).
3. Remove the rear wheels (See WHEEL AND TIRE SERVICE on page 132).
4. Remove the wheel spacer (5) from the hub assembly (2) (Ref. Fig. 2).
5. Remove the cotter pin (3) and castellated nut (4) securing the hub (2) to rear axle assembly.
6. Pull the hub (2) away from the rear axle (13).




Fig. 2 Hub Assembly

REAR AXLE AND SUSPENSION

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

7. Remove the nuts (23) and bolts (24) that secure the brake caliper mounting bracket (25) to the rear axle (13) (Ref. Fig. 3).




Fig. 3 Caliper Mounting Bracket

⚠ WARNING *The differential makes the rear axle assembly top heavy, therefore possible to rotate when separated from the springs. To reduce possibility of personal injury while removing rear axle, support differential when removing the U-bolts.*

If a lifting device is unavailable, a second person should hold the rear axle in the correct position until the bolts securing it are removed. Both people should remove the rear axle assembly.

8. Remove the motor (See Rear Motor Removal on page 70).
9. Place a floor jack under the center part of the rear axle and lift it enough to remove the weight from the springs.
10. With both the rear axle and the frame supported, remove the nuts (18), washers (17) and U-bolts (16) that secure the axle to the leaf spring assembly (15) (Ref. Fig. 4).




Fig. 4 Rear Axle Mounting

11. Lower the rear axle from the vehicle.

Rear Axle Installation

Assemble in the reverse order of removal using new lock nuts.

Tighten U-bolt lock nuts (18) to torque value specified below.

Item	Torque Specification
18	16 - 20 ft. lbs. (22 - 27 Nm)

Install the rear wheels and tighten the lug nuts (See Wheel Installation on page 126).

Bleed the brake system before installing the rear seat (See Bleeding Sequence on page 36).

REAR AXLE AND SUSPENSION

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Rear Axle Disassembly

Tool List	Qty.
Wrench, 9/16"	1
Socket, 9/16"	1
Ratchet	1
Snap Ring Pliers, Internal.....	1

1. Remove snap ring (7) from the end of the axle.
2. Remove the two ball bearings (8).
3. Remove the six bolts (9) attaching the half-shaft (13) to the rear differential (1).
4. Pull the half shaft away (13) from the differential (1) (Ref. Fig. 5).
5. Repeat the process for the opposite side of the axle.




Fig. 5 Rear Axle Disassembly

REAR SUSPENSION

NOTICE: Hardware that is removed must always be installed in its original position unless otherwise specified. If torque values are not specified, refer to the Torque Specifications table (See TORQUE SPECIFICATIONS on page 5).

Shock Absorber Removal

Tool List	Qty.
Wrench, 14mm	1
Socket, 14mm	1
Socket, 14mm, Deep Well.....	1
Extension, 3"	1
Ratchet.....	1
Floor Jack.....	1
Wheel Chock.....	2
Jack Stands.....	2

1. Remove the flip seat (See Rear Seat Removal and Installation on page 73).
2. Lift the rear of the vehicle (See Lift Rear of Vehicle on page 9).
3. Support the rear of the vehicle on the outer ends of the rear bumper.
4. Remove the bottom shock absorber nut (26), washers (28), and bushings (29) (Ref. Fig. 6).
5. Compress the shock absorber (15) to remove it from the lower bracket.
6. Remove the top shock absorber nut (27), washers (28), and bushings (29).
7. Remove the shock absorber (15) (Ref. Fig. 6).




Fig. 6 Shock Absorber

Shock Absorber Installation

Assemble in the reverse order of removal. The shock absorber nuts (26, 27) must be tightened until the shock absorber bushings (29) expand to the diameter of the shock absorber washer (28).

REAR AXLE AND SUSPENSION

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Rear Leaf Spring Removal

⚠ WARNING To reduce the possibility of personal injury, follow the lifting procedure (See **LIFTING THE VEHICLE** on page 8). Place wheel chocks in front and behind each wheel not being raised and check the stability of the vehicle on the jack stands before starting any repair procedure. Never service a vehicle that is supported by a jack alone.

NOTICE: If the rear axle is not being removed, remove and replace one spring at a time. The springs must be replaced in sets; never replace only one spring.

Tool List	Qty.
Wrench, 17mm.....	1
Wrench, 3/4".....	1
Wrench, 9/16".....	1
Socket, 17mm.....	1
Socket, 3/4".....	1
Socket, 9/16".....	1
Ratchet.....	1
Torque Wrench, ft. lbs.....	1
Floor Jack.....	1
Wheel Chocks.....	1
Jack Stands.....	4

1. Lift the rear of the vehicle (See Lift Rear of Vehicle on page 9).
2. Remove the rear wheels (See WHEEL AND TIRE SERVICE on page 126).
3. Remove the bottom shock absorber nut (26) (Ref. Fig. 6).
4. Place a floor jack under the center section of the rear axle and lift enough to put a second set of jack stands under the axle tubes.
5. With both the rear axle and the frame supported, remove the U-bolts (16).
6. Remove the bolts (23, 24), spacers (22), flanged bushing (21), shackle plates (20) and lock nuts (19, 25) (Ref. Fig. 7).
7. Remove the spring (14).

Rear Spring Installation

Assemble in the reverse order of removal.

Tighten the shock absorber nuts (26, 27) until the shock absorber bushings (29) expand to the diameter of the shock absorber washer (28) (Ref. Fig. 7).

Tighten the shoulder bolts (24), lock nuts (25), spring shackle bolts (23), lock nuts (19), and U-bolt lock nuts (19) to the torque values specified below.

Item	Torque Specification
25	18 - 23 ft. lbs. (24 - 31 Nm)
19	10 - 15 ft. lbs. (14 - 20 Nm)
18	16 - 20 ft. lbs. (22 - 27 Nm)

REAR AXLE AND SUSPENSION

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.





Fig. 7 Leaf Spring

REAR AXLE AND SUSPENSION

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Notes:

A large grid of graph paper for taking notes, consisting of 20 columns and 30 rows of small squares.

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

FAULT TESTING

SUSPENSION AND STEERING

Condition	Possible Cause	Correction
UNEVEN TIRE WEAR	Incorrect tire pressure	Inflate to recommended pressure
	Improper alignment (Incorrect toe in)	Align front tires
STIFF STEERING	Water has entered steering box and can freeze in cold conditions	Remove steering column, pinion and bearing and remove water before adding grease; Inspect gasket for good seal
	Excessive grease in steering box has moved into steering rack bellows	Raise the vehicle and observe the rack bellows while moving the steering from lock to lock Any distortion of the bellows can indicate an excess of grease has accumulated in the bellows Remove the bellows and remove excess grease
	Insufficient lubricant in king pins, tie rod ends, idler bushing, rack tensioner or steering box	Add one shot of lubricant to each grease fitting and operate steering from lock to lock. Do not over grease If steering does not return to acceptable condition, proceed to next step
	Bent rack	Remove rack and place on flat surface with rack teeth up; If a 0.015" (0.381 mm) feeler gauge will pass under the rack, the rack must be replaced
PLAY IN STEERING	Steering wheel loose	Inspect splines - replace steering wheel if required; Tighten steering wheel nut
	Steering components worn	Replace
	Loose wheel bearings	Adjust or replace
VIBRATION	Steering components worn	Replace
	Loose wheel bearings	Adjust or replace
	Out of round tires, wheels, or brake drums	Inspect and replace if out of round
STEERING PULLS TO ONE SIDE	Incorrect tire pressure	Inflate to recommended pressure
	Dragging wheel brakes	Service brake system
	Suspension component failure	Repair
	Alignment incorrect	Align

Fig. 1 Suspension and Steering Fault Diagnosis

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

CURTIS CONTROLLER

General

Use the Curtis handheld programmer for programming, fault testing, tuning, diagnosing and adjusting parameters for the speed controller and auxiliary devices (Fig. 2).



Fig. 2 Curtis Handheld Programmer

WARNING Connect the Curtis handheld programmer power cord to the Curtis programmer port only. If connected to the wrong port, voltage from other interface circuits can permanently damage the programmer.

NOTICE: The port on the passenger side is for the master controller; the port on drivers side is the slave controller.



Fig. 3 Curtis Programmer Port





Fig. 4 Curtis Programmer Port Installation

Connect the Molex plug to the receptacle on the face of the controller.

Navigation

A blinking square on the left indicates the position of the cursor.



The blinking square moves vertically when the up or down arrow on the navigation key is pressed.

Press the right arrow on the navigation key to display a column of sub-menus. Press the right arrow a second time to display more than one level of sub-menus.

Changing Data Value



Press the up or down arrow on the data value key to change the value of the parameter.

Favorites



Press a favorites (star) key for four seconds (until the favorites set screen is displayed), to set a position in the menu.

Press the appropriate favorites key to move to a selected favorites position.

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Main Menu Definitions

- PARAMETERS - Shows vehicle profile setting and adjustability.
- MONITOR - Shows vehicle real-time diagnostics.
- DIAGNOSTICS - Shows active and past faults.
- PROGRAMMING - Shows parameter setting uploads and downloads.
- SYSTEM INFO- Shows controller information.
- HHP SETTINGS- Shows handheld information and adjustment.

NOTICE: The programmer does not request confirmation before deleting fault code history. Pressing “DELETE ALL” will permanently remove any historical codes.

Menu	Submenu 1	Submenu 2	Submenu 3	Data Range	Default value	
Parameters	Reset Controller			0 - 1	0	
Monitor	Solenoid Coil			On - Off	On	
	Rear Node Select			On - Off	On	
	Solenoid PWM			0-100	0%	
	Rear Controller	Run/Tow Switch			On - Off	
		Key Switch or Charger			On - Off	Off
		Economy Mode Switch			On - Off	Off
		Forward Switch			On - Off	Off
		Reverse Switch			On - Off	Off
		Throttles	Raw Primary Throttle		0.00 - 5.00	0.73V
			Mapped Primary Throttle		0 - 1 00	0.00%
			Raw Redundant Throttle		0.00 - 5.00	0.37V
			Mapped Redundant Throttle		0 - 100	0%
	Inputs	Throttle Command			0 - 100	0%
		Mapped Throttle			0 - 100	0%
		Throttle Pot			0.00 - 5.50	0.73V
		Pot2 Raw			0.00 - 5.50	0.37V
		Interlock			On - Off	Off
		Analog 2			0.00 - 10.00	1.24V
	Outputs	5 Volts			0.00 - 6.25	4.94V
		12 Volts			0.00 - 12.00	12.42V
		Ext Supply Current			0 - 200	63mA
		Pot Low			0.00 - 6.25	0.20V
	Battery	BDI			0 - 100	75%
		Capacitor Voltage			0.0 - 105.0	3.1V
		Key Switch Voltage			0.0 - 105.0	77.0V
	Motor	Motor RPM			-12000 - 12000	0 RPM
		Temperature			-100 - 300	29 °C
		Motor Speed A			-12000 - 12000	0 RPM
Motor Speed B				-12000 - 12000	0 RPM	

Fig. 5 CURTIS Handheld Controller Main/Sub-menus

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Menu	Submenu 1	Submenu 2	Submenu 3	Data Range	Default value		
Monitor (continued)	Controller	Current (RMS)		0.0 - 1000.0	1A		
		Modulation Depth		0.0 - 100	0.00%		
		Frequency		-300.0 - 300.0	0.0Hz		
		Temperature		-100 - 300	25°C		
		Regen		On - Off	On		
		Cutbacks	Motor Temp				
			Cutback		0 - 100	100%	
			Controller Temp				
	Cutback			0 - 100	100%		
	Vehicle	Under voltage					
		Cutback		0 - 100	0%		
		Over voltage					
Cutback			0 - 100	100%			
Vehicle	Vehicle Speed			-3276.8 - 3276.7	0		
	Vehicle Odometer			0.0-10000000.0	Varies		
	Braking Distance			0.0 - 1000000.0	0		
	Distance Since Stop			0.0 - 1000000.0			
Diagnostics	Present Errors			Display active faults.			
	Fault History			Display non - active faults			
Functions	Settings	Get Settings From Controller		OK - Abort			
		Write Settings To Controller		OK - Abort			
		Reset All Settings		Yes-No			

Fig. 5 CURTIS Handheld Controller Main/Sub-menus (Continued)

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Menu	Submenu 1	Submenu 2	Submenu 3	Data Range	Default value
Controller Information	Model Number			Display the controller model number	Display the controller model number
	Serial Number			Display the controller serial number	Display the controller serial number
	Hardware Version			Display the controller hardware version	Display the controller hardware version
	Protocol Version			Display the controller protocol version	Display the controller protocol version
	Parameter Block Version			Display controller PB version	Display controller PB version
	Model Number			Display the controller model number	Display the controller model number
	Mfg. Date Code			Display controller date of manufacture	Display controller date of manufacture
	OS Version			Display controller operating system	Display controller operating system
	Build Number			Display controller OS build number	Display controller OS build number
	SM Version			Display controller SM version	Display controller SM version
	VCL App Version			Display VCL App Version	Display VCL App Version

Fig. 5 CURTIS Handheld Controller Main/Sub-menus (Continued)

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Menu	Submenu 1	Submenu 2	Submenu 3	Data Range	Default value
HHP Settings	Program	LCD Contract	-300		0
		Language		English	English
		Set Security Code		Set user lock code	
	Faults	Fault History		Display fault history of HANDHELD	
		Clear Fault History		Yes/No	
	Information	OEM Info		Display OEM information	
		*Reconfigured		Display reconfigure status	
		Model Number		Display handheld model number	
		Serial Number		Display handheld serial number	
		Manufacturing Date		Display handheld manufacture date	
		Software Version		Display handheld software version	
		Hardware Version		Display handheld hardware version	
		MC-Protocol Version		Display MC-Protocol version	
		ES-Protocol Version		Display ES-Protocol version	
		S-Protocol Version		Display S-Protocol version	
	Device Type		Display device type		

Fig. 5 CURTIS Handheld Controller Main/Sub-menus (Continued)

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Fault Code Chart

DIAGNOSTICS: Diagnostics information can be obtained by two methods:

- by reading the display on a 1313 programmer or
- by observing the fault codes issued by the Status LEDs on the top of each of the controllers.

The 1313 programmer displays all faults that are currently set, as well as a history of the faults that have been set since the history log was last cleared. The 1313 displays

the faults by name.

The pair of LEDs built into the controller (one red, one yellow) produce flash codes that display all the currently set faults in a repeating cycle. Each code has two digits. The red LED flashes once to indicate that the first digit of the code will follow; the yellow LED then flashes the appropriate number of times for the first digit. The red LED flashes twice to indicate that the second digit of the code will follow; the yellow LED flashes the appropriate number of times for the second digit.

Example: Battery Undervoltage (code 23).

In the Diagnostics menu of the 1313 programmer, the words “Undervoltage Cutback” will be displayed; the real-time battery voltage is displayed in the Monitor menu / Battery sub-menu: (“Keyswitch Voltage”).

The controller’s two LEDs will display this repeating pattern:



Fig. 6 Summary of LED Display Formats

The numerical codes used by the yellow LED are listed in the fault diagnosis chart, which also lists possible fault causes and describes the conditions that set and clear each fault.

The two LED’s have four different display modes that indicate the type of information they provide.

TYPES OF LED DISPLAY	
DISPLAY	STATUS
Neither LED illuminated	Controller is not powered on; or vehicle has dead battery; or severe damage.
Yellow LED flashing	Controller is operating normally.
Yellow and red LEDs both on solid	Controller is in Flash program mode.
Red LED on solid	Watchdog failure or no software loaded. Cycle KSI to restart, and if necessary load software.
Red LED and yellow LED flashing alternately	Controller has detected a fault. 2-digit code flashed by yellow LED identifies the specific fault; one or two flashes by red LED indicate whether first or second code digit will follow.

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

LED Code	1313 Display	Explanation	Controller Response	Recover When	Possible Cause
1-2	Controller Over current	Phase Current exceeded current limits	Vehicle Disabled	KSI Cycled	<ol style="list-style-type: none"> 1.External short of phase U,V or W 2.Check wiring 3.Motor parameters are mis-tuned 4.Defective controller 5.Speed encoder noise problems
1-3	Current Sensor Fault	Controller current sensors have invalid offset reading	Vehicle Disabled	KSI Cycled	<ol style="list-style-type: none"> 1.Short to car frame from phase U,V or W. 2.Controller defective
1-4	Precharge Failed	Capacitor bank failed to charge at KSI voltage	Vehicle Disabled	Cycle interlock	<ol style="list-style-type: none"> 1.See handheld monitor menu - battery: capacitor voltage 2.External load on capacitor bank preventing capacitor charge 3.Check wiring 4.Check brake sensor if other faults are found
1-5	Controller Sever Undertemp	Heat sink temperature below -40°C	Vehicle Disabled	Raise controller temp to above -40°C and cycle KSI or interlock	<ol style="list-style-type: none"> 1.Controller is operating in an extreme environment 2.See monitor menu - controller: temperature
1-6	Controller Sever Over temp	Heat sink temperature above +95°C	Vehicle Disabled	Reduce heat sink temperature below 95°C and cycle KSI or interlock	<ol style="list-style-type: none"> 1.Controller is operating in an extreme environment 2.See monitor menu - controller: temperature 3.Excessive load on vehicle 4.Improper mounting of controller
1-7	Severe Under voltage	Capacitor voltage dropped below limit	Reduced Drive torque and speed	Condition clears	<ol style="list-style-type: none"> 1.Battery menu parameters are mis adjusted 2.Non-controller system drain on batteries 3.Battery resistance too high 4.Battery disconnected while driving 5.See monitor menu - Battery: capacitor voltage 6.Blown B+ fuse or main contactor did not close

Fig. 7 Fault Code Chart

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

LED Code	1313 Display	Explanation	Controller Response	Recover When	Possible Cause
1-8	Severe Overvoltage	Capacitor bank voltage exceeded limit	Vehicle Disabled	Condition clears and KSI cycled	<ol style="list-style-type: none"> 1. See monitor menu-Battery: capacitor voltage 2. Battery menu parameters are mis-adjusted 3. Battery resistance too high for given regen current 4. Battery disconnected while regen braking
2-2	Controller Over temp Cutback	Heat sink temp exceeded 85°C	Reduced drive and brake torque	Condition clears	<ol style="list-style-type: none"> 1. See monitor menu-Controller: temperature 2. Controller is performance-limited at this temperature 3. Controller is operating in an extreme environment 4. Excessive load on vehicle
2-3	Under voltage Cutback	Capacitor bank voltage dropped below limit	Reduced Drive torque and speed	Condition clears	<ol style="list-style-type: none"> 1. Normal operation. Fault shows that batteries need recharging 2. Battery parameters are mis-adjusted 3. Non-controller system drain 4. Battery resistance too high 5. Battery disconnected while driving 6. See Monitor menu-Battery: capacitor voltage 7. Blown B+ fuse or main contactor did not close
2-4	Overvoltage Cutback	Capacitor bank voltage exceeded Overvoltage limit	Reduced brake torque	Condition clears	<ol style="list-style-type: none"> 1. Normal operation. Fault shows that the regen braking currents elevated the battery voltage during regen braking. Controller is performance limited at this voltage 2. Battery parameters are mis-adjusted 3. Battery resistance too high for given regen current 4. Battery disconnected while regen braking 5. See Monitor menu - Battery: ca (capacitor voltage)
2-5	+5V supply Failure	+ 5 V supply (pin 26) outside the +5V + or - 10% range	None: Check VCL	Condition clears	<ol style="list-style-type: none"> 1. External load impedance on the + 5 V supply is too low 2. See Monitor menu-Outputs: 5 volts and ext supply current
2-6	Digital Out Over current	Digital output 6 (pin 19) current exceeded 15mA	None: Check VCL	Fix the over current cause and use the VCL function set dig out to turn driver on again	<ol style="list-style-type: none"> 1. External load impedance on Digital Output 6 (pin 19) is too low

Fig. 7 Fault Code Chart (Continued)

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

LED Code	1313 Display	Explanation	Controller Response	Recover When	Possible Cause
2-7	Digital Out 7 Over current	Digital output 7 (pin 20) current exceeded 15mA	None: Check VCL	Fix the over current cause and use the VCL function set dig Out() to turn driver on again	1.External load impedance on Digital Output 7 (pin 20) is too low
2-8	Motor Temp Hot Cutback	Motor temp is at or above Hot parameter setting	Reduced Drive torque and speed	Condition clears	1.Motor temperature is at or above the programmed temperature Hot setting, and the requested current is being cut back 2.Motor temperature control menu parameters are mis-tuned 3.See Monitor menu-Motor: temperature and - Inputs: analog 2 4.Reduce load on motor
2-9	Motor Temp Sensor Fault	Motor thermistor input (pin8) is at voltage rail (0 or 10v)	Reduced speed, Motor temp cutback disabled	Condition clears	1.Motor thermistor is not connected 2.Check sensor
3-1	Coil 1 Driver Open or Short - also can be Main Open or Short	Driver 1 (pin6) is either open or shorted. This fault can only be set when main enable =off	Shutdown driver 1	Correct condition and cycle driver	1.Open or short on driver load 2.Dirty connector pins 3.Bad crimps or faulty wiring
3-2	Coil 2 Driver Open or Short	Driver 2 (pin5) is either open or shorted. This fault can only be set when main enable =off	Shutdown driver 2	Correct condition and cycle driver	1.Open or short on driver load 2.Dirty connector pins 3.Bad crimps or faulty wiring
3-3	Coil 3 Driver Open or Short	Driver 3 (pin4) is either open or shorted. This fault can only be set when main enable =off	Shutdown driver 3	Correct condition and cycle driver	1.Open or short on driver load 2.Dirty connector pins 3.Bad crimps or faulty wiring
3-4	Coil 4 Driver Open or Short	Driver 4 (pin3) is either open or shorted. This fault can only be set when main enable =off	Shutdown driver 4	Correct condition and cycle driver	1.Open or short on driver load 2.Dirty connector pins 3.Bad crimps or faulty wiring

Fig. 7 Fault Code Chart (Continued)

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

LED Code	1313 Display	Explanation	Controller Response	Recover When	Possible Cause
3-5	PD Open or Short	The Proportional driver (pin2) is either open or shorted. This fault can only be set when main enable =off	Shutdown PD driver	Correct condition and cycle driver	1.Open or short on driver load 2.Dirty connector pins 3.Bad crimps or faulty wiring
3-6	Encoder Fault	Motor encoder phase failure detected.	Throttle Shutdown	KSI cycled	1.Motor encoder failure 2.Bad crimp or faulty wiring 3.See Monitor menu - Motor: motor rpm
3-7	Motor Open	Motor Phase U,V or W detected open	Vehicle Disabled	KSI cycled	1.Motor phase is open 2.Bad crimps or faulty wiring
3-8	Main Contactor Welded	Prior to main contactor closing, capacitor bank voltage was loaded for a short time and did not discharge	Vehicle Disabled	KSI cycled	1.Main contactor tips are welded closed 2.Motor phase U or V is disconnected or open 3.An alternate voltage path is providing a current to the capacitor bank (B+ connection terminal)
3-9	Main Contactor Did Not Close	With the main contactor commanded closed, the bank voltage (B+ connection terminal) did not charge to B+	Vehicle Disabled	KSI cycled	1.Main contactor did not close 2.Main contactor tips are oxidized, burned, or not making a good contact 3.External load on capacitor bank (B+ connection terminal) that prevents capacitor bank from charging 4.Blown B+ fuse
4-1	Throttle Wiper High	Throttle pot wiper (pin16) voltage is higher than high fault setting	Shutdown throttle	Condition clears	1.See Monitor menu-Inputs: throttle pot 2.Throttle pot wiper voltage too high
4-2	Throttle Wiper Low	Throttle pot wiper (pin16) voltage is lower than low fault setting	Shutdown throttle	Condition clears	1.See Monitor menu-Inputs: throttle pot 2.Throttle pot wiper voltage too low
4-3	Pot 2 Wiper High	Pot 2 wiper (pin17) voltage is higher than high fault setting	Full Brake	Condition clears	1.See Monitor menu-Inputs: pot2 raw 2.Pot2 wiper voltage too high
4-4	Pot 2 Wiper Low	Pot 2 wiper (pin17) voltage is lower than low fault setting	Full Throttle	Condition clears	1.See Monitor menu-Inputs: pot2 raw 2.Pot2 wiper voltage too low
4-5	Pot Low Over current	Pot low (pin 18) current exceeds 10mA	Shutdown Throttle and full Brake	Condition clears and KSI cycled	1.See Monitor menu-Outputs: pot low 2.Combined pot resistance connected to pot low is to low

Fig. 7 Fault Code Chart (Continued)

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

LED Code	1313 Display	Explanation	Controller Response	Recover When	Possible Cause
4-6	EEPROM Failure	Controller operating system tried to write to EEPROM memory and failed	Vehicle Disabled	Download correct software (OS) and matching parameter default settings into the controller and c	1.Failure to write to EEPROM memory. This can be caused by EEPROM memory writes initiated by VCL, by the CAN bus, by adjusting parameters with the programmer, or by loading new software into controller
4-7	HPD/ Sequencing Fault	HPD sequencing fault caused incorrect sequence of KSI, interlock, direction and throttle input	Shutdown Throttle	Reapply inputs in correct sequence	1.KSI, interlock, direction and throttle inputs applied in incorrect sequence 2.Faulty wiring, crimps, or switches at KSI, interlock, direction, or throttle inputs. 3.See Monitor menu-Inputs
4-8	Emer Rev HPD	At the conclusion of Emergency Reverse, the fault was set because various inputs were not returned to neutral	Shutdown Throttle	If EMR_interlock=On, clear the interlock, throttle and direction inputs. If EMR_Interlock=Off, clear the throttle and direction inputs.	1.Emergency Reverse operation has concluded, but the throttle, forward and reverse inputs, and interlock have not been returned to neutral
4-9	Parameter Change Fault	Adjustment of a parameter setting that requires cycling of KSI	Vehicle Disabled	KSI cycled	1.This is a safety fault caused by a change in certain parameter settings so that the vehicle will not operate until KSI id cycled
5-2	Traction Throttle Mismatch	Throttle input/output mismatched	Throttle Shutdown	Condition Clears	1.See Monitor menu-Inputs: Throttle 2.Check throttle return
5-3	Throttle Input Out of Range	Throttle input out of range	Throttle Shutdown	Condition Clears	1.See Monitor menu-Inputs: Throttle 2.Check throttle return 3.Check for water intrusion of throttle wiper
5-4	Park Brake Set	Park brake engaged when traction pedal was activated	Throttle Shutdown	Condition cleared	1.Park brake was engaged when throttle was activated 2.Release park brake and operate unit 3.Check park brake switch

Fig. 7 Fault Code Chart (Continued)

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

LED Code	1313 Display	Explanation	Controller Response	Recover When	Possible Cause
5-5	HPD/SRO Fault	High pedal disable/ static return to off	Vehicle Disabled	Condition cleared. Correct start sequence applied	1. Verify correct start sequence. Unit must be in neutral prior to key on
5-6	Solenoid Coil Open/Short	Driver does not turn OFF	Vehicle Disabled	KSI cycled	1. Open or short on driver load 2. Dirty connector pins 3. Bad crimps or faulty wiring 4. When found in history, does not necessarily indicate a problem
6-8	VCL Run Time Error	Runtime VCL code error condition	Vehicle Disabled	KSI cycled or install new software to match parameters	1. VCL code encountered a runtime VCL error 2. See Monitor menu -Controller: VCL error module
6-9	External Supply out of Range	The external 5v and 12V supply is out of range.	None: Check VCL	External supply current within range	1. External load on the 5V and 12V supplies draws either too much or too little current 2. Fault checking menu parameters Ext supply max and Ext. supply min are mis tuned 3. See Monitor menu-Outputs: ext supply current
7-1	OS General	Internal controller fault detected	Vehicle Disabled	KSI Cycled	1. Internal controller fault detected 2. Cycle KSI
7-2	PDO Timeout	Time between CAN PDO messages received exceeded the PDO timeout period	Shutdown Interlock. Set CAN NMT state to pre-operational	Cycle KSI or Cycle F&R	1. Time out period exceeded because of no inputs from throttle or controls 2. Cycle KSI and or F&R switch
7-3	Stall Detected	No Motor encoder movement detected	Vehicle Disabled	Cycle KSI	1. Stalled motor 2. Motor encoder failure 3. Bad crimps or faulty wiring 4. Problems with power supply for the motor encoder 5. See Monitor menu-Motor: motor rpm
7-4	Fault on Other Traction Controller	Fault found on slave controller	Depends on fault	KSI cycled	1. Check slave controller faults with handheld via direct connection to slave controller
7-5	Dual Severe Fault	Severe fault found on slave controller	Vehicle Disabled	KSI cycled	1. Check slave controller faults with handheld via direct connection to slave controller

Fig. 7 Fault Code Chart (Continued)

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

LED Code	1313 Display	Explanation	Controller Response	Recover When	Possible Cause
8-7	Motor Characterization Fault	Motor Characterization failed during motor characterization process	Vehicle Disabled	KSI cycled or fault corrected	<ol style="list-style-type: none"> Motor characterization failed during MC process. See Monitor menu - Controller: motor characterization error for cause: <ul style="list-style-type: none"> 0=none 1=encoder signal seen, but step size not determined: set encoder step size manually 2=motortempsensorfault 3=motor temp hot cutback fault 4=controller over temp cutback fault 5=controller under temp cutback fault 6=under voltage cutback fault 7=severe over voltage fault 8=encoder signal not seen, or one or both channels missing 9=motor parameters out of characterization range
8-9	Motor Type Fault	Motor type parameter value is out of range	Vehicle Disabled	KSI cycled and or correct fault	<ol style="list-style-type: none"> Motor Type parameter value is out of range Check controller command on hand held
9-1	VCL/OS Mismatch	VCL and OS software do not match, when Ski is cycled a check is made to verify that they match and a fault is issued when they do not	Vehicle Disabled	Condition clears	<ol style="list-style-type: none"> The VCL software in the controller does not match the OS software in the controller- re-install software
9-3	Encoder LOS (limited operating strategy)	Encoder fault(code36) or stall detect fault (code73) was activated and brake or interlock has been applied to activate LOS control mode, allowing limited motor control	Vehicle Disabled	KSI Cycled or Fault cleared	<ol style="list-style-type: none"> Limited Operating Strategy control mode has been activated, as a result of either an encoder fault or stall detect fault Motor encoder failure Bad crimps or faulty wiring Motor stalled
9-4	EMER Rev Timeout	Emergency reverse was activated and ran until the EMR timeout timer expired.	Throttle Shutdown	Condition clears	<ol style="list-style-type: none"> Emergency reverse was activated and concluded because of EMR timeout The emergency reverse input is stuck on

Fig. 7 Fault Code Chart (Continued)

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

LED Code	1313 Display	Explanation	Controller Response	Recover When	Possible Cause
9-8	Illegal Model Number	Model Number variable, cycles a check is made to confirm a legal model number is found, a fault is issued if not	Vehicle Disabled	Appropriate software downloaded	<ol style="list-style-type: none"> 1. Model number variable is illegal for controller type 2. Software and hardware do not match 3. Defective controller
9-9	Dual motor Parameter Mismatch	Mismatch of front and rear motors	Vehicle Disabled	Condition clears	<ol style="list-style-type: none"> 1. Check Wires and connections 2. Check for mechanical bind 3. Check for high mechanical load 4. Verify motor encoder 5. Check faults on handheld for both controllers

Fig. 7 Fault Code Chart (Continued)

Curtis Handheld Diagnostic Tool Function



The first screen shown is the menu options list.

The “System Info” menu indicates detailed viewing of the controller information, such as model number, serial number, hardware version, protocol version, parameter block version, mfg date code, OS version, build number, SM version, and VCL application version.


Fig. 8 Handheld Tool Function

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




The "Parameters" menu selection does not have a controller program option. The default parameter is 0.




"Reset Controller" is the view of the reset controller function. Normal values are 0 or 1.



The "Monitor" menu selection shows controller functions, inputs, and outputs.



"Solenoid Coil" indicates power to the main solenoid.




"Rear Node Select" shows the rear controller command. It indicates on or off.

Fig. 8 Handheld Tool Function (Continued)

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.



“Solenoid PWM” shows the % of solenoid command. It shows 100% when the controller is on.



“Rear Controller” allows access to a sub menu to see rear controller inputs. The front controller is a SLAVE controller, and is controlled by the rear controller.

The rear controller sub-menu shows the run/tow switch input, key switch input, economy or max range – max speed switch input, forward input and reverse input.




Each sub menu screen of the inputs allow for viewing larger text.

“Run/Tow Switch”



“Key or Charger Switch”



“Economy Mode Switch”



“Forward Switch”


Fig. 8 Handheld Tool Function (Continued)

FAULT TESTING


Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




“Reverse Switch”



“Throttles” is the only sub-menu below the “Rear Controller” sub-menu. This selection indicates throttle voltage range and % of throttle travel.



“Raw Primary Throttle”



“Mapped Primary Throttle”




“Raw Redundant Throttle”


Fig. 8 Handheld Tool Function (Continued)

FAULT TESTING


Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




“Mapped Redundant Throttle”




View “Inputs” from the input menu and the sub-menus.



“Throttle Command” shows the % of throttle requested at the accelerator pedal. Values should range from 0 – 100%.



“Mapped Throttle” shows the mapped throttle request and changes from 0 – 100% with accelerator pedal travel.



“Throttle Pot” (pin 16) and “Pot 2 Raw” (pin 17) indicate the voltage values from 0 – 6.25V. This changes with throttle activation.






Fig. 8 Handheld Tool Function (Continued)

FAULT TESTING


Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




“Interlock” input on or off. The interlock turns on or off with key switch activation.




“Analog 2” shows the voltage at analog 2 (pin8). This value changes from 0 – 10V. This particular input determines the motor temperature readings.



The “Outputs” sub-menu shows the controller outputs and their sub-menus.



“5 Volts” shows the voltage at + 5 volt output (pin26). This circuit determines speed and throttle sensors.



“12 Volts” shows the voltage at +12 volt output (pin 25). This circuit determines the rear serial (data) port, key switch, and SOC meter.




“Ext. Supply Current” shows the combined current of the external + 12 volt and + 5 volt supplies (pins 25 and 26)


Fig. 8 Handheld Tool Function (Continued)

FAULT TESTING


Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




“Pot Low” shows the voltage at pot low. This value ranges between 0 – 6.25V.




The “Battery” sub-menu indicates state of charge (BDI), capacitor voltage, and KSI voltage.




“BDI” (battery discharge indicator) indicates the state of charge percentage.



“Capacitor Voltage” is the voltage of a controller’s internal capacitor bank at the B+ terminal.



“Keyswitch Voltage” is the voltage at KSI (pin1).




The “Motor” sub-menu indicates motor conditions and component inputs.


Fig. 8 Handheld Tool Function (Continued)

FAULT TESTING


Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.



“Motor RPM” equals speed in revolutions per minute.




“Temperature” is measured in Celsius.



“Motorspeed A” shows the motor encoder phase A speed in revolutions per minute.

Use to verify that phase A of the encoder is operating correctly.


Motor speed A should equal Motor speed B in a properly operating power train.




“MotorSpeed B” shows the motor encoder phase B speed in revolutions per minute.

Use to verify that phase B of the encoder is operating correctly.

Motor speed B should equal Motor speed A in a properly operating power train.



The controller operation can be seen in the “Controller” sub-menu.




“Current (RMS)” shows the RMS current of the controller, taking in all three phases into account (amp draw).


Fig. 8 Handheld Tool Function (Continued)

FAULT TESTING


Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.



“Modulation Depth” shows the percentage of available voltage being used.




Frequency” shows the controller electrical frequency.




“Temperature” indicates the internal controller temp.



“Regen” shows regenerative braking and activates when the brake pedal is pressed. Regen deactivates when the pedal is released.



The “Cutbacks” sub-menu selection shows voltage reductions.




“Motor Temp Cutback” displays the current available as a result of the motor temperature cutback function. A value of 100% indicates NO cutbacks.


Fig. 8 Handheld Tool Function (Continued)

FAULT TESTING



Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




“Controller Temp Cutback” shows the current available as a result of the controller temperature cutback function. A value of 100% indicates no cutback in current.



“Overvoltage Cutback” or “Undervoltage Cutback” indicates the current available as a result of the condition. A value of 100% indicates no cutback in current.



The “Vehicle” sub-menu selection shows vehicle drive operations.



“Vehicle Speed” indicates vehicle speed in units of MPH. For accurate speed estimates, the speed to RPM parameters must be set correctly.




“Vehicle Odometer” indicates vehicle distance traveled in units of miles. For accurate distance measurements, the speed to RPM parameters must be set correctly.

Fig. 8 Handheld Tool Function (Continued)

FAULT TESTING


Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.




“Braking Distance Captured” indicates the distance traveled by the vehicle starting with the vehicle braking (initiated by throttle reversal, brake pot, VCL Brake, or interlock braking) and ending when the motor RPM = 0. Units are measured in feet.




“Distance Since Stop” shows the distance traveled by the vehicle starting from a stop. In effect, the vehicle is used as a tape measure. In other words if you travel 300 feet in forward and then 300 feet in reverse the distance would be 600 feet. The distance is continuously updated and will stop and restart when motor RPM = 0



“Diagnostics” is the next menu selection that can be viewed. If a fault is detected at the time of testing, it will be viewed under “Present Errors.” See Menu Guide for a list of faults.



“Present Errors” will show any active faults.




“Fault History” shows faults encountered by the controller in the past. Specifics of when the fault occurred in run time hours can be viewed by selecting each fault directly.

Fig. 8 Handheld Tool Function (Continued)




FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.



The "Programming" menu allows the technician to upload settings from one controller (Save .cpf File) and then to download the same settings to another controller (Restore .cpf File). This is referred to as Cloning.

The cloning function is not allowed by Non-OEM handhelds.



The "HHP Settings" menu indicates user defined settings for the handheld, LCD screen settings, language settings as well as a user defined security code.




Fig. 8 Handheld Tool Function (Continued)

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

ELECTRICAL FAULT TESTING

Front - Slave and Rear - Master




Fig. 9 Front - Slave and Rear - Master

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Controller Location and Mounting Configuration




Fig. 10 Controller Location and Mounting Configuration

COMPONENT TESTING

Voltmeter

⚠ WARNING Before performing any test of wiring components, disconnect the battery cables from the battery posts to prevent electrical shock or explosion.

Electrical tests of the wiring for continuity can be done with a DVOM (Digital Volt Ohm Meter), available through the Service Parts Department (P/N 27481G01). The actual model can vary depending on availability. The DVOM (digital volt ohm meter) shown in Figure 10, is rep-

resentative only. Any DVOM can be used, however the controls, displays and features can vary depending on the make and model. Always follow the meter manufacturer's recommendations and instructions for the use and care of meter. For the purpose of this section, the red probe as (+) and black probe as (-) are used. Set the meter selector to the ohms scale, and check continuity between each circuit component as indicated.

Example: If a switch is open or if there is a break in the wiring, the meter will display a visual signal. If an analog meter is used, it will read infinity (∞).

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.



Fig. 11 Digital Voltmeter

Fuses - Testing

Check all the fuses to make sure that components are properly powered (Ref. Fig. 12). If the fuse is blown, replace the fuse.





Fig. 12 Fuse Block

NOTICE: To test the components on the gauge panel, the gauge panel has to be removed to access the individual component circuit terminals (See "Gauge Panel Replacement" on page 24).

Key Switch - Testing

Use the handheld diagnostic tool to verify operation of the key switch and the direction selector. See the inputs on the monitor menu. Operate the switch or selector to change its status. This will confirm a failed switch or a bad circuit.



Fig. 13 Key Switch




Fig. 14 Circuit Pins

NOTICE: This test can also be done with the handheld tool. Scroll down to the direction functions in the Monitor Menu.

If a handheld programmer is not available, the key switch can be tested for continuity using a DVOM (See "Electrical Schematic" on page 41).

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

State of Charge (SOC) Meter - Testing

Put the positive (+) meter probe on the F terminal (red w/ blue wire) and the negative probe of DVOM on the A terminal (black wire) of the SOC meter (Fig. 15). Voltage should be 8-20V. If not; check the batteries and harness.

The B terminal (green wire) is a .4 – 4.5V circuit that will range with state of charge.




Fig. 15 SOC Meter




Fig. 16 Solenoid

Electronic Speed Controller Solenoid - Testing

To check the electronic speed controller solenoid for energy; follow the steps below:

1. Put the positive meter probe on the white wire primary circuit terminal. Put the negative meter probe on the black / orange primary circuit terminal. 72V should be indicated on the meter with the key on and the direction selector in gear.
2. Put the negative meter probe on controller B or the negative 72V battery terminal. Put the positive probe on the secondary circuit battery side terminal. 72V should be indicated. If not, check battery voltage and wiring.

NOTICE: The solenoid testing can also be done with the handheld tool. Scroll down to the Monitor Menu. Check inputs and outputs for change in status. Check for contactor related faults in the faults menu.

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Temperature Sensor - Testing

NOTICE: If the temperature sensor is faulty, the entire motor assembly must be replaced (See “Front Motor Removal” on page 68) (See “Rear Motor Removal” on page 70).

1. If possible, allow the vehicle to cool to room temperature.
2. Unplug the temperature sensor harness at the motor (Ref. 2.)
3. Use the DVOM set on OHMS () and test the resistance between the two pins on the motor side.




Fig. 17 Temperature Sensor

4. A reading showing at or below the minimum value indicates a bad sensor.
5. A reading showing at or above the thermal cutoff temperature indicates either a faulty sensor or a severely overheating motor (Ref. Fig. 18) (Ref. Fig. 19).

Minimum Value	359 (-40° C)
Room Temperature	603 (25° C)
Beginning of Thermal Cutback	1297 (145° C)
Thermal Cutoff Temperature	1407 (160° C)


Fig. 18 KTY Temperature Sensor (male pins on the connector)

Minimum Value	843 (-40° C)
Room Temperature	962 (25° C)
Beginning of Thermal Cutback	1555 (145° C)
Thermal Cutoff Temperature	1610 (160° C)

Fig. 19 PT1000 Temperature Sensor (female pins on the connector)

Electronic Speed Sensor - Testing

1. Use the DVOM probes to check the motor speed sensor while the connector is plugged in. With the key on and the direction selector in gear; put the positive meter probe in the red wire connection. Put the negative meter probe in the black wire connection. 5V should be indicated. If not, check the wiring and the signal from the controller. Replace the speed sensor if these are good.
2. Put the negative meter probe in the black wire connection. Put the positive meter probe in the green wire connection. A 0 – 5V flash signal should be indicated when the motor armature is rotated slowly. If not, check the sensor magnet in the motor, then replace the speed sensor.



FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.



Fig. 20 Speed Sensor

Back probe pins are needed to perform electrical tests via wire harness connectors.

AC Motor Bench Test

Set a standard digital volt/ohm meter to the diode test position. Make sure the audible alarm can be heard.

1. Place one meter probe on the U-terminal and the other probe on the W-terminal. Full continuity should be observed (Ref. Fig. 21).



Fig. 21 U and W terminal

2. Now place one meter probe on the V-terminal and the other probe on the W-terminal. Full continuity should be observed (Ref. Fig. 22).



Fig. 22 V and W terminal

3. Then place one meter probe on the U-terminal and the other probe on the V-terminal. Full continuity should be observed (Ref. Fig. 23).



Fig. 23 U and V terminal

NOTICE: If continuity is not observed between terminals; an open motor field condition may exist. Disassemble the motor to visually confirm.

4. Place one meter probe on any of the three motor terminals. The other meter probe should be placed on the motor case. No continuity should be observed (Ref. Fig. 24).

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

NOTICE: If continuity is observed between the case and terminals; a field to motor case short exists.




Fig. 24 Terminal and Motor case

FAULT TESTING

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Notes:

A large grid of graph paper for taking notes, consisting of 20 columns and 30 rows of small squares.

WEATHER PROTECTION

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

WEATHER PROTECTION

GENERAL

⚠ WARNING *The canopy top does not provide protection from roll over or falling objects.*

The windshield does not provide protection from tree limbs or flying objects.

The canopy top and windshield are for weather protection only.

Clean with water and a clean cloth. Remove minor scratches with a commercial plastic polish or Plexus plastic cleaner, available from the service parts department.

Transporting Vehicle

⚠ WARNING *To prevent personal injury to occupants of other highway vehicles, be sure that the vehicle and contents are secured to trailer.*

Do not ride on a vehicle being transported.

Remove the windshield before transporting.

Maximum speed with the canopy top installed is 24 mph (39 kph).

If the vehicle is being transported on a trailer at highway speeds, remove the windshield and canopy top and secure the seat bottoms. Always check that the vehicle and contents are secured before transporting the vehicle. The rated capacity of the trailer must be more than the weight of the vehicle (See VEHICLE SPECIFICATIONS on page 129).

CANOPY TOP

Canopy Top Removal

Tool List	Qty.
Allen Socket, 4mm.....	1
Ratchet	1

Remove the screws (2) and washers (3) from the clamps (4) to release the canopy top (1) from the upper OPS (5) (Ref. Fig. 1).

Assemble in the reverse order of removal.





Fig. 1 Canopy Top

WEATHER PROTECTION

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.


Notes:

A large grid of graph paper for taking notes, consisting of 20 columns and 30 rows of small squares.

WHEELS AND TIRES

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

WHEELS AND TIRES



Valve stem should always be to outside of the wheel.

Always replace the dust cap.




Fig. 1 Wheels and Tires

WHEELS AND TIRES

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

WHEEL AND TIRE SERVICE

Tool List	Qty.
Lug Wrench, 3/4".....	1
Impact Wrench.....	1
Impact Socket, 3/4".....	1
Torque Wrench, ft. lbs.	1

WARNING To prevent injury caused by a broken socket, use only sockets made for impact wrench use. Never use a conventional socket.

When the tires are cool, inspect the condition and inflation pressures per the Periodic Service Schedule. Always install the valve dust cap after checking or inflating. When removing wheels with an impact wrench, use only impact sockets. Regular sockets are not designed for impact pressures exerted by power tools.

WARNING A tire explosion can cause severe injury or death. Never exceed inflation pressure rating on tire side wall.

To prevent a tire explosion, pressurize the tire with a small amount of air applied intermittently to seat beads. Never exceed the tire manufacturers recommendation when seating a bead. Protect face and eyes from escaping air when removing the valve core.

Use caution when inflating tires. Due to the low volume of the small tires, over inflation can occur in seconds. Over inflation could cause the tire to separate from the wheel or the tire to explode, either of which could cause personal injury.

Tire inflation depends on the type of tires installed, but under no condition should inflation pressure be higher than recommended on the tire sidewall. Standard and optional tires should be inflated to the pressure designated on the tire sidewall. All four tires should have the same pressure for optimum handling characteristics. Do not over inflate. Due to the low volume of the small tires, over inflation can occur in seconds. Install the valve dust cap after checking or inflating.

Tire Repair

The vehicle is fitted with low-pressure tubeless tires mounted on one piece rims.

The most cost effective way to repair a flat tire with a puncture in the tread portion of the tire is to use a tire plug.

NOTICE: Tire plug tools and plugs are available at most automotive parts stores and do not require the tire be removed from the wheel.

If the tire is flat, lift the vehicle and remove the wheel.

1. Lift the vehicle according to the lifting procedure (See LIFTING THE VEHICLE on page 8).
2. Put the tire in water to find the leak, and mark with chalk.
3. Insert the tire plug in accordance with manufacturers specifications.

If the tire is being removed or mounted, the tire-changing machine manufacturers recommendations must be followed to minimize the possibility of personal injury.

WARNING To prevent injury, be sure the mounting/demounting machine is anchored to the floor. Wear OSHA approved safety equipment when mounting/demounting tires.

Follow all instructions and safety warnings provided by the mounting/demounting machine manufacturer.

Wheel Installation

CAUTION Do not tighten lug nuts to more than 75 ft. lbs. (102 Nm) torque.

NOTICE: Use the 'cross sequence' pattern when installing lug nuts to ensure even seating of the wheel against the hub.

1. With the valve stem to the outside, mount the wheel onto the hub with lug nuts.
2. Position the wheel on the hub.
3. Finger tighten the lug nuts in a 'cross sequence' pattern (Ref. Fig. 1).
4. Lower the vehicle onto the ground.
5. Continue to tighten the lug nuts to the torque value specified below, in 20 ft. lbs. (27 Nm) increments, following the same 'cross sequence' pattern.

Item	Torque Specification
Lug Nut	65 - 75 ft. lbs. (88 - 102 Nm)

WHEELS AND TIRES

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.


Notes:

A large grid of graph paper for taking notes, consisting of 20 columns and 30 rows of small squares.

WHEELS AND TIRES

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Notes:

A large grid of graph paper for taking notes, consisting of 20 columns and 30 rows of small squares.

VEHICLE SPECIFICATIONS

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

VEHICLE SPECIFICATIONS


Tracker EV

Item	Specification
Overall Length	111 in (28 cm)
Overall Width	52 in (132 cm)
Overall Height	76 in (193 cm)
Wheelbase	9 in (178 cm)
Ground Clearance at Frame	16 in (42 cm)
Ground Clearance at Differential	10 in (25 cm)
Power Source	72 Volts DC
Motor Type	72 Volt AC
Horsepower (kW)	38 hp (28.3 kW) Peak
Electrical System	72 Volt
Battery Quantity and Type	Six 12V Deep Cycle
Key or Pedal Start	Pedal Start
Battery Charger	72 VDC DPI, 120 VAC 60 Hz
Speed Controller	300 Amp AC Controller
Drive Train	Motor Shaft Direct Drive
Trans-axle	Differential w/ Hardened Helical Gears
Gear Selection	Dash mounted Forward-Neutral-Reverse
Speed Selection	Dash Mounted Speed/Range Switch
Rear Axle Ratio	12.49:1
Front Axle Ratio	12.49:1
Seating Capacity	4 People
Curb Weight	1685 lb. (764 kg)
Vehicle Load Capacity	940 lb (426 kg)
Gross Front Axle Rating	678 lb (308 kg)
Gross Rear Axle Rating	1947 lb (kg)
Outside Clearance Circle	24 ft. (7.5 m)
Speed - Low (Level Ground)	16 mph (25.7 kph)
Speed - High (Level Ground)	24.5 mph (39.4 kph)
Speed - Reverse (Level Ground)	10 mph (16.1 kph)
Towing Capacity	1000 lb 454(kg)
Steering	Self-compensating rack and pinion
Front Suspension	Coil springs with MacPherson Struts
Rear Suspension	Leaf springs with hydraulic shock absorbers
Service Brake	4-wheel Hydraulic Disc Brakes and Induction Motor
Parking Brake	Speed Based Electronic Motor Brake
Front Tires	Carlisle Trail Pro 25 x 8 - 12
Rear Tires	Carlisle Trail Pro 25 x 10 - 12
Frame	Welded steel with E-Shield ecoat plus DuraShield™ powder coat
Body and Finish	Injection molded TPO

VEHICLE SPECIFICATIONS

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Notes:

A large grid of graph paper for taking notes, consisting of 20 columns and 30 rows of small squares.

PERIODIC SERVICE SCHEDULE

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

PERIODIC SERVICE SCHEDULE

PSS

C - CHECK

C&A - CHECK & ADJUST

CL - CLEAN

R - REPLACE


REMARKS	Before each use DAILY	WEEKLY	20 hrs MONTHLY	50 hrs QUARTERLY	125 hrs SEMI-ANNUAL	250 - 300 hrs ANNUAL	5 YEARS
Tires - Check pressure and inspect condition of tires & rims.	C	C	C	C	C	C	
Hardware - Check for loose or missing.	C	C	C	C	C	C	
Overall Vehicle Condition	C	C	C	C	C	C	
Battery Pack - Check state of charge, condition, loose terminals, corrosion, hold down & hardware.	C	C	CL	CL	CL	CL	
Brake Pedal - Check for smooth operation	C	C	C	C	C	C	
Accelerator - Check for smooth operation.	C	C	C	C	C	C	
Charger / Receptacle - Inspect charger connector and receptacle.	C	C	C	C	C	C	
Brakes - Conduct brake performance test; adjust if required.			C&A	C&A	C&A	C&A	
Wiring - Inspect for loose connections, broken or missing insulation.			C	C	C	C	
Steering Assembly - Check for excess play, loose or missing hardware.			C	C	C	C	
Tie Rods - Check for excess play, bent rods, loose or missing hardware.			C	C	C	C	
Front Axle - Check for damage to axle, loose or missing hardware.				C	C	C	
Rear Axle - Noise, loose or missing hardware.			C	C	C	C	
Front and Rear Differential- Check for leaks, drain & replace fluid.			C	C	C	C	R
Rear Suspension - Inspect for shock oil leakage, worn bushings, loose or missing hardware.				C	C	C	
Front Suspension - Inspect for strut oil leakage, excessive play in hubs or kingpins, worn bushings, loose or missing hardware.				C	C	C	
Front Wheel Alignment - Inspect for unusual tire wear.				C&A	C&A	C&A	
Steering Assembly - Inspect bellows and pinion seal for damage and leakage.					C	C	
Rack End Ball Joint - Check for noise and loose or missing hardware.					C	C	

NOTE: Some maintenance items must be serviced more frequently on vehicles used under severe driving conditions.

PERIODIC SERVICE SCHEDULE

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Notes:

A large grid of graph paper, consisting of 20 columns and 30 rows of small squares, intended for taking notes.

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

APPENDIX A

BATTERY CHARGER USER'S GUIDE

APPENDIX A

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.



QuiQ™ 1500 Industrial Battery Charger Product Manual

This manual contains important safety and operating instructions for Delta-Q QuiQ 1500 chargers. Please read this information in its entirety before using your QuiQ Charger. For technical support, please visit delta-q.com/support or contact the manufacturer of your vehicle or machine, as their versions of this charger may require special instructions.

1500



Warning

Use charger only with an algorithm selected that is appropriate to the specific battery type. Other usage may cause personal injury and damage. Lead acid batteries may generate explosive hydrogen gas during normal operation. Keep sparks, flames, and smoking materials away from batteries. Provide adequate ventilation during charging. Never charge a frozen battery. Study all battery manufacturers' specific precautions (e.g. maximum charge rates and if cell caps should be removed while charging).



Danger

Risk of electric shock. Connect charger power cord to an outlet that has been properly installed and grounded in accordance with all local codes and ordinances. A grounded outlet is required to reduce risk of electric shock – do not use ground adapters or modify plug. Do not touch uninsulated portions of output connector or uninsulated battery terminals. Disconnect the AC supply before making or breaking the connections to the battery. Do not open or disassemble charger. Do not operate this charger if the AC supply cord is damaged or if the charger has received a sharp blow, been dropped, or is damaged in any way – refer all repair work to the manufacturer, or qualified personnel. This charger is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge on electrical systems and battery charging, unless they have been given supervision or instruction concerning use of the charger by a person responsible for their safety. Children should be supervised to ensure that they do not play with the charger.



Attention

Utiliser le chargeur seulement avec un algorithme approprié au type spécifique de batterie. D'autres types de batteries pourraient éclater et causer des blessures ou dommages. Les batteries peuvent produire des gaz explosifs en service normal. Ne jamais fumer près de la batterie et éviter toute étincelle ou flamme nue à proximité des batteries. Fournissez une ventilation adéquate du chargement. Ne jamais charger une batterie gelée. Prendre connaissance des mesures de précaution spécifiées par le fabricant de la batterie, p. ex., vérifier s'il faut enlever les bouchons des cellules lors du chargement, et les taux de chargement.



Danger

Risque de décharge électrique. Ne pas toucher les parties non isolées du connecteur de sortie ou les bornes non isolées de la batterie. Toujours connecter le chargeur à une prise de courant mise à la terre. Déconnectez la source AC avant de faire ou défaire les connections à la batterie en chargement. Ne pas utiliser le chargeur si le cordon d'alimentation AC est endommagé ou si le chargeur est abîmé suite à une chute ou autre incident. Ne pas ouvrir ni désassembler le chargeur – référer toute réparation aux personnes qualifiées. Cet appareil n'est pas destiné à un usage par des personnes (dont les enfants) avec des facultés motrices, sensorielles ou mentales réduites, ou ayant une expérience et des connaissances insuffisantes, à moins qu'elles sont sous la supervision ou reçoivent les instructions sur l'utilisation de l'appareil d'un répondant garant de leur sécurité. Les enfants devraient être surveillés afin qu'il ne jouent en aucun temps avec l'appareil.

Operating Instructions

- ✦ The charger may become hot during charging. Use hand protection to safely handle the charger during charging.
- ✦ Extension cords must be 3-wire cord no longer than 30m (100') at 10 AWG or 7.5m (25') at 16 AWG per UL guidelines.
- ✦ Only connect one QuiQ Charger to a single 120VAC 15A circuit, or the circuit may become overloaded.
- ✦ The charger will conduct a self-test after being powered on, visible by flashing all of its LEDs in sequence.

Charger 10-LED Display

Ammeter

- ✦ If solid: Displays scale of output during bulk phase.
- ✦ If flashing: Output has been reduced due to high internal charger temperature. Displays charge profiles 1-6 for 11 seconds if no battery is connected.

Bulk Charge Indicator

- ✦ If solid: Bulk charge phase complete (80% charged); in absorption phase.
- ✦ If flashing: Displays charge profile number if no battery is connected.

Charge Completion Indicator (Green Light)

- ✦ If solid: Charging complete and maintenance mode is active.
- ✦ If flashing: Absorption phase complete, in finishing phase.

AC Indicator

- ✦ If solid: AC voltage is above 185 volts.
- ✦ If flashing: AC voltage is between 105 volts and 185 volts.
- ✦ If off: AC voltage is below 105 volts.

Fault Indicator (Red Light)

- ✦ Charger error. Refer to troubleshooting information below.

© 2015 Delta-Q Technologies Corp. All rights reserved.
(DOCUMENT 710-0188 Rev 1 Date: 31/05/2015)

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Optional Remote Single -LED Display

Delta-Q QuiQ 1500 Charger Manual



LED Color	Indication
Green	<ul style="list-style-type: none"> + If solid: Charging complete and maintenance mode is active. + If flashing: <ul style="list-style-type: none"> Short: <80% Charge. Long: >80% Charge. When battery is not connected: Charge Profile (Algorithm Number) is displayed when first connected to AC, then will show "Battery low voltage" error
Amber	<ul style="list-style-type: none"> + If flashing: Reduced power mode due to high internal charger temperature.
Red	<ul style="list-style-type: none"> + If flashing: Charging error. Reset charger power and refer to Troubleshooting Instructions below.

Maintenance Instructions

- Do not expose charger to high pressure water spray when cleaning vehicle.
- The enclosure of the charger meets IP66, making it dust-tight and protected against powerful water jets. The AC connection is rated to IP20, which is not protected against water. Protect the AC connection if used in wet or dusty environments.
- If the detachable input power supply cord set is damaged, replace with a cord that is appropriate for your region:
 - + This charger is provided with a cord set for connection to outlets operating at nominal 120 Volts (or 240 Volts as appropriate). If the input plug does not fit the power outlet, contact Delta-Q Technologies for the proper cord set terminating in an attachment plug of the proper configuration for the power outlet.
 - + 'North America: UL or CSA listed / approved detachable cord, 3 conductor, 16AWG minimum and rated SJT; terminated in a grounding type IEC 60320 C14 plug rated 250V, 13A minimum
 - + For all other regions: Safety approved detachable cord, 3 conductor, 1.5mm² minimum, rated appropriately for industrial use. The cord set must be terminated on one end with a grounding type input connector appropriate for use in the country of destination and, on the other end, an output grounding type IEC 60320 C14 plug.

Troubleshooting Instructions

If a fault occurs, count the number of red flashes between pauses and refer to the table below.

Flashes	Cause	Solution
⏸️ 🔴 ⏸️	Battery high voltage	Check battery size and condition. This fault will clear automatically once the condition has been corrected.
⏸️ 🔴 🔴 ⏸️	Battery low voltage	Check battery size and condition. This fault will clear automatically once the condition has been corrected.
⏸️ 🔴 🔴 🔴 ⏸️	Charge timeout caused by battery pack not reaching required voltage; or charger output reduced due to high temperatures.	Check connections, that battery type matches selected charge profile and operate the charger at a lower ambient temperature. Reset the charger by interrupting AC power for 15+ seconds.
⏸️ 🔴 🔴 🔴 🔴 ⏸️	Battery could not be trickle charged up to minimum voltage.	Check for shorted or damaged cells. Reset the charger by interrupting AC power for 15+ seconds.
⏸️ 🔴 🔴 🔴 🔴 🔴 ⏸️	Charger shutdown due to high internal temperature.	Ensure sufficient cooling airflow. Reset the charger by interrupting AC power for 15+ seconds.
⏸️ 🔴 🔴 🔴 🔴 🔴 🔴 ⏸️	Internal charger fault	Reset the charger by interrupting AC power for 15+ seconds. Return to service depot if fault persists.

Note: This is a Class A product complying with United States Federal Communications Commission, Code of Federal Regulations; 47CFR part 15. In a domestic environment this product may cause radio interference, in which case the user may be required to take adequate measures.

WARNING: Charger connectors must be mated to connectors from the same manufacturer. Failure to do so may void warranty and cause a hazardous condition or equipment damage.



www.delta-q.com

APPENDIX A

Read all of SAFETY and this section before attempting any procedure. Pay particular attention to Notices, Cautions, Warnings and Dangers.

Selecting A Charge Profile

Delta-Q's QuiQ 1500 Charger can store up to 10 charging profiles, also called charge algorithms. This section shows how to identify the default profile and select a new profile using the "tap method."

QuiQ chargers are reprogrammable using the QuiQ Programmer supplied by Delta-Q to its OEM partners. Pre-2006 QuiQ chargers with serial number prefix DQCP allow pre-loaded profiles to be selected, but cannot be reprogrammed with new profiles.

Identify the default profile

1. Required supplies include an insulated wrench, eye protection and gloves.

2. Disconnect the AC power source from the charger, either from the wall outlet, or from the IEC320 connector on the charger.



Figure 1: Disconnect AC power.

3. Use your insulated wrench to remove the positive lead from the positive terminal on the battery pack.



Figure 2: Remove positive lead from positive terminal on the battery pack.

4. Reconnect AC power.



Figure 3: Reconnect AC power to the charger.

5. Charger will conduct a self-test of its LED indicators.



Figure 4: Charger LED indicator self-test.

6a. For 11 seconds after the self-test, the charger will display its default charge profile. Profiles #1-6 will display on the ammeter, as well as on the bulk charge indicator.



Figure 5: Charge profile #1 on the ammeter.

6b. Charge profiles #7 and above will display on the bulk charge indicator. If the charge profile number has two digits, it will be displayed by one or more flashes, a pause, then one or more flashes (e.g. #13 =    )



Figure 6: Bulk charge indicator displays charge profiles 7 and above.

Select a new profile

7. Disconnect AC power (see Figure 1).

8. Reconnect AC power (see Figure 3).

9. Touch the positive lead to the positive terminal for three seconds (+/- 0.5 seconds), then remove the lead. You will see the next profile displayed on the charger's display. Repeat this step until you reach the desired charge profile.



Figure 7: Touch the positive lead to the positive battery terminal for 3 seconds.

10. When the charger displays the desired charge profile, apply the positive lead to the positive battery terminal for 10 seconds. When the charge profile is locked, you will hear a click from the charger. See Figure 7 for how to apply the positive lead to the positive terminal.

11. Disconnect AC power, wait for the LED indicator display to turn off, then reconnect AC power. (See Figure 3)

12. Check the LED display to ensure that the desired charge profile is selected.

13. Disconnect the charger from AC power and wait for the LED indicator display to turn off. (See Figure 1)

14. Reconnect the positive lead to the positive battery terminal.



Figure 8: Reattach the positive lead to the positive terminal after disconnecting AC power.

 Visit www.youtube.com/deltaqtechnologies for instructional videos.

NOTICE: Read the following warnings before operating vehicle:

⚠ WARNING When the vehicle is without an operator, engage the parking brake, turn the key switch to the OFF position, and remove the key from the switch.

Operate the vehicle only as fast as the terrain and safety conditions allow. Consider the terrain and traffic conditions. Consider environmental conditions that change the terrain and your ability to control the vehicle.

Do not drive fast downhill. Sudden stops or change of direction can cause a loss of control. Use the brake to control the speed of the vehicle when you drive down a slope.

All travel must be straight up or down hills. Use cautions if you must drive across a slope.

Stay in designated areas and avoid steep slopes. When the vehicle is parked, engage the parking brake.

Always keep feet, legs, hands and arms inside vehicle.

Do not drive on rough terrain.

Before driving in reverse, make sure the area behind the vehicle is clear.

Make sure the direction selector is in the correct position before pressing the accelerator pedal.

Decrease speed before and during turns.

Always completely stop the vehicle before moving the direction selector.

See **GENERAL SPECIFICATIONS for the vehicle load and seat capacity (See VEHICLE SPECIFICATIONS on page 129).**

NOTICE: Read the following information and warnings before operating vehicle:

In any product, components will eventually fail to perform properly as the result of normal use, age, wear or abuse.

The manufacturer can not know all possible component failures or the methods that failures can occur.

A vehicle in need of repair does not operate correctly and can be dangerous.

Be careful when you service the vehicle. Be aware of your safety and the safety of other people in the area.

Some components are heavy, spring loaded, corrosive, explosive, can cause high amperage or get hot. Battery acid and hydrogen gas can cause injury. Do not put your hands, face, feet or body in a location that can expose them to injury if an unexpected situation occurs.

Always use the correct tools shown in the tool list and wear safety equipment.

⚠ WARNING Remove all jewelry before you service the vehicle.

Do not allow loose clothing or hair to contact the moving parts.

Do not touch hot objects.

The drive wheels must be lifted and supported on jack stands before servicing the powertrain when the motor is in operation.



When servicing the vehicle, always wear eye protection. Be careful when working around batteries or using solvents or compressed air.

Use wrenches with insulation to decrease the risk of a short-circuit if a wrench falls across the battery terminals. A battery short-circuit can cause an explosion.

To prevent the risk of battery explosion, keep all flammable materials, open flames or sparks away from the batteries.

TRACKER



OFF ROAD™

Manufacturer Information:

Textron Specialized Vehicles, Inc.

1451 Marvin Griffin Road

Augusta, Georgia, USA 30906-3852

Dealer: 800-286-4804

Consumer: 877-294-6727

www.trackeroffroad.com

Copyrighted Material

This manual may not be reproduced in whole
or in part without the express permission of
the manufacturer.